

# **TRIPLE S** *Customs*

## **FORD EXPLORER SPORT TRAC 2001-2005 VEHICLE WIRING**

WIRING INFORMATION: 2001 Ford Explorer Sport Trac

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	YELLOW	Ignition Harness
STARTER WIRE	RED/LT. BLUE	Ignition Harness
IGNITION WIRE	LT GREEN/PURPLE	Ignition Harness
ACCESSORY WIRE	BROWN (2 brown wires, both must be energized with separate relays)	Ignition Harness
SECOND ACCESSORY WIRE	BLACK/GREEN	Ignition Harness
POWER LOCK (models with OEM keyless: negative trigger, on models without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER UNLOCK (models with OEM keyless: negative trigger, on models without OEM keyless: 5-wire reverse polarity)	PINK/LT GREEN	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> <li>The factory module that controls the door locks shuts down to conserve power. When installing an aftermarket keyless entry system, hook up dome light supervision and program the aftermarket system for a double-pulse unlock to "wake up" the module and unlock the doors.</li> </ul>		
PARKING LIGHTS (+)	WHITE/BLACK or BROWN	Headlight Switch
DOOR TRIGGER (-)	YELLOW/BLACK (driver front) GREEN/YELLOW (driver rear) GRAY/RED (pass. front) PINK/LT.BLUE (pass. rear)	Trigger Wires For Driver Side Doors Located In Harness In Driver's Kick Panel, Trigger Wires For Passenger Side Doors Located In Harness In Passenger's Kick Panel
DOME SUPERVISION	Use door trigger	
HOOD TRIGGER (-)	TAN/LT.GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms on lock w/ door open	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/YELLOW	Powertrain Control Module Located In Engine Bay Against Firewall On Passenger Side
BRAKE WIRE (+)	LT GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2002 Ford Explorer Sport Trac

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	YELLOW	Ignition Harness
STARTER WIRE	RED/LT. BLUE	Ignition Harness
IGNITION WIRE	LT GREEN/PURPLE	Ignition Harness
ACCESSORY WIRE	BROWN (2 brown wires, both must be energized with separate relays)	Ignition Harness
SECOND ACCESSORY WIRE	BLACK/GREEN	Ignition Harness
POWER LOCK (models with OEM keyless: negative trigger, on models without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER UNLOCK (models with OEM keyless: negative trigger, on models without OEM keyless: 5-wire reverse polarity)	PINK/LT GREEN	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> <li>The factory module that controls the door locks shuts down to conserve power. When installing an aftermarket keyless entry system, hook up dome light supervision and program the aftermarket system for a double-pulse unlock to "wake up" the module and unlock the doors.</li> </ul>		
PARKING LIGHTS (+)	WHITE/BLACK or BROWN	Headlight Switch
DOOR TRIGGER (-)	YELLOW/BLACK (driver front) GREEN/YELLOW (driver rear) GRAY/RED (pass. front) PINK/LT.BLUE (pass. rear)	Trigger Wires For Driver Side Doors Located In Harness In Driver's Kick Panel, Trigger Wires For Passenger Side Doors Located In Harness In Passenger's Kick Panel
DOME SUPERVISION	Use door trigger	
HOOD TRIGGER (-)	TAN/LT.GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms on lock w/ door open	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/YELLOW	Powertrain Control Module Located In Engine Bay Against Firewall On Passenger Side
BRAKE WIRE (+)	LT GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2003 Ford Explorer Sport Trac

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	YELLOW	Ignition Harness
STARTER WIRE	RED/LT. BLUE	Ignition Harness
IGNITION WIRE	LT GREEN/PURPLE	Ignition Harness
ACCESSORY WIRE	BROWN (2 brown wires, both must be energized with separate relays)	Ignition Harness
SECOND ACCESSORY WIRE	BLACK/GREEN	Ignition Harness
POWER LOCK (models with OEM keyless: negative trigger, on models without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER UNLOCK (models with OEM keyless: negative trigger, on models without OEM keyless: 5-wire reverse polarity)	PINK/LT GREEN	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> <li>The factory module that controls the door locks shuts down to conserve power. When installing an aftermarket keyless entry system, hook up dome light supervision and program the aftermarket system for a double-pulse unlock to "wake up" the module and unlock the doors.</li> </ul>		
PARKING LIGHTS (+)	WHITE/BLACK or BROWN	Headlight Switch
DOOR TRIGGER (-)	YELLOW/BLACK (driver front) GREEN/YELLOW (driver rear) GRAY/RED (pass. front) PINK/LT.BLUE (pass. rear)	Trigger Wires For Driver Side Doors Located In Harness In Driver's Kick Panel, Trigger Wires For Passenger Side Doors Located In Harness In Passenger's Kick Panel
DOME SUPERVISION	Use door trigger	
HOOD TRIGGER (-)	TAN/LT.GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms on lock w/ door open	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/YELLOW	Powertrain Control Module Located In Engine Bay Against Firewall On Passenger Side
BRAKE WIRE (+)	LT GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2004 Ford Explorer Sport Trac

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/LT. BLUE	Ignition Harness
IGNITION WIRE	LT GREEN/PURPLE	Ignition Harness
ACCESSORY WIRE	PINK/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
THIRD ACCESSORY WIRE	GRAY/YELLOW	Ignition Harness
POWER LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER UNLOCK (-)	PINK/LT GREEN	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> <li>The factory module that controls the door locks shuts down to conserve power. When installing an aftermarket keyless entry system, hook up dome light supervision and program the aftermarket system for a double-pulse unlock to "wake up" the module and unlock the doors.</li> </ul>		
PARKING LIGHTS (+)	BROWN	Headlight Switch
DOOR TRIGGER (-)	YELLOW/BLACK (driver front) GRAY/RED (all passenger doors)	Trigger Wires For Driver Side Doors Located In Harness In Driver's Kick Panel, Trigger Wires For Passenger Doors Located In Harness In Passenger's Kick Panel
DOME SUPERVISION (+)	BLACK/BLUE	Harness In Driver's Kick Panel
TACHOMETER	TAN/YELLOW	Powertrain Control Module Located In Engine Bay Against Firewall On Passenger Side
BRAKE WIRE (+)	LT GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Column
LEFT FRONT WINDOW UP	YELLOW	At Window Switch
LEFT FRONT WINDOW DOWN	WHITE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 Ford Explorer Sport Trac

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	RED/LT. BLUE	Ignition Harness
IGNITION WIRE	LT GREEN/PURPLE	Ignition Harness
ACCESSORY WIRE	PINK/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
THIRD ACCESSORY WIRE	GRAY/YELLOW	Ignition Harness
POWER LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER UNLOCK (-)	PINK/LT GREEN	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> <li>The factory module that controls the door locks shuts down to conserve power. When installing an aftermarket keyless entry system, hook up dome light supervision and program the aftermarket system for a double-pulse unlock to "wake up" the module and unlock the doors.</li> </ul>		
PARKING LIGHTS (+)	BROWN	Headlight Switch
DOOR TRIGGER (-)	YELLOW/BLACK (driver front) GRAY/RED (all passenger doors)	Trigger Wires For Driver Side Doors Located In Harness In Driver's Kick Panel, Trigger Wires For Passenger Doors Located In Harness In Passenger's Kick Panel
DOME SUPERVISION (+)	BLACK/BLUE	Harness In Driver's Kick Panel
TACHOMETER	TAN/YELLOW	Powertrain Control Module Located In Engine Bay Against Firewall On Passenger Side
BRAKE WIRE (+)	LT GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Column
LEFT FRONT WINDOW UP	YELLOW	At Window Switch
LEFT FRONT WINDOW DOWN	WHITE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		