

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED	Ignition Harness
STARTER WIRE 1	DARK GREEN	Ignition Harness
IGNITION WIRE 1	LT.GREEN/PURPLE	Ignition Harness
ACCESSORY WIRE 1	GRAY/YELLOW	Ignition Harness
FACTRY ALARM ARM (-)	Arms on lock with a door open	
FACTRY ALARM DISARM (-)	LT.BLUE/BLACK	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TACHOMETER WIRE	NOT RED	Any Fuel Injector
BRAKE WIRE (+)	RED/LIGHT GREEN	At Switch Or Connector A at Module Attached To Fuse Box
HORN TRIGGER (-)	DK.BLUE	Harness At Steering Column Or Connector B at Module Attached To Fuse Box
PARKING LIGHTS (+)	BROWN/WHITE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
PARKING LIGHTS (-)	BLACK/LT.GREEN	Harness In Driver's Kick Panel Or Connector D at Module Attached To Fuse Box
ALL DOOR TRIGGER (-)	Use domelight wire. The individual door trigger wires rest at ground and go to an open circuit when the door is opened.	
DOME SUPERVISION (+)	BLACK/LT. BLUE	PLUG E - PIN #7at Module Attached To Fuse Box
LEFT FRONT DOOR TRIGGER (-)	LT.GREEN/BLACK	PLUG C - PIN #20 at Module Attached To Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	YELLOW/LT.GREEN	PLUG C - PIN #22 at Module Attached To Fuse Box
LEFT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	PLUG C - PIN #7 at Module Attached To Fuse Box
RIGHT REARDOOR TRIGGER (-)	RED	PLUG C - PIN #6 at Module Attached To Fuse Box
TRUNK TRIGGER (-)	WHITE/PURPLE	PLUG C - PIN #5 at Module Attached To Fuse Box
POWER DOOR LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
POWER UNLOCK (-)	PINK/ LT. GREEN	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TRUNK RELEASE (-)	PINK/ORANGE	At Switch Or Connector D at Module Attached To Fuse Box
LEFT FRONT WINDOW UP	Not recommended due to one-touch open and close.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	PURPLE	Radio Harness	
RADIO GROUND	BLACK/ORANGE	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
FACTORY AMP TURN-ON	GRAY/BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	ORANGE/LT.GREEN	At Speaker	
LEFT FRONT SPEAKER (-)	LT.BLUE/WHITE	At Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN/ORANGE	At Speaker	
LEFT REAR SPEAKER (+)	GRAY/LT.BLUE	At Speaker	
LEFT REAR SPEAKER (-)	TAN/YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	ORANGE/RED	At Speaker	
RIGHT REAR SPEAKER (-)	BROWN/PINK	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-5812, SCOSCHE FD1424B	METRA 70-5520, SCOSCHE FDK11B	Not required	
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED	Ignition Harness
STARTER WIRE 1	DARK GREEN	Ignition Harness
IGNITION WIRE 1	LT.GREEN/PURPLE	Ignition Harness
ACCESSORY WIRE 1	GRAY/YELLOW	Ignition Harness
FACTRY ALARM ARM (-)	Arms on lock with a door open	
FACTRY ALARM DISARM (-)	LT.BLUE/BLACK	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TACHOMETER WIRE	NOT RED	Any Fuel Injector
BRAKE WIRE (+)	RED/LIGHT GREEN	At Switch Or Connector A at Module Attached To Fuse Box
HORN TRIGGER (-)	DK.BLUE	Harness At Steering Column Or Connector B at Module Attached To Fuse Box
PARKING LIGHTS (+)	BROWN/WHITE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
PARKING LIGHTS (-)	BLACK/LT.GREEN	Harness In Driver's Kick Panel Or Connector D at Module Attached To Fuse Box
ALL DOOR TRIGGER (-)	Use domelight wire. The individual door trigger wires rest at ground and go to an open circuit when the door is opened.	
DOME SUPERVISION (+)	BLACK/LT. BLUE	PLUG E - PIN #7at Module Attached To Fuse Box
LEFT FRONT DOOR TRIGGER (-)	LT.GREEN/BLACK	PLUG C - PIN #20 at Module Attached To Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	YELLOW/LT.GREEN	PLUG C - PIN #22 at Module Attached To Fuse Box
LEFT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	PLUG C - PIN #7 at Module Attached To Fuse Box
RIGHT REARDOOR TRIGGER (-)	RED	PLUG C - PIN #6 at Module Attached To Fuse Box
TRUNK TRIGGER (-)	WHITE/PURPLE	PLUG C - PIN #5 at Module Attached To Fuse Box
POWER DOOR LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
POWER UNLOCK (-)	PINK/ LT. GREEN	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TRUNK RELEASE (-)	PINK/ORANGE	At Switch Or Connector D at Module Attached To Fuse Box
LEFT FRONT WINDOW UP	Not recommended due to one-touch open and close.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	PURPLE	Radio Harness	
RADIO GROUND	BLACK/ORANGE	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
FACTORY AMP TURN-ON	GRAY/BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	ORANGE/LT.GREEN	At Speaker	
LEFT FRONT SPEAKER (-)	LT.BLUE/WHITE	At Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN/ORANGE	At Speaker	
LEFT REAR SPEAKER (+)	GRAY/LT.BLUE	At Speaker	
LEFT REAR SPEAKER (-)	TAN/YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	ORANGE/RED	At Speaker	
RIGHT REAR SPEAKER (-)	BROWN/PINK	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5812, SCOSCHE FD1424B		METRA 70-5520, SCOSCHE FDK11B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED	Ignition Harness
STARTER WIRE 1	DARK GREEN	Ignition Harness
IGNITION WIRE 1	LT.GREEN/PURPLE	Ignition Harness
ACCESSORY WIRE 1	GRAY/YELLOW	Ignition Harness
FACTRY ALARM ARM (-)	Arms on lock with a door open	
FACTRY ALARM DISARM (-)	LT.BLUE/BLACK	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TACHOMETER WIRE	NOT RED	Any Fuel Injector
BRAKE WIRE (+)	RED/LIGHT GREEN	At Switch Or Connector A at Module Attached To Fuse Box
HORN TRIGGER (-)	DK.BLUE	Harness At Steering Column Or Connector B at Module Attached To Fuse Box
PARKING LIGHTS (+)	BROWN/WHITE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
PARKING LIGHTS (-)	BLACK/LT.GREEN	Harness In Driver's Kick Panel Or Connector D at Module Attached To Fuse Box
ALL DOOR TRIGGER (-)	Use domelight wire. The individual door trigger wires rest at ground and go to an open circuit when the door is opened.	
DOME SUPERVISION (+)	BLACK/LT. BLUE	PLUG E - PIN #7at Module Attached To Fuse Box
LEFT FRONT DOOR TRIGGER (-)	LT.GREEN/BLACK	PLUG C - PIN #20 at Module Attached To Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	YELLOW/LT.GREEN	PLUG C - PIN #22 at Module Attached To Fuse Box
LEFT REAR DOOR TRIGGER (-)	PURPLE/LT.GREEN	PLUG C - PIN #7 at Module Attached To Fuse Box
RIGHT REARDOOR TRIGGER (-)	RED	PLUG C - PIN #6 at Module Attached To Fuse Box
TRUNK TRIGGER (-)	WHITE/PURPLE	PLUG C - PIN #5 at Module Attached To Fuse Box
POWER DOOR LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
POWER UNLOCK (-)	PINK/ LT. GREEN	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TRUNK RELEASE (-)	PINK/ORANGE	At Switch Or Connector D at Module Attached To Fuse Box
LEFT FRONT WINDOW UP	Not recommended due to one-touch open and close.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	PURPLE	Radio Harness	
RADIO GROUND	BLACK/ORANGE	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
FACTORY AMP TURN-ON	GRAY/BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	ORANGE/LT.GREEN	At Speaker	
LEFT FRONT SPEAKER (-)	LT.BLUE/WHITE	At Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN/ORANGE	At Speaker	
LEFT REAR SPEAKER (+)	GRAY/LT.BLUE	At Speaker	
LEFT REAR SPEAKER (-)	TAN/YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	ORANGE/RED	At Speaker	
RIGHT REAR SPEAKER (-)	BROWN/PINK	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-5812, SCOSCHE FD1424B	METRA 70-5520, SCOSCHE FDK11B		Not required
Please verify all part numbers before ordering.			