

**Vehicle Wiring Information**  
for the  
**1966 Ford Mustang**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/blue		ign harness, behind cluster
SECOND STARTER			
IGNITION	red/green		ign harness, behind cluster
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	black/green		ign harness, behind cluster
SECOND ACCESSORY			
POWER LOCK			
POWER UNLOCK			
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/wht & blu/red		switch in driver side dash
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	black/blue	+	underdash domelight
DOVE SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes: