

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLACK/RED	Ignition Harness
SECOND ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness At Fuse Box
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	YELLOW/GREEN or YELLOW/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	LIGHT GREEN/BLACK	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)	BLUE/ORANGE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"	Behind Trim In Right Rear Cargo Area	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5556, SCOSCHE FD1510B		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW or BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE or BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLACK/RED or BLUE	Ignition Harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	YELLOW/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	LIGHT GREEN/BLACK	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)	BLUE/ORANGE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"	Behind Trim In Right Rear Cargo Area	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5556, SCOSCHE FD1510B		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW or BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE or BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLACK/RED or BLUE	Ignition Harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	YELLOW/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	LIGHT GREEN/BLACK	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)	BLUE/ORANGE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"	Behind Trim In Right Rear Cargo Area	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5556, SCOSCHE FD1510B		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW or BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE or BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLACK/RED or BLUE	Ignition Harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	YELLOW/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	LIGHT GREEN/BLACK	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)	BLUE/ORANGE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"	Behind Trim In Right Rear Cargo Area	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5556, SCOSCHE FD1510B		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/PINK	Ignition Harness
ACCESSORY WIRE	BLUE/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	ORANGE	Harness At Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	LT.BLUE	Harness At Top Of Fuse Box
FACTORY ALARM DISARM (-)	YELLOW/RED	In Gray Connector Behind Fuse Box
TACHOMETER	YELLOW/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	ORANGE	Radio Harness	
POWER ANTENNA (+)	LIGHT GREEN/YELLOW	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"	Behind Right Rear Speaker	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/PINK	Ignition Harness
ACCESSORY WIRE	BLUE/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	ORANGE	Harness At Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	LT.BLUE	Harness At Top Of Fuse Box
FACTORY ALARM DISARM (-)	YELLOW/RED	In Gray Connector Behind Fuse Box
TACHOMETER	YELLOW/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	ORANGE	Radio Harness	
POWER ANTENNA (+)	LIGHT GREEN/YELLOW	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"	Behind Right Rear Speaker	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or BLACK	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/PINK	Ignition Harness
ACCESSORY WIRE	BLUE/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	ORANGE	Harness At Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	LT.BLUE	Harness At Top Of Fuse Box
FACTORY ALARM DISARM (-)	YELLOW/RED	In Gray Connector Behind Fuse Box
TACHOMETER	YELLOW/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	ORANGE	Radio Harness	
POWER ANTENNA (+)	LIGHT GREEN/YELLOW	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"	Behind Right Rear Speaker	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE	Ignition harness
STARTER WIRE	GREEN	Ignition harness
12V IGNITION WIRE	BLACK/PINK	Ignition harness
ACCESSORY WIRE	BLACK/RED	Ignition harness
SECOND ACCESSORY WIRE	BLUETYELLOW	Ignition harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	ORANGE	Harness At Top of fuse box
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's kick panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN	At Ignition coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake pedal switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering column
LEFT FRONT WINDOW UP	GREEN/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	ORANGE	Radio Harness	
POWER ANTENNA (+)	LIGHT GREEN/YELLOW	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"	Behind Right Rear Speaker	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE	Ignition harness
STARTER WIRE	GREEN	Ignition harness
12V IGNITION WIRE	BLACK/PINK	Ignition harness
ACCESSORY WIRE	BLACK/RED	Ignition harness
SECOND ACCESSORY WIRE	BLUETYELLOW	Ignition harness
POWER DOOR LOCK (+)	GREEN/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK	Same wire as lock	
Notes: Unlock is a positive trigger through a 4700-ohm resistor. Refer to TechDoc 3958		
PARKING LIGHTS (+)	ORANGE	Harness At Top of fuse box
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's kick panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN	At Ignition coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake pedal switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering column
LEFT FRONT WINDOW UP	GREEN/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND	BLACK/PINK	Radio Harness	
ILLUMINATION (+)	ORANGE	Radio Harness	
POWER ANTENNA (+)	LIGHT GREEN/YELLOW	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"	Behind Right Rear Speaker	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1770, SCOSCHE FD02B	Not required
Please verify all part numbers before ordering.			