

TRIPLE S *Customs*

FORD RANGER 1993-2005 VEHICLE WIRING

WIRING INFORMATION 1993 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT	YELLOW	Ignition Harness
STARTER	RED/LT. BLUE	Ignition Harness
IGNITION	RED/LT. GREEN	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (5-wire reverse polarity)	PINK/YELLOW	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/GREEN	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Head Light Switch
HEADLIGHTS (+)	RED/YELLOW	At Head Light Switch
DOOR TRIGGER (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel Or Courtesy Light Under Dash
DOMELIGHT SUPERVISION (+)	USE DOOR TRIGGER	
TACHOMETER WIRE	GRAY/ORANGE	ECM in Passenger Kick Panel or Behind Instrument Cluster
BRAKE WIRE (+)	LT. GREEN	Harness In Driver's Kick Panel Or At Brake Pedal Switch
HORN TRIGGER (negative trigger on vehicles with factory cruise control and positive trigger on vehicles without factory cruise control)	YELLOW/LT. GREEN OR BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1994 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT	YELLOW	Ignition Harness
STARTER	RED/LT. BLUE	Ignition Harness
IGNITION	RED/LT. GREEN	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (5-wire reverse polarity)	PINK/YELLOW	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (5-wire reverse polarity)	PINK/GREEN	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Head Light Switch
HEADLIGHTS (+)	RED/YELLOW	At Head Light Switch
DOOR TRIGGER (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel Or Courtesy Light Under Dash
DOMELIGHT SUPERVISION (+)	USE DOOR TRIGGER	
TACHOMETER WIRE	GRAY/ORANGE	ECM in Passenger Kick Panel or Behind Instrument Cluster
BRAKE WIRE (+)	LT. GREEN	Harness In Driver's Kick Panel Or At Brake Pedal Switch
HORN TRIGGER (negative trigger on vehicles with factory cruise control and positive trigger on vehicles without factory cruise control)	YELLOW/LT. GREEN OR BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1995 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT	YELLOW	Ignition Harness
STARTER	RED/LT. BLUE	Ignition Harness
IGNITION	GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
SECOND ACCESSORY	BLACK/GREEN	Ignition Harness
POWER LOCK (-)	PINK/YELLOW	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
POWER UNLOCK (-)	PINK/GREEN	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN OR WHITE/BLACK	At Headlight Switch
HEADLIGHTS (+)	RED/YELLOW	At Headlight Switch
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Center of Dash
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Center Of Dash
DOME SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel
HOOD PIN (-)	TAN/LT. GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/STRIPE or YELLOW/STRIPE	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1996 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT	YELLOW	Ignition Harness
STARTER	RED/LT. BLUE	Ignition Harness
IGNITION	GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
SECOND ACCESSORY	BLACK/GREEN	Ignition Harness
POWER LOCK (-)	PINK/YELLOW	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
POWER UNLOCK (-)	PINK/GREEN	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN OR WHITE/BLACK	At Headlight Switch
HEADLIGHTS (+)	RED/YELLOW	At Headlight Switch
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Center of Dash
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Center Of Dash
DOME SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel
HOOD PIN (-)	TAN/LT. GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/STRIPE or YELLOW/STRIPE	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1997 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT	YELLOW	Ignition Harness
STARTER	RED/LT. BLUE	Ignition Harness
IGNITION	GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
SECOND ACCESSORY	BLACK/GREEN	Ignition Harness
POWER LOCK (-)	PINK/YELLOW	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
POWER UNLOCK (-)	PINK/GREEN	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN OR WHITE/BLACK	At Headlight Switch
HEADLIGHTS (+)	RED/YELLOW	At Headlight Switch
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Center of Dash
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Center Of Dash
DOME SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel
HOOD PIN (-)	TAN/LT. GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/STRIPE or YELLOW/STRIPE	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1998 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V	YELLOW	Ignition Harness
STARTER	RED/LIGHT BLUE	Ignition Harness
IGNITION	LT. GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
SECOND ACCESSORY	BLACK/LT GREEN	Ignition Harness
POWER DOOR LOCK (-)	PINK/YELLOW	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	PINK/GREEN	Harness in Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	WHITE/PURPLE	Harness In Driver's Kick Panel
HEADLIGHTS (+)	RED/YELLOW	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Center of Dash
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Center Of Dash
DOME SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	TAN/LT. GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/WHITE	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness In Driver's Kick Panel
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1999 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V	YELLOW	Ignition Harness
STARTER	RED/LIGHT BLUE	Ignition Harness
IGNITION	LT. GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
SECOND ACCESSORY	BLACK/LT GREEN	Ignition Harness
POWER DOOR LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	PINK/GREEN	Harness In Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	WHITE/PURPLE	Harness In Driver's Kick Panel
HEADLIGHTS (+)	RED/YELLOW	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Center of Dash
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Center Of Dash
DOVE SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	TAN/LT. GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/WHITE	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness In Driver's Kick Panel
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle may be equipped with PATS anti-theft system. This must be bypassed when installing a remote start system.

WIRING INFORMATION 2000 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V	YELLOW	Ignition Harness
STARTER	RED/LIGHT BLUE	Ignition Harness
IGNITION	LT. GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
SECOND ACCESSORY	BLACK/LT GREEN	Ignition Harness
POWER DOOR LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	PINK/GREEN	Harness In Driver's Kick Panel or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	WHITE/PURPLE	Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Dash Left Of Radio
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Dash Left Of Radio
DOVE SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	TAN/LT. GREEN	Harness In Driver's Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	TAN/WHITE	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness In Driver's Kick Panel
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle may be equipped with PATS anti-theft system. This must be bypassed when installing a remote start system.

WIRING INFORMATION 2001 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V	YELLOW	Ignition harness
STARTER	RED/LT. BLUE	Ignition harness
IGNITION	LT. GREEN/PURPLE	Ignition harness
ACCESSORY	GRAY/YELLOW	Ignition harness
SECOND ACCESSORY	BLACK/LT. GREEN	Ignition harness
POWER LOCK (-)	PINK/YELLOW	Harness Coming Into The Vehicle From The Driver's Door Or Harness In Passenger Kick Panel
POWER UNLOCK (-)	PINK/LT. GREEN	Harness Coming Into The Vehicle From The Driver's Door Or Harness In Passenger Kick Panel
The module controlling the factory power door locks shuts down to conserve power. When installing a system with keyless entry, you must hook up dome light supervision and program the system to double-pulse the unlock wire to "wake up" the module and operate the door locks.		
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Dash Left Of Radio
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Dash Left Of Radio
DOMESUPERVISION (-)	USE DOOR TRIGGER	
TACHOMETER	TAN/YELLOW	Instrument cluster Or Module Top Passenger Side Of Firewall Under Hood
BRAKE WIRE (+)	LT. GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2002 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V	YELLOW	Ignition harness
STARTER	RED/LT. BLUE	Ignition harness
IGNITION	LT. GREEN/PURPLE	Ignition harness
ACCESSORY	GRAY/YELLOW	Ignition harness
SECOND ACCESSORY	BLACK/LT. GREEN	Ignition harness
POWER LOCK (-)	PINK/YELLOW	Harness Coming Into The Vehicle From The Driver's Door Or Harness In Passenger Kick Panel
POWER UNLOCK (-)	PINK/LT. GREEN	Harness Coming Into The Vehicle From The Driver's Door Or Harness In Passenger Kick Panel
The module controlling the factory power door locks shuts down to conserve power. When installing a system with keyless entry, you must hook up dome light supervision and program the system to double-pulse the unlock wire to "wake up" the module and operate the door locks.		
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Dash Left Of Radio
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Dash Left Of Radio
DOMESUPERVISION (-)	USE DOOR TRIGGER	
TACHOMETER	TAN/YELLOW	Instrument cluster Or Module Top Passenger Side Of Firewall Under Hood
BRAKE WIRE (+)	LT. GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2003 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V	YELLOW	Ignition harness
STARTER	RED/LT. BLUE	Ignition harness
IGNITION	LT. GREEN/PURPLE	Ignition harness
ACCESSORY	GRAY/YELLOW	Ignition harness
SECOND ACCESSORY	BLACK/LT. GREEN	Ignition harness
POWER LOCK (-)	PINK/YELLOW	Harness Coming Into The Vehicle From The Driver's Door Or Harness In Passenger Kick Panel
POWER UNLOCK (-)	PINK/LT. GREEN	Harness Coming Into The Vehicle From The Driver's Door Or Harness In Passenger Kick Panel
The module controlling the factory power door locks shuts down to conserve power. When installing a system with keyless entry, you must hook up dome light supervision and program the system to double-pulse the unlock wire to "wake up" the module and operate the door locks.		
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	Module Behind Dash Left Of Radio
PASSENGER DOOR TRIGGER (-)	GRAY/RED	Module Behind Dash Left Of Radio
DOMESUPERVISION (-)	USE DOOR TRIGGER	
TACHOMETER	TAN/YELLOW	Instrument cluster Or Module Top Passenger Side Of Firewall Under Hood
BRAKE WIRE (+)	LT. GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	YELLOW/LT. GREEN	Harness At Steering column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2004 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V	YELLOW	Ignition harness
STARTER	RED/LT. BLUE	Ignition harness
IGNITION	LT. GREEN/PURPLE	Ignition harness
ACCESSORY	GRAY/YELLOW	Ignition harness
SECOND ACCESSORY	BLACK/LT. GREEN	Ignition harness
POWER LOCK (-)	PINK/YELLOW	In Large Black Connector At Fuse Box In Passenger Kick Panel
POWER UNLOCK (-)	PINK/LT. GREEN	In Large Black Connector At Fuse Box In Passenger Kick Panel
The module controlling the factory power door locks shuts down to conserve power. When installing a system with keyless entry, you must hook up dome light supervision and program the system to double-pulse the unlock wire to "wake up" the module and operate the door locks.		
PARKING LIGHTS (+)	BROWN	In Brown Connector At Fuse Box In Passenger Kick Panel
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	In Large Black Connector At Fuse Box In Passenger Kick Panel
PASSENGER DOOR TRIGGER (-)	GRAY/RED	In Large Black Connector At Fuse Box In Passenger Kick Panel
DOMESUPERVISION (+)	BLACK/LT.BLUE	In Gray Connector At Fuse Box In Passenger Kick Panel
TACHOMETER	NOT RED	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	DK.BLUE or YELLOW/LT. GREEN	Harness At Steering column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2005 Ford Ranger

WIRE	WIRE COLOR	WIRE LOCATION
12V	YELLOW	Ignition harness
STARTER	RED/LT. BLUE	Ignition harness
IGNITION	LT. GREEN/PURPLE	Ignition harness
ACCESSORY	GRAY/YELLOW	Ignition harness
SECOND ACCESSORY	BLACK/LT. GREEN	Ignition harness
POWER LOCK (-)	PINK/YELLOW	In Large Black Connector At Fuse Box In Passenger Kick Panel
POWER UNLOCK (-)	PINK/LT. GREEN	In Large Black Connector At Fuse Box In Passenger Kick Panel
The module controlling the factory power door locks shuts down to conserve power. When installing a system with keyless entry, you must hook up dome light supervision and program the system to double-pulse the unlock wire to "wake up" the module and operate the door locks.		
PARKING LIGHTS (+)	BROWN	In Brown Connector At Fuse Box In Passenger Kick Panel
DRIVER DOOR TRIGGER (-)	YELLOW/BLACK	In Large Black Connector At Fuse Box In Passenger Kick Panel
PASSENGER DOOR TRIGGER (-)	GRAY/RED	In Large Black Connector At Fuse Box In Passenger Kick Panel
DOMESUPERVISION (+)	BLACK/LT.BLUE	In Gray Connector At Fuse Box In Passenger Kick Panel
TACHOMETER	NOT RED	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	DK.BLUE or YELLOW/LT. GREEN	Harness At Steering column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
This vehicle may be equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		