

Vehicle Wiring Information
for the
1989 Ford Taurus

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	yellow	+	ignition harness
STARTER	white/pink	+	ignition harness
IGNITION	red/lt. green	+	ignition harness
ACCESSORY	gray/yellow	+	ignition harness
SECOND ACCESSORY	black/green	+	ignition harness
POWER LOCK	pink/yellow	*2	either kick
POWER UNLOCK	pink/green	*2	either kick
PARKING LIGHTS +	brown		at switch
PARKING LIGHTS -			
HEADLIGHTS	red/yellow	+	at switch
DOOR TRIGGER	black/blue	+	either kick
TRUNK/HATCH PIN	black/pink	-	at light
HOOD PIN			
TRNK/HATCH RELEASE	gray/red	+	at release switch
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
TACHOMETER	dk. green/yellow *1		ignition coil *1
BRAKE WIRE	red/lt. green	+	at brake switch
HORN TRIGGER	yellow/lt. green	-	steering column
WIPERS	black/pink	+	at switch
LF WINDOW UP/DN	yellow - red	A	in drivers door
RF WINDOW UP/DN	yel/blk - red/blk	A	in drivers door or dkp
LR WINDOW UP/DN	yel/blu - red/blu	A	in drivers door or dkp
RR WINDOW UP/DN	yel/blk - red/blk	A	in drivers door or dkp

Notes:

*1 For multi-coil engines the tach is gray/orange at the EDIS module on the passenger side of motor. *2 5-wire for non-keyless, negative trigger for the keyless-entry equipped versions.

Vehicle Wiring Information
for the
1988 Ford Taurus

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/blu or wht/pnk		ignition harness
SECOND STARTER			
IGNITION	red/green		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	gray/yellow		ignition harness
SECOND ACCESSORY	black/green		ignition harness
POWER LOCK	pink/yellow	5wi	kick
POWER UNLOCK	pink/green	5wi	kick
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	brown		switch or kick
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	black/blue	+	underdash light
DOME SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	tan/yellow		ignition coil
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

Vehicle Wiring Information
for the
1987 Ford Taurus

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/blu or wht/pnk		ignition harness
SECOND STARTER			
IGNITION	red/green		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	gray/yellow		ignition harness
SECOND ACCESSORY	black/green		ignition harness
POWER LOCK	pink/yellow	5wi	kick
POWER UNLOCK	pink/green	5wi	kick
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	brown		switch or kick
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	black/blue	+	underdash light
DOME SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	tan/yellow		ignition coil
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

Vehicle Wiring Information
for the
1986 Ford Taurus

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/blu or wht/pnk		ignition harness
SECOND STARTER			
IGNITION	red/green		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	gray/yellow		ignition harness
SECOND ACCESSORY	black/green		ignition harness
POWER LOCK	pink/yellow	5wi	kick
POWER UNLOCK	pink/green	5wi	kick
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	brown		switch or kick
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	black/blue	+	underdash light
DOME SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	tan/yellow		ignition coil
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPEN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes: