

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DiN opening - none required		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DiN opening - none required		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DiN opening - none required		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Head Light Switch
HEADLIGHTS (+)	RED/WHITE	At Head Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	White Connector Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BLACK/RED or BROWN	Connector Between Passenger's Seat Rail And Running Board Or Behind Driver's Rear Speaker
TACHOMETER WIRE	BROWN/WHITE	Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake Switch
HORN TRIGGER (-)	BLUE/GREEN	Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			