

# **TRIPLE S** *Customs*

## **HONDA CRV 1997-2006 VEHICLE WIRING**

WIRING INFORMATION: 1997 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-) **Must use relays**	GREEN/WHITE	Green Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-) **Must use relays**	GREEN/ORANGE	Green Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	At Dash Light Dimmer Switch
DOOR TRIGGER (-)	LT. GREEN/RED	Harness In Driver's Kick Panel
DOME SUPERVISION	USE DOOR TRIGGER WIRE	
REAR HATCH TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	YELLOW/RED OR YELLOW	At Factory Hood Pin Switch
REAR HATCH RELEASE (+)	YELLOW	At Rear Hatch Release Switch
TACHOMETER WIRE	BLUE	Single Wire Plug On Firewall Or At Distributor
BRAKE WIRE (+)	GREEN/WHITE	At Cruise Control Module In Driver's Kick Panel
HORN TRIGGER (-)	GRAY	Harness In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1998 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-) **Must use relays**	GREEN/WHITE	Green Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-) **Must use relays**	GREEN/ORANGE	Green Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	At Dash Light Dimmer Switch
DOOR TRIGGER (-)	LT. GREEN/RED	Harness In Driver's Kick Panel
DOME SUPERVISION	USE DOOR TRIGGER WIRE	
REAR HATCH TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	YELLOW/RED OR YELLOW	At Factory Hood Pin Switch
REAR HATCH RELEASE (+)	YELLOW	At Rear Hatch Release Switch
TACHOMETER WIRE	BLUE	Single Wire Plug On Firewall Or At Distributor
BRAKE WIRE (+)	GREEN/WHITE	At Cruise Control Module In Driver's Kick Panel
HORN TRIGGER (-)	GRAY	Harness In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1999 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-) **Must use relays**	GREEN/WHITE	Green Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-) **Must use relays**	GREEN/ORANGE	Green Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	At Dash Light Dimmer Switch
DOOR TRIGGER (-)	LT. GREEN/RED	Harness In Driver's Kick Panel
DOVE SUPERVISION	USE DOOR TRIGGER WIRE	
REAR HATCH TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	YELLOW/RED OR YELLOW	At Factory Hood Pin Switch
REAR HATCH RELEASE (+)	YELLOW	At Rear Hatch Release Switch
TACHOMETER WIRE	BLUE	Single Wire Plug On Firewall Or At Distributor
BRAKE WIRE (+)	GREEN/WHITE	At Cruise Control Module In Driver's Kick Panel
HORN TRIGGER (-)	GRAY	Harness In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2000 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-) **Must use relays**	GREEN/WHITE	Green Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-) **Must use relays**	GREEN/ORANGE	Green Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	At Dash Light Dimmer Switch
HEADLIGHTS (+)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	LT. GREEN/RED	Harness In Driver's Kick Panel
DOVE SUPERVISION	USE DOOR TRIGGER WIRE	
REAR HATCH TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	YELLOW/RED OR YELLOW	At Factory Hood Pin Switch
REAR HATCH RELEASE (+)	YELLOW	At Rear Hatch Release Switch
TACHOMETER WIRE	BLUE	Single Wire Plug On Firewall Or At Distributor
BRAKE WIRE (+)	GREEN/WHITE	At Cruise Control Module In Driver's Kick Panel
HORN TRIGGER (-)	GRAY	Harness In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2001 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-) **Must use relays**	GREEN/WHITE	Green Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-) **Must use relays**	GREEN/ORANGE	Green Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	At Dash Light Dimmer Switch
HEADLIGHTS (+)	RED/WHITE	Harness At Steering Column
DOOR TRIGGER (-)	LT. GREEN/RED	Harness In Driver's Kick Panel
DOVE SUPERVISION	USE DOOR TRIGGER WIRE	
REAR HATCH TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
HOOD TRIGGER (-)	YELLOW/RED OR YELLOW	At Factory Hood Pin Switch
REAR HATCH RELEASE (+)	YELLOW	At Rear Hatch Release Switch
TACHOMETER WIRE	BLUE	Single Wire Plug On Firewall Or At Distributor
BRAKE WIRE (+)	GREEN/WHITE	At Cruise Control Module In Driver's Kick Panel
HORN TRIGGER (-)	GRAY	Harness In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED/BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 2002 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLACK/RED	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/BLUE	Gray Harness Under Dash Above Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Gray Harness Under Dash Above Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BLUE	Green Harness Left Of The Steering Column
HEADLIGHTS (-)	BLUE/RED	Green Harness Left Of The Steering Column
DRIVER DOOR TRIGGER (-)	GREEN	Green Harness Left Of The Steering Column
PASSENGER DOORS TRIGGER (-)	LT.GREEN/RED	Green Harness Left Of The Steering Column
DOVE SUPERVISION	COMES ON WITH UNLOCK	
REAR HATCH TRIGGER (-)	GREEN/WHITE (Rear glass) and RED (Rear hatch)	Green Harness Left Of The Steering Column
HOOD TRIGGER (-)	YELLOW/RED	Green Harness Left Of The Steering Column
REAR HATCH RELEASE (-)	BLACK/YELLOW	Driver Kick Panel
TACHOMETER	BLUE	Small Connector Next To Battery
BRAKE WIRE (+)	WHITE/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BROWN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.

WIRING INFORMATION: 2003 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLACK/RED	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/BLUE	Gray Harness Under Dash Above Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Gray Harness Under Dash Above Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BLUE	Green Harness Left Of The Steering Column
HEADLIGHTS (-)	BLUE/RED	Green Harness Left Of The Steering Column
DRIVER DOOR TRIGGER (-)	GREEN	Green Harness Left Of The Steering Column
PASSENGER DOORS TRIGGER (-)	LT.GREEN/RED	Green Harness Left Of The Steering Column
DOVE SUPERVISION	COMES ON WITH UNLOCK	
REAR HATCH TRIGGER (-)	GREEN/WHITE (Rear glass) and RED (Rear hatch)	Green Harness Left Of The Steering Column
HOOD TRIGGER (-)	YELLOW/RED	Green Harness Left Of The Steering Column
REAR HATCH RELEASE (-)	BLACK/YELLOW	Driver Kick Panel
TACHOMETER	BLUE	Small Connector Next To Battery
BRAKE WIRE (+)	WHITE/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BROWN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.

WIRING INFORMATION: 2004 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLACK/RED	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/BLUE	Gray Harness Under Dash Above Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Gray Harness Under Dash Above Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BLUE	Green Harness Left Of The Steering Column
HEADLIGHTS (-)	BLUE/RED	Green Harness Left Of The Steering Column
DRIVER DOOR TRIGGER (-)	GREEN	Green Harness Left Of The Steering Column
PASSENGER DOORS TRIGGER (-)	LT.GREEN/RED	Green Harness Left Of The Steering Column
DOVE SUPERVISION	COMES ON WITH UNLOCK	
REAR HATCH TRIGGER (-)	GREEN/WHITE (Rear glass) and RED (Rear hatch)	Green Harness Left Of The Steering Column
HOOD TRIGGER (-)	YELLOW/RED	Green Harness Left Of The Steering Column
REAR HATCH RELEASE (-)	BLACK/YELLOW	Driver Kick Panel
TACHOMETER	BLUE	Small Connector Next To Battery
BRAKE WIRE (+)	WHITE/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BROWN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.

WIRING INFORMATION: 2005 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLACK/RED	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/BLUE	Gray Harness Under Dash Above Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Gray Harness Under Dash Above Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BLUE	Green Harness Left Of The Steering Column
HEADLIGHTS (-)	BLUE/RED	Green Harness Left Of The Steering Column
DRIVER DOOR TRIGGER (-)	GREEN	Green Harness Left Of The Steering Column
PASSENGER DOORS TRIGGER (-)	LT.GREEN/RED	Green Harness Left Of The Steering Column
DOME SUPERVISION	COMES ON WITH UNLOCK	
REAR HATCH TRIGGER (-)	GREEN/WHITE (Rear glass) and RED (Rear hatch)	Green Harness Left Of The Steering Column
HOOD TRIGGER (-)	YELLOW/RED	Green Harness Left Of The Steering Column
REAR HATCH RELEASE (-)	BLACK/YELLOW	Driver Kick Panel
TACHOMETER	BLUE	Small Connector Next To Battery
BRAKE WIRE (+)	WHITE/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BROWN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.

WIRING INFORMATION: 2006 Honda CRV

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLACK/RED	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/BLUE	Gray Harness Under Dash Above Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Gray Harness Under Dash Above Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BLUE	Green Harness Left Of The Steering Column
HEADLIGHTS (-)	BLUE/RED	Green Harness Left Of The Steering Column
DRIVER DOOR TRIGGER (-)	GREEN	Green Harness Left Of The Steering Column
PASSENGER DOORS TRIGGER (-)	LT.GREEN/RED	Green Harness Left Of The Steering Column
DOME SUPERVISION	COMES ON WITH UNLOCK	
REAR HATCH TRIGGER (-)	GREEN/WHITE (Rear glass) and RED (Rear hatch)	Green Harness Left Of The Steering Column
HOOD TRIGGER (-)	YELLOW/RED	Green Harness Left Of The Steering Column
REAR HATCH RELEASE (-)	BLACK/YELLOW	Driver Kick Panel
TACHOMETER	BLUE	Small Connector Next To Battery
BRAKE WIRE (+)	WHITE/BLACK	Plug At Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BROWN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.