

**Vehicle Wiring Information**  
for the  
**1987 Honda Civic**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	black/white		ignition harness
SECOND STARTER			
IGNITION	black/yellow		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	yellow		ignition harness
SECOND ACCESSORY	white/black		ignition harness
POWER LOCK	green/white	-	in driver door
POWER UNLOCK	green/red	-	in driver door
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	red/black		column or driver door sill
PARKING LIGHTS -			
HEADLIGHTS	red/blue		steering column
DOOR TRIGGER	green/red	-	driver door sill
DOME SUPERVISION			
TRUNK/HATCH PIN	green/black		driver door sill
HOOD PIN			
TRNK/HATCH RELEASE			
FACTRY ALARM ARM			
FACTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	blue		at the distributor
SPEED SENSE			
BRAKE WIRE	green/blue		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes: