

TRIPLE S *Customs*

INFINITI FX35 2003-2005 VEHICLE WIRING

WIRING INFORMATION: 2003 Infiniti FX35

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLUE/RED or RED	Ignition Harness
STARTER WIRE	BLUE	Ignition Harness
SECOND STARTER WIRE	PINK	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Module In Driver's Door
POWER DOOR UNLOCK (-)	ORANGE	At Module In Driver's Door
Test door lock wires while turning the key in the driver's door		
PARKING LIGHTS (+)	WHITE	In White Connector In Driver's Kick Panel
DRIVER DOOR TRIGGER WIRE (-)	WHITE	At Body Control Module In Driver's Kick Panel
PASSENGER FRONT DOOR TRIGGER WIRE (-)	BLACK	At Body Control Module In Driver's Kick Panel
DRIVER REAR DOOR TRIGGER WIRE (-)	PINK	At Body Control Module In Driver's Kick Panel
PASSENGER REAR DOOR TRIGGER WIRE (-)	PINK/BLUE	At Body Control Module IN Driver's Kick Panel
DOMELIGHT SUPERVISION (-)	PURPLE/WHITE	In Black Connector At Body Control Module
TRUNK TRIGGER (-)	BLUE	At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LIGHT GREEN	At Factory Hood Pin
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	Any wire that is NOT WHITE or BLACK	At Ignition Coil
BRAKE WIRE (+)	PINK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK or LIGHT/BLUE	At Steering Column
LEFT FRONT WINDOW UP	Extended triggers on the door lock wires will operate the power windows	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2004 Infiniti FX35

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLUE/RED or RED	Ignition Harness
STARTER WIRE	BLUE	Ignition Harness
SECOND STARTER WIRE	PINK	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Module In Driver's Door
POWER DOOR UNLOCK (-)	ORANGE	At Module In Driver's Door
Test door lock wires while turning the key in the driver's door		
PARKING LIGHTS (+)	WHITE	In White Connector In Driver's Kick Panel
DRIVER DOOR TRIGGER WIRE (-)	WHITE	At Body Control Module In Driver's Kick Panel
PASSENGER FRONT DOOR TRIGGER WIRE (-)	BLACK	At Body Control Module In Driver's Kick Panel
DRIVER REAR DOOR TRIGGER WIRE (-)	PINK	At Body Control Module In Driver's Kick Panel
PASSENGER REAR DOOR TRIGGER WIRE (-)	PINK/BLUE	At Body Control Module IN Driver's Kick Panel
DOMELIGHT SUPERVISION (-)	PURPLE/WHITE	In Black Connector At Body Control Module
TRUNK TRIGGER (-)	BLUE	At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LIGHT GREEN	At Factory Hood Pin
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	Any wire that is NOT WHITE or BLACK	At Ignition Coil
BRAKE WIRE (+)	PINK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK or LIGHT/BLUE	At Steering Column
LEFT FRONT WINDOW UP	Extended triggers on the door lock wires will operate the power windows	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 Infiniti FX35

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLUE/RED or RED	Ignition Harness
STARTER WIRE	BLUE	Ignition Harness
SECOND STARTER WIRE	PINK	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
ACCESSORY WIRE	WHITE	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Module In Driver's Door
POWER DOOR UNLOCK (-)	ORANGE	At Module In Driver's Door
Test door lock wires while turning the key in the driver's door		
PARKING LIGHTS (+)	WHITE	In White Connector In Driver's Kick Panel
DRIVER DOOR TRIGGER WIRE (-)	WHITE	At Body Control Module In Driver's Kick Panel
PASSENGER FRONT DOOR TRIGGER WIRE (-)	BLACK	At Body Control Module In Driver's Kick Panel
DRIVER REAR DOOR TRIGGER WIRE (-)	PINK	At Body Control Module In Driver's Kick Panel
PASSENGER REAR DOOR TRIGGER WIRE (-)	PINK/BLUE	At Body Control Module IN Driver's Kick Panel
DOMELIGHT SUPERVISION (-)	PURPLE/WHITE	In Black Connector At Body Control Module
TRUNK TRIGGER (-)	BLUE	At Body Control Module In Driver's Kick Panel
HOOD TRIGGER (-)	LIGHT GREEN	At Factory Hood Pin
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	Any wire that is NOT WHITE or BLACK	At Ignition Coil
BRAKE WIRE (+)	PINK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK or LIGHT/BLUE	At Steering Column
LEFT FRONT WINDOW UP	Extended triggers on the door lock wires will operate the power windows	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		