

TRIPLE S *Customs*

**INFINITI G20 1991-1996 1999-2002
VEHICLE WIRING**

WIRING INFORMATION: 1991 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	ORANGE/BLUE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Module Under Dash By Steering Column
TRUNK TRIGGER (-)	RED/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	Factory Anti-Theft Module Under Dash By Steering Column
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM (-)	LT. GREEN/RED	Factory Anti-Theft Module Under Dash By Steering Column
FACTORY ALARM DISARM (-)	GREEN/YELLOW	Factory Anti-Theft Module Under Dash By Steering Column
TACHOMETER WIRE	BLUE/BLACK	At Ignition Coil
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1992 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	ORANGE/BLUE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Module Under Dash By Steering Column
TRUNK TRIGGER (-)	RED/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	Factory Anti-Theft Module Under Dash By Steering Column
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM (-)	LT. GREEN/RED	Factory Anti-Theft Module Under Dash By Steering Column
FACTORY ALARM DISARM (-)	GREEN/YELLOW	Factory Anti-Theft Module Under Dash By Steering Column
TACHOMETER WIRE	BLUE/BLACK	At Ignition Coil
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1993 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE/BLACK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	ORANGE/BLUE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Module Under Dash By Steering Column
TRUNK TRIGGER (-)	RED/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	Factory Anti-Theft Module Under Dash By Steering Column
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	At Trunk Release Switch
FACTORY ALARM ARM (-)	LT. GREEN/RED	Factory Anti-Theft Module Under Dash By Steering Column
FACTORY ALARM DISARM (-)	GREEN/YELLOW	Factory Anti-Theft Module Under Dash By Steering Column
TACHOMETER WIRE	BLUE/BLACK	At Ignition Coil
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1994 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE/BLACK	Module In Passenger Kick Panel
POWER DOOR UNLOCK (-)	ORANGE/BLUE	Module In Passenger Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Module Under Dash By Steering Column
TRUNK TRIGGER (-)	RED/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	Factory Anti-Theft Module Under Dash By Steering Column
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	In Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM	Arms On Lock	
FACTORY ALARM DISARM (-)	GREEN/YELLOW	Factory Anti-Theft Module Under Dash By Steering Column
TACHOMETER WIRE	BLUE/BLACK	At Ignition Coil
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1995 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE/BLACK	Module In Passenger Kick Panel
POWER DOOR UNLOCK (-)	ORANGE/BLUE	Module In Passenger Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Module Under Dash By Steering Column
TRUNK TRIGGER (-)	RED/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	Factory Anti-Theft Module Under Dash By Steering Column
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	In Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM	Arms On Lock	
FACTORY ALARM DISARM (-)	GREEN/YELLOW	Factory Anti-Theft Module Under Dash By Steering Column
TACHOMETER WIRE	BLUE/BLACK	At Ignition Coil
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1996 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE/BLACK	Module In Passenger Kick Panel
POWER DOOR UNLOCK (-)	ORANGE/BLUE	Module In Passenger Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Factory Anti-Theft Module Under Dash By Steering Column
TRUNK TRIGGER (-)	RED/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	Factory Anti-Theft Module Under Dash By Steering Column
TRUNK RELEASE (+)	ORANGE OR LT. GREEN	In Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM	Arms On Lock	
FACTORY ALARM DISARM (-)	GREEN/YELLOW	Factory Anti-Theft Module Under Dash By Steering Column
TACHOMETER WIRE	BLUE/BLACK	At Ignition Coil
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLUE	Factory Anti-Theft Module Under Dash By Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1999 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	WHITE/GREEN	Ignition Harness
IGNITION WIRE	WHITE/RED	Ignition Harness
SECOND IGNITION WIRE	WHITE/PURPLE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW	At Module Under Dash Left Of Steering Column
POWER DOOR UNLOCK (-)	LT. GREEN/RED	At Module Under Dash Left Of Steering Column
Unlock requires a double pulse		
PARKING LIGHTS (+)	RED/BLUE	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	RED/WHITE	At Module Under Dash Left Of Steering Column
PASSENGER DOORS TRIGGER (-)	RED/BLUE	At Module Under Dash Left Of Steering Column
TRUNK TRIGGER (-)	RED	At Module Under Dash Left Of Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	At Module Under Dash Left Of Steering Column
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK	SINGLE PULSE TO UNLOCK WIRE WILL DISARM WITHOUT UNLOCKING	
TACHOMETER WIRE	BLUE OR BLUE/ORANGE	White 18-Pin Connector Located Just In Front Of The Shifter.
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2000 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	WHITE/GREEN	Ignition Harness
IGNITION WIRE	WHITE/RED	Ignition Harness
SECOND IGNITION WIRE	WHITE/PURPLE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW	At Module Under Dash Left Of Steering Column
POWER DOOR UNLOCK (-)	LT. GREEN/RED	At Module Under Dash Left Of Steering Column
Unlock requires a double pulse		
PARKING LIGHTS (+)	RED/BLUE	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	RED/WHITE	At Module Under Dash Left Of Steering Column
PASSENGER DOORS TRIGGER (-)	RED/BLUE	At Module Under Dash Left Of Steering Column
TRUNK TRIGGER (-)	RED	At Module Under Dash Left Of Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	At Module Under Dash Left Of Steering Column
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK	SINGLE PULSE TO UNLOCK WIRE WILL DISARM WITHOUT UNLOCKING	
TACHOMETER WIRE	BLUE OR BLUE/ORANGE	White 18-Pin Connector Located Just In Front Of The Shifter.
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2001 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	WHITE/GREEN	Ignition Harness
IGNITION WIRE	WHITE/RED	Ignition Harness
SECOND IGNITION WIRE	WHITE/PURPLE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW	At Module Under Dash Left Of Steering Column
POWER DOOR UNLOCK (-)	LT. GREEN/RED	At Module Under Dash Left Of Steering Column
Unlock requires a double pulse		
PARKING LIGHTS (+)	RED/BLUE	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	RED/WHITE	At Module Under Dash Left Of Steering Column
PASSENGER DOORS TRIGGER (-)	RED/BLUE	At Module Under Dash Left Of Steering Column
TRUNK TRIGGER (-)	RED	At Module Under Dash Left Of Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	At Module Under Dash Left Of Steering Column
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK	SINGLE PULSE TO UNLOCK WIRE WILL DISARM WITHOUT UNLOCKING	
TACHOMETER WIRE	BLUE OR BLUE/ORANGE	White 18-Pin Connector Located Just In Front Of The Shifter.
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2002 Infiniti G20

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	WHITE/GREEN	Ignition Harness
IGNITION WIRE	WHITE/RED	Ignition Harness
SECOND IGNITION WIRE	WHITE/PURPLE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW	At Module Under Dash Left Of Steering Column
POWER DOOR UNLOCK (-)	LT. GREEN/RED	At Module Under Dash Left Of Steering Column
Unlock requires a double pulse		
PARKING LIGHTS (+)	RED/BLUE	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	RED/WHITE	At Module Under Dash Left Of Steering Column
PASSENGER DOORS TRIGGER (-)	RED/BLUE	At Module Under Dash Left Of Steering Column
TRUNK TRIGGER (-)	RED	At Module Under Dash Left Of Steering Column
HOOD TRIGGER (-)	YELLOW/BLACK	At Module Under Dash Left Of Steering Column
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK	SINGLE PULSE TO UNLOCK WIRE WILL DISARM WITHOUT UNLOCKING	
TACHOMETER WIRE	BLUE OR BLUE/ORANGE	White 18-Pin Connector Located Just In Front Of The Shifter.
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		