

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/RED (smaller)	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
SECOND ACCESSORY	WHITE/BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	ORANGE/BLACK	At Module In Driver's Door
<b>Notes:</b> Test door lock wires by using the key in the driver's door. Unlock requires a double pulse		
POWER DOOR UNLOCK (-)	ORANGE/BLUE	At Module In Driver's Door
<b>Notes:</b> Test door lock wires by using the key in the driver's door. Unlock requires a double pulse		
DRIVER DOOR TRIGGER (-)	LT.GREEN	Module Under Dash Right Of Steering Column
PASSENGER DOOR TRIGGER (-)	RED/BLUE	Module Under Dash Right Of Steering Column
REAR DOORS TRIGGER (-)	RED/WHITE	Module Under Dash Right Of Steering Column
TRUNK TRIGGER (-)	PURPLE/YELLOW	Module Under Dash Right Of Steering Column
HOOD TRIGGER (-)	YELLOW/RED	Module Under Dash Right Of Steering Column
TRUNK RELEASE (-)	BLUE	Module Under Dash Right Of Steering Column
<b>Notes:</b> A relay must be used to trigger the trunk release wire. Refer to TechDoc 3970		
FACTORY ALARM ARM	Arms With Lock	
FACTORY ALARM DISARM	Disarms With Unlock	
TACHOMETER	WHITE/GREEN	At Engine Control Module In Center Console
<b>Notes:</b> Remove The Small Panel Just To The Front Of The Center Console On The Passenger Side To Access <b>**DO NOT UNPLUG THE ENGINE CONTROL MODULE**</b>		
BRAKE WIRE (+)	RED/GREEN	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column From Steering Wheel
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN	At Right Front Window Switch
LEFT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	CHASSIS		
ILLUMINATION (+)	RED/WHITE	Radio Harness	
POWER ANTENNA (+)	GREEN/WHITE	Radio Harness	
AMP TURN ON (+)	GREEN/WHITE	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7609G, SCOSCHE II1653B		METRA 70-7551, SCOSCHE NN03B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/RED (smaller)	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
SECOND ACCESSORY	WHITE/BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	ORANGE/BLACK	At Module In Driver's Door
<b>Notes:</b> Test door lock wires by using the key in the driver's door. Unlock requires a double pulse		
POWER DOOR UNLOCK (-)	ORANGE/BLUE	At Module In Driver's Door
<b>Notes:</b> Test door lock wires by using the key in the driver's door. Unlock requires a double pulse		
DRIVER DOOR TRIGGER (-)	LT.GREEN	Module Under Dash Right Of Steering Column
PASSENGER DOOR TRIGGER (-)	RED/BLUE	Module Under Dash Right Of Steering Column
REAR DOORS TRIGGER (-)	RED/WHITE	Module Under Dash Right Of Steering Column
TRUNK TRIGGER (-)	PURPLE/YELLOW	Module Under Dash Right Of Steering Column
HOOD TRIGGER (-)	YELLOW/RED	Module Under Dash Right Of Steering Column
TRUNK RELEASE (-)	BLUE	Module Under Dash Right Of Steering Column
<b>Notes:</b> A relay must be used to trigger the trunk release wire. Refer to TechDoc 3970		
FACTORY ALARM ARM	Arms With Lock	
FACTORY ALARM DISARM	Disarms With Unlock	
TACHOMETER	WHITE/GREEN	At Engine Control Module In Center Console
<b>Notes:</b> Remove The Small Panel Just To The Front Of The Center Console On The Passenger Side To Access <b>**DO NOT UNPLUG THE ENGINE CONTROL MODULE**</b>		
BRAKE WIRE (+)	RED/GREEN	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column From Steering Wheel
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN	At Right Front Window Switch
LEFT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	CHASSIS		
ILLUMINATION (+)	RED/WHITE	Radio Harness	
POWER ANTENNA (+)	GREEN/WHITE	Radio Harness	
AMP TURN ON (+)	GREEN/WHITE	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7609G, SCOSCHE II1653B		METRA 70-7551, SCOSCHE NN03B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/RED (smaller)	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/BLUE	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
SECOND ACCESSORY	WHITE/BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Harness In Driver's Kick Panel
POWER DOOR LOCK (-)	ORANGE/BLACK	At Module In Driver's Door
<b>Notes:</b> Test door lock wires by using the key in the driver's door. Unlock requires a double pulse		
POWER DOOR UNLOCK (-)	ORANGE/BLUE	At Module In Driver's Door
<b>Notes:</b> Test door lock wires by using the key in the driver's door. Unlock requires a double pulse		
DRIVER DOOR TRIGGER (-)	LT.GREEN	Module Under Dash Right Of Steering Column
PASSENGER DOOR TRIGGER (-)	RED/BLUE	Module Under Dash Right Of Steering Column
REAR DOORS TRIGGER (-)	RED/WHITE	Module Under Dash Right Of Steering Column
TRUNK TRIGGER (-)	PURPLE/YELLOW	Module Under Dash Right Of Steering Column
HOOD TRIGGER (-)	YELLOW/RED	Module Under Dash Right Of Steering Column
TRUNK RELEASE (-)	BLUE	Module Under Dash Right Of Steering Column
<b>Notes:</b> A relay must be used to trigger the trunk release wire. Refer to TechDoc 3970		
FACTORY ALARM ARM	Arms With Lock	
FACTORY ALARM DISARM	Disarms With Unlock	
TACHOMETER	WHITE/GREEN	At Engine Control Module In Center Console
<b>Notes:</b> Remove The Small Panel Just To The Front Of The Center Console On The Passenger Side To Access <b>**DO NOT UNPLUG THE ENGINE CONTROL MODULE**</b>		
BRAKE WIRE (+)	RED/GREEN	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column From Steering Wheel
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN	At Right Front Window Switch
LEFT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	CHASSIS		
ILLUMINATION (+)	RED/WHITE	Radio Harness	
POWER ANTENNA (+)	GREEN/WHITE	Radio Harness	
AMP TURN ON (+)	GREEN/WHITE	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"	Under Rear Deck	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7609G, SCOSCHE II1653B	METRA 70-7551, SCOSCHE NN03B	METRA 40-NI10, SCOSCHE NDAB

Please verify all part numbers before ordering.