

TRIPLE S *Customs*

INFINITI M45 2003-2004 VEHICLE WIRING

WIRING INFORMATION 2003 Infiniti M45

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	At Body Control Module In Driver's Kick Panel
POWER DOOR LOCK (-)	GRAY	At Module In Driver's Door
POWER DOOR UNLOCK (-)	PURPLE/WHITE	At Module In Driver's Door
Test door lock wires by using the key in the driver's door. Unlock requires a double pulse		
DRIVER DOOR TRIGGER (-)	RED/YELLOW	At Body Control Module In Driver's Kick
PASSENGER DOOR TRIGGER (-)	LIGHT GREEN	At Body Control Module In Driver's Kick
DRIVER REAR DOOR TRIGGER (-)	WHITE	At Body Control Module In Driver's Kick
PASSENGER REAR DOOR TRIGGER (-)	WHITE/BLUE	At Body Control Module In Driver's Kick
TRUNK TRIGGER (-)	PINK	At Body Control Module In Driver's Kick
HOOD TRIGGER (-)	LT.GREEN/BLACK	At Body Control Module In Driver's Kick
TRUNK RELEASE (-)	YELLOW/BLACK	At Body Control Module In Driver's Kick
FUEL DOOR RELEASE (-)	YELLOW/BLACK	Harness In Passenger Kick Panel Running Towards Rear Of Vehicle
A relay must be used to trigger the fuel door release		
FACTORY ALARM ARM	Arms With Lock	
FACTORY ALARM DISARM	Disarms With Unlock	
TACHOMETER	WHITE/GREEN	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	RED/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column From Steering Wheel
LEFT FRONT WINDOW UP	Extended triggers on the lock wires will roll the windows up or down.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2004 Infiniti M45

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	At Body Control Module In Driver's Kick Panel
POWER DOOR LOCK (-)	GRAY	At Module In Driver's Door
POWER DOOR UNLOCK (-)	PURPLE/WHITE	At Module In Driver's Door
Test door lock wires by using the key in the driver's door. Unlock requires a double pulse		
DRIVER DOOR TRIGGER (-)	RED/YELLOW	At Body Control Module In Driver's Kick
PASSENGER DOOR TRIGGER (-)	LIGHT GREEN	At Body Control Module In Driver's Kick
DRIVER REAR DOOR TRIGGER (-)	WHITE	At Body Control Module In Driver's Kick
PASSENGER REAR DOOR TRIGGER (-)	WHITE/BLUE	At Body Control Module In Driver's Kick
TRUNK TRIGGER (-)	PINK	At Body Control Module In Driver's Kick
HOOD TRIGGER (-)	LT.GREEN/BLACK	At Body Control Module In Driver's Kick
TRUNK RELEASE (-)	YELLOW/BLACK	At Body Control Module In Driver's Kick
FUEL DOOR RELEASE (-)	YELLOW/BLACK	Harness In Passenger Kick Panel Running Towards Rear Of Vehicle
A relay must be used to trigger the fuel door release		
FACTORY ALARM ARM	Arms With Lock	
FACTORY ALARM DISARM	Disarms With Unlock	
TACHOMETER	WHITE/GREEN	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	RED/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column From Steering Wheel
LEFT FRONT WINDOW UP	Extended triggers on the lock wires will roll the windows up or down.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
This vehicle is equipped with a factory Immobilizer. This must be bypassed when installing a remote start system.		