

TRIPLE S *Customs*

INFINITI QX4 1997-2003 VEHICLE WIRING

WIRING INFORMATION: 1997 Infiniti QX4

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	RED/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/RED	At Keyless Entry Module Under Driver's Side Dash
POWER DOORUNLOCK (-)	BROWN	At Keyless Entry Module Under Driver's Side Dash
PARKING LIGHTS (+)	PINK/BLUE	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Driver's Kick Panel
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM (-)	YELLOW	At Keyless Entry Module Under Driver's Side Dash
FACTORY ALARM DISARM (-)	LIGHT GREEN	At Keyless Entry Module Under Driver's Side Dash
TACHOMETER WIRE	BLUE	At Distributor
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1998 Infiniti QX4

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	RED/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/RED	At Keyless Entry Module Under Driver's Side Dash
POWER DOORUNLOCK (-)	BROWN	At Keyless Entry Module Under Driver's Side Dash
PARKING LIGHTS (+)	PINK/BLUE	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Driver's Kick Panel
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM (-)	YELLOW	At Keyless Entry Module Under Driver's Side Dash
FACTORY ALARM DISARM (-)	LIGHT GREEN	At Keyless Entry Module Under Driver's Side Dash
TACHOMETER WIRE	BLUE	At Distributor
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1999 Infiniti QX4

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	RED/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/RED	At Keyless Entry Module Under Driver's Side Dash
POWER DOORUNLOCK (-)	BROWN	At Keyless Entry Module Under Driver's Side Dash
PARKING LIGHTS (+)	PINK/BLUE	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Driver's Kick Panel
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM (-)	YELLOW	At Keyless Entry Module Under Driver's Side Dash
FACTORY ALARM DISARM (-)	LIGHT GREEN	At Keyless Entry Module Under Driver's Side Dash
TACHOMETER WIRE	BLUE	At Distributor
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door
Some models are equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2000 Infiniti QX4

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/PURPLE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	RED/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/RED	At Keyless Entry Module Under Driver's Side Dash
POWER DOORUNLOCK (-)	BROWN	At Keyless Entry Module Under Driver's Side Dash
PARKING LIGHTS (+)	PINK/BLUE	Harness At Steering Column
DOOR TRIGGER (-)	RED/BLACK	Harness In Driver's Kick Panel
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM (-)	YELLOW	At Keyless Entry Module Under Driver's Side Dash
FACTORY ALARM DISARM (-)	LIGHT GREEN	At Keyless Entry Module Under Driver's Side Dash
TACHOMETER WIRE	BLUE	At Distributor
BRAKE WIRE (+)	GREEN/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	LT GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door
Some models are equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2001 Infiniti QX4

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	RED/BLACK	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	YELLOW	At Module Between Steering Column And Fuse Box
POWER DOOR UNLOCK (-) **Requires a double pulse**	LT. GREEN	At Module Between Steering Column And Fuse Box
PARKING LIGHTS (+)	PINK/BLUE	Harness At Steering Column
DOOR TRIGGER (-)	GREEN/RED (Driver door) YELLOW (Front pass. door) RED/BLUE (Rear doors)	At Module Between Steering Column And Fuse Box
REAR HATCH TRIGGER (-)	BLUE/WHITE	At Module Between Steering Column And Fuse Box
HOOD TRIGGER (-)	YELLOW/BLACK	At Module Between Steering Column And Fuse Box
FACTRY ALARM ARM	Arms with lock	
FACTRY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Single pulse to unlock wire will disarm factory security without unlocking doors	
TACHOMETER WIRE	WHITE/GREEN	Engine Control Module Under Dash Right Of Steering Column- Do Not Unplug
BRAKE WIRE (+)	GREEN/YELLOW	Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLACK	At Module Between Steering Column And Fuse Box
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door
Some models are equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2002 Infiniti QX4

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	RED/BLACK	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	YELLOW	At Module Between Steering Column And Fuse Box
POWER DOOR UNLOCK (-) **Requires a double pulse**	LT. GREEN	At Module Between Steering Column And Fuse Box
PARKING LIGHTS (+)	PINK/BLUE	Harness At Steering Column
DOOR TRIGGER (-)	GREEN/RED (Driver door) YELLOW (Front pass. door) RED/BLUE (Rear doors)	At Module Between Steering Column And Fuse Box
DOVE SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	BLUE/WHITE	At Module Between Steering Column And Fuse Box
HOOD TRIGGER (-)	YELLOW/BLACK	At Module Between Steering Column And Fuse Box
FACTRY ALARM ARM	Arms with lock	
FACTRY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Single pulse to unlock wire will disarm factory security without unlocking doors	
TACHOMETER WIRE	WHITE/GREEN	Engine Control Module Under Dash Right Of Steering Column- Do Not Unplug
BRAKE WIRE (+)	GREEN/YELLOW	Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLACK	At Module Between Steering Column And Fuse Box
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door
Some models are equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2003 Infiniti QX4

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	RED/BLACK	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	YELLOW	At Module Between Steering Column And Fuse Box
POWER DOOR UNLOCK (-) **Requires a double pulse**	LT. GREEN	At Module Between Steering Column And Fuse Box
PARKING LIGHTS (+)	PINK/BLUE	Harness At Steering Column
DOOR TRIGGER (-)	GREEN/RED (Driver door) YELLOW (Front pass. door) RED/BLUE (Rear doors)	At Module Between Steering Column And Fuse Box
DOVE SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	BLUE/WHITE	At Module Between Steering Column And Fuse Box
HOOD TRIGGER (-)	YELLOW/BLACK	At Module Between Steering Column And Fuse Box
FACTRY ALARM ARM	Arms with lock	
FACTRY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Single pulse to unlock wire will disarm factory security without unlocking doors	
TACHOMETER WIRE	WHITE/GREEN	Engine Control Module Under Dash Right Of Steering Column- Do Not Unplug
BRAKE WIRE (+)	GREEN/YELLOW	Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLACK	At Module Between Steering Column And Fuse Box
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door
Some models are equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		