

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE/BLUE or BLACK/WHITE	Ignition harness
SECOND STARTER WIRE	GREEN or BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/RED	At Dimmer Switch
DOOR TRIGGER/ DOMELIGHT SUPER	RED/GREEN or BLACK	Behind Driver Dash Speaker
TRUNK TRIGGER	Tied In With Doors	
TACHOMETER WIRE	BLUE or GRAY	At Ignition Coil
BRAKE WIRE (+)	RED	Harness At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3400, SCOSCHE GO1565B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE/BLUE or BLACK/WHITE	Ignition harness
SECOND STARTER WIRE	GREEN or BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/RED	At Dimmer Switch
DOOR TRIGGER/ DOMELIGHT SUPER	RED/GREEN or BLACK	Behind Driver Dash Speaker
TRUNK TRIGGER	Tied In With Doors	
TACHOMETER WIRE	BLUE or GRAY	At Ignition Coil
BRAKE WIRE (+)	RED	Harness At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3400, SCOSCHE GO1565B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE/BLUE or BLACK/WHITE	Ignition harness
SECOND STARTER WIRE	GREEN or BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/RED	At Dimmer Switch
DOOR TRIGGER/ DOMELIGHT SUPER	RED/GREEN or BLACK	Behind Driver Dash Speaker
TRUNK TRIGGER	Tied In With Doors	
TACHOMETER WIRE	BLUE or GRAY	At Ignition Coil
BRAKE WIRE (+)	RED	Harness At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3400, SCOSCHE GO1565B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE/BLUE or BLACK/WHITE	Ignition harness
SECOND STARTER WIRE	GREEN or BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/RED	At Dimmer Switch
DOOR TRIGGER/ DOMELIGHT SUPER	RED/GREEN or BLACK	Behind Driver Dash Speaker
TRUNK TRIGGER	Tied In With Doors	
TACHOMETER WIRE	BLUE or GRAY	At Ignition Coil
BRAKE WIRE (+)	RED	Harness At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3400, SCOSCHE GO1565B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE/BLUE or BLACK/WHITE	Ignition harness
SECOND STARTER WIRE	GREEN or BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/RED	At Dimmer Switch
DOOR TRIGGER/ DOMELIGHT SUPER	RED/GREEN or BLACK	Behind Driver Dash Speaker
TRUNK TRIGGER	Tied In With Doors	
TACHOMETER WIRE	BLUE or GRAY	At Ignition Coil
BRAKE WIRE (+)	RED	Harness At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3400, SCOSCHE GO1565B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE/BLUE or BLACK/WHITE	Ignition harness
SECOND STARTER WIRE	GREEN or BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/RED	At Dimmer Switch
DOOR TRIGGER/ DOMELIGHT SUPER	RED/GREEN or BLACK	Behind Driver Dash Speaker
TRUNK TRIGGER	Tied In With Doors	
TACHOMETER WIRE	BLUE or GRAY	At Ignition Coil
BRAKE WIRE (+)	RED	Harness At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3400, SCOSCHE GO1565B		METRA 70-1782, SCOSCHE IM01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOORLOCK (-)	LT. GREEN/RED	Large Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/BLUE	Large Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Black Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/GREEN	White Harness In Driver's Kick Panel
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOOR TRIGGER	
HOOD TRIGGER (-)	GREEN/RED	At OEM Keyless Module To The Right Of The Glove Box
REAR HATCH RELEASE (-)	LT. GREEN	At OEM Keyless Module To The Right Of The Glove Box
FACTORY ALARM ARM (-)	PURPLE	White Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	YELLOW/BLUE	White Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK/RED	Harness In Driver's Kick Panel
BRAKE WIRE (+)	RED	Plug At Brake Pedal Switch
HORN TRIGGER (-)	GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BROWN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/RED	In Right Front Door
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE IM2120B		METRA 70-7712, SCOSCHE IU02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOORLOCK (-)	LT. GREEN/RED	Large Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/BLUE	Large Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Black Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/GREEN	White Harness In Driver's Kick Panel
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOOR TRIGGER	
HOOD TRIGGER (-)	GREEN/RED	At OEM Keyless Module To The Right Of The Glove Box
REAR HATCH RELEASE (-)	LT. GREEN	At OEM Keyless Module To The Right Of The Glove Box
FACTORY ALARM ARM (-)	PURPLE	White Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	YELLOW/BLUE	White Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK/RED	Harness In Driver's Kick Panel
BRAKE WIRE (+)	RED	Plug At Brake Pedal Switch
HORN TRIGGER (-)	GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BROWN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/RED	In Right Front Door
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE IM2120B		METRA 70-7712, SCOSCHE IU02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE, WHITE/BLACK	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOORLOCK (-)	LT. GREEN/RED	Large Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/BLUE	Large Harness In Driver's Kick Panel
PARKING LIGHTS (+)	GREEN/RED	Black Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/GREEN	White Harness In Driver's Kick Panel
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOOR TRIGGER	
HOOD TRIGGER (-)	GREEN/RED	At OEM Keyless Module To The Right Of The Glove Box
REAR HATCH RELEASE (-)	LT. GREEN	At OEM Keyless Module To The Right Of The Glove Box
FACTORY ALARM ARM (-)	PURPLE	White Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	YELLOW/BLUE	White Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK/RED	Harness In Driver's Kick Panel
BRAKE WIRE (+)	RED	Plug At Brake Pedal Switch
HORN TRIGGER (-)	GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BROWN/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BROWN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	In Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN/RED	In Right Front Door
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/BLUE	Radio Harness	
RADIO SWITCHED	YELLOW/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE IM2120B		METRA 70-7712, SCOSCHE IU02B	Not required
Please verify all part numbers before ordering.			