

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLUE/RED	Ignition Harness
<b>Notes:</b> Must energize second ignition wire to prevent factory alarm from triggering.		
12V ACCESSORY WIRE	BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	Behind Dimmer Switch
DOOR TRIGGER (-)	RED/YELLOW	At Module High In Driver's Kick Panel
TRUNK TRIGGER (-)	BLUE	At Light In Trunk
FACTORY ALARM DISARM (-)	GREEN (Key sense wire)	Ignition Harness
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	GRAY/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN ORANGE	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	BLUE/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	LIGHT GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2060B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLUE/RED	Ignition Harness
<b>Notes:</b> Must energize second ignition wire to prevent factory alarm from triggering.		
12V ACCESSORY WIRE	BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	Behind Dimmer Switch
DOOR TRIGGER (-)	RED/YELLOW	At Module High In Driver's Kick Panel
TRUNK TRIGGER (-)	BLUE	At Light In Trunk
FACTORY ALARM DISARM (-)	GREEN (Key sense wire)	Ignition Harness
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	GRAY/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN ORANGE	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	BLUE/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	LIGHT GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2060B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLUE/RED	Ignition Harness
<b>Notes:</b> Must energize second ignition wire to prevent factory alarm from triggering.		
12V ACCESSORY WIRE	BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	Behind Dimmer Switch
DOOR TRIGGER (-)	RED/YELLOW	At Module High In Driver's Kick Panel
TRUNK TRIGGER (-)	BLUE	At Light In Trunk
FACTORY ALARM DISARM (-)	GREEN (Key sense wire)	Ignition Harness
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	GRAY/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN ORANGE	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	BLUE/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	LIGHT GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2060B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLUE/RED	Ignition Harness
<b>Notes:</b> Must energize second ignition wire to prevent factory alarm from triggering.		
12V ACCESSORY WIRE	BLACK/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	Behind Dimmer Switch
DOOR TRIGGER (-)	RED/YELLOW	At Module High In Driver's Kick Panel
TRUNK TRIGGER (-)	BLUE	At Light In Trunk
FACTORY ALARM DISARM (-)	GREEN (Key sense wire)	Ignition Harness
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	GRAY/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN ORANGE	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	BLUE/WHITE	In Driver's Door
RIGHT REAR WINDOW UP	RED/WHITE	In Driver's Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	LIGHT GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2060B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK	Ignition Harness
12V IGNITION WIRE	WHITE/BLUE	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	BLUE/WHITE	Behind Dimmer Switch
DOOR TRIGGER (-)	LT.GREEN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/LT.GREEN	At Light In Trunk
TACHOMETER WIRE	YELLOW	At Test Connector On Driver's Strut Tower
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/RED	Harness Coming From Steering Wheel At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	LIGHT GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5x7"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHEKA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK	Ignition Harness
12V IGNITION WIRE	WHITE/BLUE	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	BLUE/WHITE	Behind Dimmer Switch
DOOR TRIGGER (-)	LT.GREEN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/LT.GREEN	At Light In Trunk
TACHOMETER WIRE	YELLOW	At Test Connector On Driver's Strut Tower
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/RED	Harness Coming From Steering Wheel At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	LIGHT GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHEKA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK	Ignition Harness
12V IGNITION WIRE	WHITE/BLUE	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	BLUE/WHITE	Behind Dimmer Switch
DOOR TRIGGER (-)	LT.GREEN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/LT.GREEN	At Light In Trunk
TACHOMETER WIRE	YELLOW	At Test Connector On Driver's Strut Tower
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/RED	Harness Coming From Steering Wheel At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	LIGHT GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHEKA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK	Ignition Harness
12V IGNITION WIRE	WHITE/BLUE	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
12V ACCESSORY WIRE	GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	BLUE/WHITE	Behind Dimmer Switch
DOOR TRIGGER (-)	LT.GREEN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/LT.GREEN	At Light In Trunk
TACHOMETER WIRE	YELLOW	At Test Connector On Driver's Strut Tower
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/RED	Harness Coming From Steering Wheel At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	LIGHT GREEN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHEKA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			