

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW or WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED or BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	BLACK/RED or BLUE	Ignition Harness
STARTER WIRE	BLACK/WHITE or WHITE/RED	Ignition Harness
PARKING LIGHTS (+)	BLUE/YELLOW	Behind Dimmer Switch
DOOR TRIGGER (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/YELLOW	At Rear Dome Light
HOOD TRIGGER (-)	BLUE/WHITE	At Factory Hood Pin
FACTORY ALARM ARM (-)	RED/GREEN	In Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (-)	WHITE/RED	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	YELLOW/WHITE	At Test Connector On Driver's Rear Of Engine Bay
BRAKE WIRE (+)	ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/BLACK	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	In Driver's Door
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/BLACK	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/RED	In Driver's Door
RIGHT REAR WINDOW DOWN	BLUE/GREEN	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GOLD	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE or BLACK	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW or WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED or BLACK/WHITE	Ignition Harness
12V ACCESSORY WIRE	BLACK/RED or BLUE	Ignition Harness
STARTER WIRE	BLACK/WHITE or WHITE/RED	Ignition Harness
PARKING LIGHTS (+)	BLUE/YELLOW	Behind Dimmer Switch
DOOR TRIGGER (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/YELLOW	At Rear Dome Light
HOOD TRIGGER (-)	BLUE/WHITE	At Factory Hood Pin
FACTORY ALARM ARM (-)	RED/GREEN	In Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (-)	WHITE/RED	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	YELLOW/WHITE	At Test Connector On Driver's Rear Of Engine Bay
BRAKE WIRE (+)	ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/BLACK	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	In Driver's Door
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/BLACK	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/RED	In Driver's Door
RIGHT REAR WINDOW DOWN	BLUE/GREEN	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GOLD	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
THIRD IGNITION WIRE	LT.GREEN/BLACK or GREEN (key sense wire)	Ignition Harness
Notes: Key sense wire must be energized as a second ignition wire to disarm the factory security without unlocking the doors when remote starting the vehicle.		
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	WHITE/RED	In Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	RED/GREEN	In Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BLUE/YELLOW	Behind Dimmer Switch
DOOR TRIGGER (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/YELLOW	At Rear Dome Light
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	YELLOW/WHITE	At Test Connector On Driver's Rear Of Engine Bay
BRAKE WIRE (+)	ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/BLACK	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	In Driver's Door
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/BLACK	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/RED	In Driver's Door
RIGHT REAR WINDOW DOWN	BLUE/GREEN	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	BLACK/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
THIRD IGNITION WIRE	LT.GREEN/BLACK or GREEN (key sense wire)	Ignition Harness
Notes: Key sense wire must be energized as a second ignition wire to disarm the factory security without unlocking the doors when remote starting the vehicle.		
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	WHITE/RED	In Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	RED/GREEN	In Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BLUE/YELLOW	Behind Dimmer Switch
DOOR TRIGGER (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/YELLOW	At Rear Dome Light
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	YELLOW/WHITE	At Test Connector On Driver's Rear Of Engine Bay
BRAKE WIRE (+)	ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/BLACK	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	In Driver's Door
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/BLACK	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/RED	In Driver's Door
RIGHT REAR WINDOW DOWN	BLUE/GREEN	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	BLACK/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
THIRD IGNITION WIRE	LT.GREEN/BLACK or GREEN (key sense wire)	Ignition Harness
Notes: Key sense wire must be energized as a second ignition wire to disarm the factory security without unlocking the doors when remote starting the vehicle.		
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	WHITE/RED	In Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	RED/GREEN	In Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BLUE/YELLOW	Behind Dimmer Switch
DOOR TRIGGER (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/YELLOW	At Rear Dome Light
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	YELLOW/WHITE	At Test Connector On Driver's Rear Of Engine Bay
BRAKE WIRE (+)	ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/BLACK	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	In Driver's Door
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/BLACK	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/RED	In Driver's Door
RIGHT REAR WINDOW DOWN	BLUE/GREEN	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	BLACK/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
THIRD IGNITION WIRE	LT.GREEN/BLACK or GREEN (key sense wire)	Ignition Harness
Notes: Key sense wire must be energized as a second ignition wire to disarm the factory security without unlocking the doors when remote starting the vehicle.		
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	WHITE/RED	In Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	RED/GREEN	In Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BLUE/YELLOW	Behind Dimmer Switch
DOOR TRIGGER (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/YELLOW	At Rear Dome Light
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	YELLOW/WHITE	At Test Connector On Driver's Rear Of Engine Bay
BRAKE WIRE (+)	ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/BLACK	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	In Driver's Door
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/BLACK	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/RED	In Driver's Door
RIGHT REAR WINDOW DOWN	BLUE/GREEN	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	BLACK/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
THIRD IGNITION WIRE	LT.GREEN/BLACK or GREEN (key sense wire)	Ignition Harness
Notes: Key sense wire must be energized as a second ignition wire to disarm the factory security without unlocking the doors when remote starting the vehicle.		
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (-)	WHITE/RED	In Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	RED/GREEN	In Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BLUE/YELLOW	Behind Dimmer Switch
DOOR TRIGGER (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/YELLOW	At Rear Dome Light
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	YELLOW/WHITE	At Test Connector On Driver's Rear Of Engine Bay
BRAKE WIRE (+)	ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	WHITE/BLACK	Harness Coming From Steering Wheel At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	In Driver's Door
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	In Driver's Door
LEFT REAR WINDOW UP	RED/BLUE	In Driver's Door
LEFT REAR WINDOW DOWN	RED/BLACK	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/RED	In Driver's Door
RIGHT REAR WINDOW DOWN	BLUE/GREEN	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	BLACK/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	BLUE/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-1003, SCOSCHE KA2065B		METRA 70-1003, SCOSCHE KA01B	Not required
Please verify all part numbers before ordering.			