

# **TRIPLE S** *Customs*

## **LAND ROVER FREELANDER 2002-2005 VEHICLE WIRING**

WIRING INFORMATION: 2002 LAND ROVER FREELANDER

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN and BROWN/RED	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	GREEN	Ignition Harness
SECOND IGNITION WIRE	BROWN/WHITE	Ignition Harness
ACCESSORY WIRE	GRAY/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	PURPLE/GRAY	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	At Module Attached To Fuse Box
POWER DOOR UNLOCK (-)	BLACK/PINK	At Module Attached To Fuse Box
PARKING LIGHTS (+)	RED/WHITE or RED	At Headlight Switch
DOOR TRIGGER (-)	PURPLE/GRAY & PURPLE/WHITE	At Module Attached To Fuse Box
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	BLACK/ORANGE	At Module Attached To Fuse Box
HOOD TRIGGER (-)	RED/PURPLE	At Module Attached To Fuse Box
REAR HATCH RELEASE (-)	ORANGE/BROWN	At Module Attached To Fuse Box
FACTORY ALARM ARM (-)	BLACK/PINK	At Module Attached To Fuse Box
FACTORY ALARM DISARM (-)	BLACK/RED	At Module Attached To Fuse Box
TACHOMETER WIRE	NOT BLACK or BROWN/PINK	Ignition Coil
BRAKE WIRE (+)	GREEN/PINK	At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/YELLOW	At Module Attached To Fuse Box
LEFT FRONT WINDOW UP	ORANGE/RED	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/BLUE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	ORANGE/RED	At Motor In Right Front Door
RIGHT FRONT WINDOW DOWN	ORANGE/BLUE	At Motor In Right Front Door
LEFT REAR WINDOW UP	RED	At Motor In Left Rear Door
LEFT REAR WINDOW DOWN	BLUE	At Motor In Left Rear Door
RIGHT REAR WINDOW UP	RED	At Motor In Right Rear Door
RIGHT REAR WINDOW DOWN	BLUE	At Motor In Right Rear Door
This vehicle has a factory Immobilizer system. This needs to be bypassed when installing a remote start system.		

WIRING INFORMATION: 2003 LAND ROVER FREELANDER

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN and BROWN/RED	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	GREEN	Ignition Harness
SECOND IGNITION WIRE	BROWN/WHITE	Ignition Harness
ACCESSORY WIRE	GRAY/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	PURPLE/GRAY	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	At Module Attached To Fuse Box
POWER DOOR UNLOCK (-)	BLACK/PINK	At Module Attached To Fuse Box
PARKING LIGHTS (+)	RED/WHITE or RED	At Headlight Switch
DOOR TRIGGER (-)	PURPLE/GRAY & PURPLE/WHITE	At Module Attached To Fuse Box
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	BLACK/ORANGE	At Module Attached To Fuse Box
HOOD TRIGGER (-)	RED/PURPLE	At Module Attached To Fuse Box
REAR HATCH RELEASE (-)	ORANGE/BROWN	At Module Attached To Fuse Box
FACTORY ALARM ARM (-)	BLACK/PINK	At Module Attached To Fuse Box
FACTORY ALARM DISARM (-)	BLACK/RED	At Module Attached To Fuse Box
TACHOMETER WIRE	NOT BLACK or BROWN/PINK	Ignition Coil
BRAKE WIRE (+)	GREEN/PINK	At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/YELLOW	At Module Attached To Fuse Box
LEFT FRONT WINDOW UP	ORANGE/RED	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/BLUE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	ORANGE/RED	At Motor In Right Front Door
RIGHT FRONT WINDOW DOWN	ORANGE/BLUE	At Motor In Right Front Door
LEFT REAR WINDOW UP	RED	At Motor In Left Rear Door
LEFT REAR WINDOW DOWN	BLUE	At Motor In Left Rear Door
RIGHT REAR WINDOW UP	RED	At Motor In Right Rear Door
RIGHT REAR WINDOW DOWN	BLUE	At Motor In Right Rear Door
This vehicle has a factory Immobilizer system. This needs to be bypassed when installing a remote start system.		

WIRING INFORMATION: 2004 LAND ROVER FREELANDER

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN and BROWN/RED	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	GREEN	Ignition Harness
SECOND IGNITION WIRE	BROWN/WHITE	Ignition Harness
ACCESSORY WIRE	GRAY/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	PURPLE/GRAY	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	At Module Attached To Fuse Box
POWER DOOR UNLOCK (-)	BLACK/PINK	At Module Attached To Fuse Box
PARKING LIGHTS (+)	RED/WHITE or RED	At Headlight Switch
DOOR TRIGGER (-)	PURPLE/GRAY & PURPLE/WHITE	At Module Attached To Fuse Box
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	BLACK/ORANGE	At Module Attached To Fuse Box
HOOD TRIGGER (-)	RED/PURPLE	At Module Attached To Fuse Box
REAR HATCH RELEASE (-)	ORANGE/BROWN	At Module Attached To Fuse Box
FACTORY ALARM ARM (-)	BLACK/PINK	At Module Attached To Fuse Box
FACTORY ALARM DISARM (-)	BLACK/RED	At Module Attached To Fuse Box
TACHOMETER WIRE	NOT BLACK or BROWN/PINK	Ignition Coil
BRAKE WIRE (+)	GREEN/PINK	At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/YELLOW	At Module Attached To Fuse Box
LEFT FRONT WINDOW UP	ORANGE/RED	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/BLUE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	ORANGE/RED	At Motor In Right Front Door
RIGHT FRONT WINDOW DOWN	ORANGE/BLUE	At Motor In Right Front Door
LEFT REAR WINDOW UP	RED	At Motor In Left Rear Door
LEFT REAR WINDOW DOWN	BLUE	At Motor In Left Rear Door
RIGHT REAR WINDOW UP	RED	At Motor In Right Rear Door
RIGHT REAR WINDOW DOWN	BLUE	At Motor In Right Rear Door
This vehicle has a factory Immobilizer system. This needs to be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 LAND ROVER FREELANDER

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN and BROWN/RED	Ignition Harness
STARTER WIRE	WHITE/RED	Ignition Harness
IGNITION WIRE	GREEN	Ignition Harness
SECOND IGNITION WIRE	BROWN/WHITE	Ignition Harness
ACCESSORY WIRE	GRAY/BLUE	Ignition Harness
SECOND ACCESSORY WIRE	PURPLE/GRAY	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	At Module Attached To Fuse Box
POWER DOOR UNLOCK (-)	BLACK/PINK	At Module Attached To Fuse Box
PARKING LIGHTS (+)	RED/WHITE or RED	At Headlight Switch
DOOR TRIGGER (-)	PURPLE/GRAY & PURPLE/WHITE	At Module Attached To Fuse Box
DOME LIGHT SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER (-)	BLACK/ORANGE	At Module Attached To Fuse Box
HOOD TRIGGER (-)	RED/PURPLE	At Module Attached To Fuse Box
REAR HATCH RELEASE (-)	ORANGE/BROWN	At Module Attached To Fuse Box
FACTORY ALARM ARM (-)	BLACK/PINK	At Module Attached To Fuse Box
FACTORY ALARM DISARM (-)	BLACK/RED	At Module Attached To Fuse Box
TACHOMETER WIRE	NOT BLACK or BROWN/PINK	Ignition Coil
BRAKE WIRE (+)	GREEN/PINK	At Brake Pedal Switch
HORN TRIGGER (-)	PURPLE/YELLOW	At Module Attached To Fuse Box
LEFT FRONT WINDOW UP	ORANGE/RED	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/BLUE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	ORANGE/RED	At Motor In Right Front Door
RIGHT FRONT WINDOW DOWN	ORANGE/BLUE	At Motor In Right Front Door
LEFT REAR WINDOW UP	RED	At Motor In Left Rear Door
LEFT REAR WINDOW DOWN	BLUE	At Motor In Left Rear Door
RIGHT REAR WINDOW UP	RED	At Motor In Right Rear Door
RIGHT REAR WINDOW DOWN	BLUE	At Motor In Right Rear Door
This vehicle has a factory Immobilizer system. This needs to be bypassed when installing a remote start system.		