

TRIPLE S *Customs*

LEXUS ES300 1992-2003 VEHICLE WIRING

WIRING INFORMATION: 1992 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE AND WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW/RED	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/BLUE	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
PARKING LIGHTS (+)	GREEN W/ SILVER DOTS	Harness At Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Bottom Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	Light In Trunk Or Factory Anti-theft Unit Behind Glove Box
HOOD TRIGGER (-)	BLACK	Factory Hood Pin Switch Or Factory Anti-theft Unit Behind Glove Box
TRUNK RELEASE (-)	RED/BLUE	Harness In Driver's Kick Panel
FACTRY ALARM ARM	ARMS WITH LOCK	
FACTRY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	RED/BLUE	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> To disarm the factory security system without unlocking the doors, give a negative pulse to the smaller gauge RED/BLUE wire in the drivers kick panel. 		
TACHOMETER WIRE	BLACK	Connector By Engine On Right Side
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/BLACK	Factory Anti-theft Unit Behind Glove Box
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1993 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE AND WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW/RED	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/BLUE	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
PARKING LIGHTS (+)	GREEN W/ SILVER DOTS	Harness At Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Bottom Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	Light In Trunk Or Factory Anti-theft Unit Behind Glove Box
HOOD TRIGGER (-)	BLACK	Factory Hood Pin Switch Or Factory Anti-theft Unit Behind Glove Box
TRUNK RELEASE (-)	RED/BLUE	Harness In Driver's Kick Panel
FACTRY ALARM ARM	ARMS WITH LOCK	
FACTRY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	RED/BLUE	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> To disarm the factory security system without unlocking the doors, give a negative pulse to the smaller gauge RED/BLUE wire in the drivers kick panel. 		
TACHOMETER WIRE	BLACK	Connector By Engine On Right Side
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/BLACK	Factory Anti-theft Unit Behind Glove Box
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1994 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE AND WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW/RED	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/BLUE	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
PARKING LIGHTS (+)	GREEN W/ SILVER DOTS	Harness At Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Bottom Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	Light In Trunk Or Factory Anti-theft Unit Behind Glove Box
HOOD TRIGGER (-)	BLACK	Factory Hood Pin Switch Or Factory Anti-theft Unit Behind Glove Box
TRUNK RELEASE (+)	BLUE	Harness In Driver's Kick Panel
FACTRY ALARM ARM	ARMS WITH LOCK	
FACTRY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	RED/BLUE	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> To disarm the factory security system without unlocking the doors, give a negative pulse to the smaller gauge RED/BLUE wire in the drivers kick panel. 		
TACHOMETER WIRE	BLACK	Connector By Engine On Right Side
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/BLACK	Factory Anti-theft Unit Behind Glove Box
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1995 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE AND WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW/RED	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/BLUE	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
PARKING LIGHTS (+)	GREEN W/ SILVER DOTS	Harness At Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Bottom Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	Light In Trunk Or Factory Anti-theft Unit Behind Glove Box
HOOD TRIGGER (-)	BLACK	Factory Hood Pin Switch Or Factory Anti-theft Unit Behind Glove Box
TRUNK RELEASE (+)	BLUE	Harness In Driver's Kick Panel
FACTRY ALARM ARM	ARMS WITH LOCK	
FACTRY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	RED/BLUE	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> To disarm the factory security system without unlocking the doors, give a negative pulse to the smaller gauge RED/BLUE wire in the drivers kick panel. 		
TACHOMETER WIRE	BLACK	Connector By Engine On Right Side
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/BLACK	Factory Anti-theft Unit Behind Glove Box
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1996 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE AND WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	PINK/BLUE	Ignition Harness
POWER DOOR LOCK (-)	YELLOW/RED	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
POWER DOOR UNLOCK (-)	YELLOW/BLUE	Harness In Passenger Kick Or Factory Anti-theft Unit Behind Glove Box
PARKING LIGHTS (+)	GREEN W/ SILVER DOTS	Harness At Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Bottom Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	Light In Trunk Or Factory Anti-theft Unit Behind Glove Box
HOOD TRIGGER (-)	BLACK	Factory Hood Pin Switch Or Factory Anti-theft Unit Behind Glove Box
TRUNK RELEASE (-)	RED	Harness In Driver's Kick Panel
FACTRY ALARM ARM	ARMS WITH LOCK	
FACTRY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	RED/BLUE	Harness In Driver's Kick Panel
<ul style="list-style-type: none"> To disarm the factory security system without unlocking the doors, give a negative pulse to the smaller gauge RED/BLUE wire in the drivers kick panel. 		
TACHOMETER WIRE	BLACK	Connector By Engine On Right Side
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/BLACK	Factory Anti-theft Unit Behind Glove Box
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1997 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Orange Connector At Bottom Of Fuse Box
POWER DOOR UNLOCK (-)	DK. BLUE	Orange Connector At Bottom Of Fuse Box
Test door lock wires by operating the key in the passenger door lock cylinder.		
PARKING LIGHTS (+)	GREEN/ORANGE OR GREEN/BLACK	Harness At Bottom Of Fuse box
DOOR TRIGGER (-)	RED/WHITE	Harness On Top Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk Or Factory Anti-theft Module Behind Dash Under Radio
HOOD TRIGGER (-)	BLACK	At Factory Hood Pin Or Factory Anti-theft Module Behind Dash Under Radio
TRUNK RELEASE (-)	RED	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
FACTORY ALARM DISARM NO UNLOCK (-)	BLUE or BLUE/BLACK (key-sense wire)	Ignition harness
TACHOMETER WIRE	GRAY	At Igniter On Front Of Driver Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness On Bottom Of Fuse box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1998 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Factory Anti-theft Module Behind Dash Under Radio
POWER DOOR UNLOCK (-)	DK. BLUE	Factory Anti-theft Module Behind Dash Under Radio
Test door lock wires by operating the key in the passenger door lock cylinder.		
PARKING LIGHTS (+)	GREEN/ORANGE OR GREEN/BLACK	Harness At Bottom Of Fuse box
DOOR TRIGGER (-)	RED/WHITE	Harness On Top Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk Or Factory Anti-theft Module Behind Dash Under Radio
HOOD TRIGGER (-)	BLACK	At Factory Hood Pin Or Factory Anti-theft Module Behind Dash Under Radio
TRUNK RELEASE (-)	RED	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
FACTORY ALARM DISARM NO UNLOCK (-)	BLUE or BLUE/BLACK (key-sense wire)	Ignition harness
TACHOMETER WIRE	GRAY	At Igniter On Front Of Driver Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness On Bottom Of Fuse box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 1999 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Factory Anti-theft Module Behind Dash Under Radio
POWER DOOR UNLOCK (-)	DK. BLUE	Factory Anti-theft Module Behind Dash Under Radio
Test door lock wires by operating the key in the passenger door lock cylinder.		
PARKING LIGHTS (+)	GREEN/ORANGE OR GREEN/BLACK	Harness At Bottom Of Fuse box
DOOR TRIGGER (-)	RED/WHITE	Harness On Top Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk Or Factory Anti-theft Module Behind Dash Under Radio
HOOD TRIGGER (-)	BLACK	At Factory Hood Pin Or Factory Anti-theft Module Behind Dash Under Radio
TRUNK RELEASE (-)	RED	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
FACTORY ALARM DISARM NO UNLOCK (-)	BLUE or BLUE/BLACK (key-sense wire)	Ignition harness
TACHOMETER WIRE	GRAY	At Igniter On Front Of Driver Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness On Bottom Of Fuse box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2000 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Factory Anti-theft Module Behind Dash Under Radio
POWER DOOR UNLOCK (-)	DK. BLUE	Factory Anti-theft Module Behind Dash Under Radio
Test door lock wires by operating the key in the passenger door lock cylinder.		
PARKING LIGHTS (+)	GREEN/ORANGE OR GREEN/BLACK	Harness At Bottom Of Fuse box
DOOR TRIGGER (-)	RED/WHITE	Harness On Top Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk Or Factory Anti-theft Module Behind Dash Under Radio
HOOD TRIGGER (-)	BLACK	At Factory Hood Pin Or Factory Anti-theft Module Behind Dash Under Radio
TRUNK RELEASE (-)	RED	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
FACTORY ALARM DISARM NO UNLOCK (-)	BLUE or BLUE/BLACK (key-sense wire)	Ignition harness
TACHOMETER WIRE	GRAY	At Igniter On Front Of Driver Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness On Bottom Of Fuse box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2001 Lexus ES300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE - WHITE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	DK. BLUE/WHITE	Factory Anti-theft Module Behind Dash Under Radio
POWER DOOR UNLOCK (-)	DK. BLUE	Factory Anti-theft Module Behind Dash Under Radio
Test door lock wires by operating the key in the passenger door lock cylinder.		
PARKING LIGHTS (+)	GREEN/ORANGE OR GREEN/BLACK	Harness At Bottom Of Fuse box
DOOR TRIGGER (-)	RED/WHITE	Harness On Top Of Fuse Box
TRUNK TRIGGER (-)	RED/YELLOW	At Light In Trunk Or Factory Anti-theft Module Behind Dash Under Radio
HOOD TRIGGER (-)	BLACK	At Factory Hood Pin Or Factory Anti-theft Module Behind Dash Under Radio
TRUNK RELEASE (-)	RED	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
FACTORY ALARM DISARM NO UNLOCK (-)	BLUE or BLUE/BLACK (key-sense wire)	Ignition harness
TACHOMETER WIRE	GRAY	At Igniter On Front Of Driver Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	Harness On Bottom Of Fuse box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2002 Lexus ES300

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	BLACK/WHITE	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	BLUE/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Test door lock wires by operating the key in the passenger door lock cylinder.		
DRIVER DOOR TRIGGER (-)	RED/GREEN	Plug Lower Left Of Fuse Box
PASSENGER DOOR TRIGGER (-)	RED/GREEN	Plug Upper Left Of Fuse Box
REAR DOORS TRIGGER (-)	RED/WHITE	Plug Bottom Of Fuse Box
TRUNK TRIGGER (-)	GREEN	Harness In Driver's Kick Panel Or At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TRUNK RELEASE (5-wire)	WHITE/BLUE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Harness At Bottom Of Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2003 Lexus ES300

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	BLACK/WHITE	Ignition harness
SECOND STARTER WIRE	GREEN/YELLOW	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	BLUE/YELLOW	At Module Inside Driver's Door
POWER DOOR UNLOCK (-)	BLUE	At Module Inside Driver's Door
Unlock requires a double pulse		
DRIVER DOOR TRIGGER (-)	RED/GREEN	Plug Lower Left Of Fuse Box
PASSENGER DOOR TRIGGER (-)	RED/GREEN	Plug Upper Left Of Fuse Box
LEFT REAR DOOR TRIGGER (-)	RED/WHITE	Plug Bottom Of Fuse Box
RIGHT REAR DOOR TRIGGER (-)	RED/YELLOW	Plug Bottom Of Fuse Box
TRUNK TRIGGER (-)	GREEN	Harness In Driver's Kick Panel Or At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TRUNK RELEASE (5-wire)	WHITE/BLUE	Harness In Driver's Kick Panel
FUEL DOOR RELEASE (+)	RED/WHITE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK/ORANGE	At Engine Control Module Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Module In Left Front Door
LEFT FRONT WINDOW DOWN	RED	At Module In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Module In Right Front Door
LEFT REAR WINDOW UP	GREEN	At Module In Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Module In Left Rear Door
RIGHT REAR WINDOW UP	GREEN	At Module In Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Module In Right Rear Door
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		