

TRIPLE S *Customs*

LEXUS ES330 2004-2006 VEHICLE WIRING

WIRING INFORMATION: 2004 Lexus ES330

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	GREEN/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
KEY SENSE WIRE (-)	BLUE	Ignition Harness
Using the ground when remote start activated wire from the remote start to trigger this wire will disarm the factory security without unlocking the doors.		
POWER DOOR LOCK (-)	BLUE/YELLOW	At Module Inside Driver Door
POWER DOOR UNLOCK (-)	BLUE	At Module Inside Driver Door
A double pulse is required to unlock all the doors.		
PARKING LIGHTS (+)	GREEN	In Connector At Bottom Of Fuse Box
PARKING LIGHTS (-)	RED	At Body ECU Attached To Rear Of Fuse Box
LEFT FRONT DOOR TRIGGER (-)	RED/GREEN	At Body ECU Attached To Rear Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	RED/GREEN	
LEFT REAR DOOR TRIGGER (-)	RED/WHITE	
RIGHT REAR DOOR TRIGGER (-)	RED/YELLOW	
DOMELIGHT SUPERVISION (-)	GREEN/RED	In Driver's "A" Pillar
TRUNK TRIGGER (-)	GREEN	At Body ECU Attached To Rear Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Theft ECU Behind Glove Box
TRUNK RELEASE (-)	RED or BLUE/YELLOW	At Body ECU Attached To Rear Of Fuse Box
FUEL DOOR RELEASE (+)	RED/WHITE	At Switch On Dash
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY ALARM DISARM NO UNLOCK	Use key sense wire	
TACHOMETER WIRE	BLACK/ORANGE	At ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Bottom Of Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Bottom Of Fuse Box
LEFT FRONT WINDOW UP	GREEN	At Module In Left Front Door
LEFT FRONT WINDOW DOWN	RED	At Module In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Module In Right Front Door
LEFT REAR WINDOW UP	GREEN	At Module In Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Module In Left Rear Door
RIGHT REAR WINDOW UP	GREEN	At Module In Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Module In Right Rear Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system		

WIRING INFORMATION: 2005 Lexus ES330

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	GREEN/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
KEY SENSE WIRE (-)	BLUE	Ignition Harness
Using the ground when remote start activated wire from the remote start to trigger this wire will disarm the factory security without unlocking the doors.		
POWER DOOR LOCK (-)	BLUE/YELLOW	At Module Inside Driver Door
POWER DOOR UNLOCK (-)	BLUE	At Module Inside Driver Door
A double pulse is required to unlock all the doors.		
PARKING LIGHTS (+)	GREEN	In Connector At Bottom Of Fuse Box
PARKING LIGHTS (-)	RED	At Body ECU Attached To Rear Of Fuse Box
LEFT FRONT DOOR TRIGGER (-)	RED/GREEN	At Body ECU Attached To Rear Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	RED/GREEN	
LEFT REAR DOOR TRIGGER (-)	RED/WHITE	
RIGHT REAR DOOR TRIGGER (-)	RED/YELLOW	
DOMELIGHT SUPERVISION (-)	GREEN/RED	In Driver's "A" Pillar
TRUNK TRIGGER (-)	GREEN	At Body ECU Attached To Rear Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Theft ECU Behind Glove Box
TRUNK RELEASE (-)	RED or BLUE/YELLOW	At Body ECU Attached To Rear Of Fuse Box
FUEL DOOR RELEASE (+)	RED/WHITE	At Switch On Dash
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY ALARM DISARM NO UNLOCK	Use key sense wire	
TACHOMETER WIRE	BLACK/ORANGE	At ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Bottom Of Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Bottom Of Fuse Box
LEFT FRONT WINDOW UP	GREEN	At Module In Left Front Door
LEFT FRONT WINDOW DOWN	RED	At Module In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Module In Right Front Door
LEFT REAR WINDOW UP	GREEN	At Module In Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Module In Left Rear Door
RIGHT REAR WINDOW UP	GREEN	At Module In Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Module In Right Rear Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system		

WIRING INFORMATION: 2006 Lexus ES330

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	GREEN/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
KEY SENSE WIRE (-)	BLUE	Ignition Harness
Using the ground when remote start activated wire from the remote start to trigger this wire will disarm the factory security without unlocking the doors.		
POWER DOOR LOCK (-)	BLUE/YELLOW	At Module Inside Driver Door
POWER DOOR UNLOCK (-)	BLUE	At Module Inside Driver Door
A double pulse is required to unlock all the doors.		
PARKING LIGHTS (+)	GREEN	In Connector At Bottom Of Fuse Box
PARKING LIGHTS (-)	RED	At Body ECU Attached To Rear Of Fuse Box
LEFT FRONT DOOR TRIGGER (-)	RED/GREEN	At Body ECU Attached To Rear Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	RED/GREEN	
LEFT REAR DOOR TRIGGER (-)	RED/WHITE	
RIGHT REAR DOOR TRIGGER (-)	RED/YELLOW	
DOMELIGHT SUPERVISION (-)	GREEN/RED	In Driver's "A" Pillar
TRUNK TRIGGER (-)	GREEN	At Body ECU Attached To Rear Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Theft ECU Behind Glove Box
TRUNK RELEASE (-)	RED or BLUE/YELLOW	At Body ECU Attached To Rear Of Fuse Box
FUEL DOOR RELEASE (+)	RED/WHITE	At Switch On Dash
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY ALARM DISARM NO UNLOCK	Use key sense wire	
TACHOMETER WIRE	BLACK/ORANGE	At ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Harness At Bottom Of Fuse Box
HORN TRIGGER (-)	GREEN/BLACK	Harness At Bottom Of Fuse Box
LEFT FRONT WINDOW UP	GREEN	At Module In Left Front Door
LEFT FRONT WINDOW DOWN	RED	At Module In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Module In Right Front Door
LEFT REAR WINDOW UP	GREEN	At Module In Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Module In Left Rear Door
RIGHT REAR WINDOW UP	GREEN	At Module In Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Module In Right Rear Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system		