

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
POWER DOOR LOCK (-)	GREEN/BLACK or BLACK/ORANGE	Harness In Passenger Kick Panel

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

POWER DOOR UNLOCK (-)	GREEN	Harness In Passenger Kick Panel
-----------------------	-------	---------------------------------

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

PARKING LIGHTS (+)	GREEN	Harness To The Left Of The Fuse Box
PARKING LIGHTS (-)	GREEN	Top Connector At Body ECU Which Is Part Of The Fuse Box Under The Dash
DRIVER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
PASSENGER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
LEFT REAR DOOR TRIGGER (-)	PINK/BLACK	Middle Connector At Body ECU
RIGHT REAR DOOR TRIGGER (-)	PINK/BLUE	Middle Connector At Body ECU
DOMELIGHT SUPERVISION (-)	WHITE	Harness On Right Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Middle Connector At Body ECU
HOOD TRIGGER (-)	RED/WHITE	Large Harness By Firewall
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/YELLOW (key-sense wire)	Ignition harness
TACHOMETER	BLACK/WHITE	In Top Connector At ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/YELLOW	Harness Left Of Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Module In Driver Door
LEFT FRONT WINDOW DOWN	GREEN	At Module In Driver Door
RIGHT FRONT WINDOW UP	RED	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	GREEN	At Module In Right Front Door
LEFT REAR WINDOW UP		
Notes: Extended triggers on the power door lock wires will roll the windows up or down.		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 555XW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	PURPLE	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	RED	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5", 3.5"		10" subwoofer
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
None available		None available	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
POWER DOOR LOCK (-)	GREEN/BLACK or BLACK/ORANGE	Harness In Passenger Kick Panel

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

POWER DOOR UNLOCK (-)	GREEN	Harness In Passenger Kick Panel
-----------------------	-------	---------------------------------

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

PARKING LIGHTS (+)	GREEN	Harness To The Left Of The Fuse Box
PARKING LIGHTS (-)	GREEN	Top Connector At Body ECU Which Is Part Of The Fuse Box Under The Dash
DRIVER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
PASSENGER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
LEFT REAR DOOR TRIGGER (-)	PINK/BLACK	Middle Connector At Body ECU
RIGHT REAR DOOR TRIGGER (-)	PINK/BLUE	Middle Connector At Body ECU
DOMELIGHT SUPERVISION (-)	WHITE	Harness On Right Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Middle Connector At Body ECU
HOOD TRIGGER (-)	RED/WHITE	Large Harness By Firewall
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/YELLOW (key-sense wire)	Ignition harness
TACHOMETER	BLACK/WHITE	In Top Connector At ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/YELLOW	Harness Left Of Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Module In Driver Door
LEFT FRONT WINDOW DOWN	GREEN	At Module In Driver Door
RIGHT FRONT WINDOW UP	RED	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	GREEN	At Module In Right Front Door
LEFT REAR WINDOW UP		
Notes: Extended triggers on the power door lock wires will roll the windows up or down.		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 555XW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	PURPLE	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	RED	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5", 3.5"		10" subwoofer
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
None available		None available	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
POWER DOOR LOCK (-)	GREEN/BLACK or BLACK/ORANGE	Harness In Passenger Kick Panel

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

POWER DOOR UNLOCK (-)	GREEN	Harness In Passenger Kick Panel
-----------------------	-------	---------------------------------

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

PARKING LIGHTS (+)	GREEN	Harness To The Left Of The Fuse Box
PARKING LIGHTS (-)	GREEN	Top Connector At Body ECU Which Is Part Of The Fuse Box Under The Dash
DRIVER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
PASSENGER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
LEFT REAR DOOR TRIGGER (-)	PINK/BLACK	Middle Connector At Body ECU
RIGHT REAR DOOR TRIGGER (-)	PINK/BLUE	Middle Connector At Body ECU
DOMELIGHT SUPERVISION (-)	WHITE	Harness On Right Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Middle Connector At Body ECU
HOOD TRIGGER (-)	RED/WHITE	Large Harness By Firewall
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/YELLOW (key-sense wire)	Ignition harness
TACHOMETER	BLACK/WHITE	In Top Connector At ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/YELLOW	Harness Left Of Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Module In Driver Door
LEFT FRONT WINDOW DOWN	GREEN	At Module In Driver Door
RIGHT FRONT WINDOW UP	RED	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	GREEN	At Module In Right Front Door
LEFT REAR WINDOW UP		
Notes: Extended triggers on the power door lock wires will roll the windows up or down.		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 555XW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	PURPLE	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	RED	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5", 3.5"		10" subwoofer
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
None available		None available	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
POWER DOOR LOCK (-)	GREEN/BLACK or BLACK/ORANGE	Harness In Passenger Kick Panel

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

POWER DOOR UNLOCK (-)	GREEN	Harness In Passenger Kick Panel
-----------------------	-------	---------------------------------

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

PARKING LIGHTS (+)	GREEN	Harness To The Left Of The Fuse Box
PARKING LIGHTS (-)	GREEN	Top Connector At Body ECU Which Is Part Of The Fuse Box Under The Dash
DRIVER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
PASSENGER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
LEFT REAR DOOR TRIGGER (-)	PINK/BLACK	Middle Connector At Body ECU
RIGHT REAR DOOR TRIGGER (-)	PINK/BLUE	Middle Connector At Body ECU
DOMELIGHT SUPERVISION (-)	WHITE	Harness On Right Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Middle Connector At Body ECU
HOOD TRIGGER (-)	RED/WHITE	Large Harness By Firewall
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/YELLOW (key-sense wire)	Ignition harness
TACHOMETER	BLACK/WHITE	In Top Connector At ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/YELLOW	Harness Left Of Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Module In Driver Door
LEFT FRONT WINDOW DOWN	GREEN	At Module In Driver Door
RIGHT FRONT WINDOW UP	RED	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	GREEN	At Module In Right Front Door
LEFT REAR WINDOW UP		
Notes: Extended triggers on the power door lock wires will roll the windows up or down.		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 555XW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	PURPLE	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	RED	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5", 3.5"		10" subwoofer
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
None available		None available	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
POWER DOOR LOCK (-)	GREEN/BLACK or BLACK/ORANGE	Harness In Passenger Kick Panel

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

POWER DOOR UNLOCK (-)	GREEN	Harness In Passenger Kick Panel
-----------------------	-------	---------------------------------

Notes: Test door lock wires by using the key in the passenger door. Unlock requires a double pulse.

PARKING LIGHTS (+)	GREEN	Harness To The Left Of The Fuse Box
PARKING LIGHTS (-)	GREEN	Top Connector At Body ECU Which Is Part Of The Fuse Box Under The Dash
DRIVER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
PASSENGER DOOR TRIGGER (-)	RED/YELLOW	Middle Connector At Body ECU
LEFT REAR DOOR TRIGGER (-)	PINK/BLACK	Middle Connector At Body ECU
RIGHT REAR DOOR TRIGGER (-)	PINK/BLUE	Middle Connector At Body ECU
DOMELIGHT SUPERVISION (-)	WHITE	Harness On Right Of Fuse Box
TRUNK TRIGGER (-)	RED/BLUE	Middle Connector At Body ECU
HOOD TRIGGER (-)	RED/WHITE	Large Harness By Firewall
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN/YELLOW (key-sense wire)	Ignition harness
TACHOMETER	BLACK/WHITE	In Top Connector At ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/YELLOW	Harness Left Of Fuse Box
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Module In Driver Door
LEFT FRONT WINDOW DOWN	GREEN	At Module In Driver Door
RIGHT FRONT WINDOW UP	RED	At Module In Right Front Door
RIGHT FRONT WINDOW DOWN	GREEN	At Module In Right Front Door
LEFT REAR WINDOW UP		
Notes: Extended triggers on the power door lock wires will roll the windows up or down.		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 555XW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker or Amplifier Under Driver Seat	
LEFT FRONT SPEAKER (-)	PURPLE	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (+)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (+)	BLACK	At Speaker or Amplifier Under Driver Seat	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (+)	RED	At Speaker or Amplifier Under Driver Seat	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker or Amplifier Under Driver Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5", 3.5"		10" subwoofer
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
None available		None available	Not required
Please verify all part numbers before ordering.			