

TRIPLE S *Customs*

LEXUS SC300 1992-2000 VEHICLE WIRING

WIRING INFORMATION: 1992 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	PINK/BLUE or YELLOW	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
Unlock requires a double pulse.		
PARKING LIGHTS (+)	DARK GREEN	White Connector In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK	Single Pulse To Unlock Wire Will Disarm Factory Alarm Without Unlocking Doors.	
TACHOMETER WIRE	BLACK	Connector On Rear Of Passenger Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch

WIRING INFORMATION: 1993 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	PINK/BLUE or YELLOW	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
Unlock requires a double pulse.		
PARKING LIGHTS (+)	DARK GREEN	White Connector In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK	Single Pulse To Unlock Wire Will Disarm Factory Alarm Without Unlocking Doors.	
TACHOMETER WIRE	BLACK	Connector On Rear Of Passenger Strut Tower
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch

WIRING INFORMATION: 1994 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	PINK/BLUE or YELLOW	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
Unlock requires a double pulse		
PARKING LIGHTS (+)	DARK GREEN	White Connector In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK	Single Pulse To Unlock Wire Will Disarm Factory Alarm Without Unlocking Doors.	
TACHOMETER WIRE	BLACK	Igniter On Passenger Fender
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch

WIRING INFORMATION: 1995 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	RED	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	Igniter On Driver Fender
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch

WIRING INFORMATION: 1996 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION	BLACK/ORANGE	Ignition Harness
ACCESSORY WIRE	RED	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	Igniter On Driver Fender
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch

WIRING INFORMATION: 1997 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	RED	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	Igniter On Driver Fender
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch

WIRING INFORMATION: 1998 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	RED	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	Igniter On Driver Fender
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 1999 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	RED	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	Igniter On Driver Fender
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2000 Lexus SC300

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE	RED	Ignition Harness
POWER LOCK (-)	GREEN/YELLOW	Harness In Passenger Kick Panel
POWER UNLOCK (-)	GREEN/WHITE	Harness In Passenger Kick Panel
PARKING LIGHTS (+)	GREEN	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Connector Below Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk Or Harness In Driver's Kick Panel Running To Rear Of Vehicle
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK	Igniter On Driver Fender
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	At Right Front Window Switch
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	At Right Front Window Switch
This vehicle is equipped with a factory immobilizer system. This must be bypassed when installing a remote start system.		