

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	GRAY/BLACK	Ignition Harness
IGNITION WIRE	GREEN/BLACK	Ignition Harness
SECOND IGNITION WIRE	PINK/WHITE	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	PINK/YELLOW	Ignition Harness
POWER LOCK (-)	BLACK/BLUE	Module Inside Driver's Door In Center Of Door
POWER UNLOCK (-)	BLACK/WHITE	Module Inside Driver's Door In Center Of Door

Notes: Requires a double pulse

PARKING LIGHTS	WHITE/GREEN	At Headlight Switch
----------------	-------------	---------------------

Notes: Negative trigger through an 1800-ohm resistor. Refer to TechDoc 3964

DOOR TRIGGER (-)	BLUE	At Under Dash Light
TRUNK TRIGGER (-)	WHITE/BLACK	At Module In Trunk Above Battery
TRUNK RELEASE (-)	WHITE	At Release Switch Or Module In Trunk Above Battery
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	BROWN/WHITE or BROWN/STRIPE	At Main Harness Going Through Firewall In Passenger Side
BRAKE WIRE (+)	ORANGE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/RED	At Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	WHITE	At Module In Driver's Door
LEFT FRONT WINDOW DOWN	YELLOW	At Module In Driver's Door
RIGHT FRONT WINDOW UP	WHITE/PURPLE	At Module In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	YELLOW/PURPLE	At Module In Driver's Kick Panel
LEFT REAR WINDOW UP	BLUE/RED	At Module In Trunk Above Battery
LEFT REAR WINDOW DOWN	PURPLE/BLUE	At Module In Trunk Above Battery
RIGHT REAR WINDOW UP	BLUE/ORANGE	At Module In Trunk Above Battery
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	At Module In Trunk Above Battery

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 555SW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	GREEN/BLACK	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
RADIO GROUND	BLACK/GREEN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	TAN/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLACK/VIOLET	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/VIOLET	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5000, SCOSCHE LN1328B		METRA 70-1771, SCOSCHE FDK13B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	GRAY/BLACK	Ignition Harness
IGNITION WIRE	GREEN/BLACK	Ignition Harness
SECOND IGNITION WIRE	PINK/WHITE	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	PINK/YELLOW	Ignition Harness
POWER LOCK (-)	BLACK/BLUE	Module Inside Driver's Door In Center Of Door
POWER UNLOCK (-)	BLACK/WHITE	Module Inside Driver's Door In Center Of Door

Notes: Requires a double pulse

PARKING LIGHTS	WHITE/GREEN	At Headlight Switch
----------------	-------------	---------------------

Notes: Negative trigger through an 1800-ohm resistor. Refer to TechDoc 3964

DOOR TRIGGER (-)	BLUE	At Under Dash Light
TRUNK TRIGGER (-)	WHITE/BLACK	At Module In Trunk Above Battery
TRUNK RELEASE (-)	WHITE	At Release Switch Or Module In Trunk Above Battery
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	BROWN/WHITE or BROWN/STRIPE	At Main Harness Going Through Firewall In Passenger Side
BRAKE WIRE (+)	ORANGE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/RED	At Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	WHITE	At Module In Driver's Door
LEFT FRONT WINDOW DOWN	YELLOW	At Module In Driver's Door
RIGHT FRONT WINDOW UP	WHITE/PURPLE	At Module In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	YELLOW/PURPLE	At Module In Driver's Kick Panel
LEFT REAR WINDOW UP	BLUE/RED	At Module In Trunk Above Battery
LEFT REAR WINDOW DOWN	PURPLE/BLUE	At Module In Trunk Above Battery
RIGHT REAR WINDOW UP	BLUE/ORANGE	At Module In Trunk Above Battery
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	At Module In Trunk Above Battery

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 555SW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	GREEN/BLACK	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
RADIO GROUND	BLACK/GREEN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	TAN/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLACK/VIOLET	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/VIOLET	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5000, SCOSCHE LN1328B		METRA 70-1771, SCOSCHE FDK13B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	GRAY/BLACK	Ignition Harness
IGNITION WIRE	GREEN/BLACK	Ignition Harness
SECOND IGNITION WIRE	PINK/WHITE	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	PINK/YELLOW	Ignition Harness
POWER LOCK (-)	BLACK/BLUE	Module Inside Driver's Door In Center Of Door
POWER UNLOCK (-)	BLACK/WHITE	Module Inside Driver's Door In Center Of Door

Notes: Requires a double pulse

PARKING LIGHTS	WHITE/GREEN	At Headlight Switch
----------------	-------------	---------------------

Notes: Negative trigger through an 1800-ohm resistor. Refer to TechDoc 3964

DOOR TRIGGER (-)	BLUE	At Under Dash Light
TRUNK TRIGGER (-)	WHITE/BLACK	At Module In Trunk Above Battery
TRUNK RELEASE (-)	WHITE	At Release Switch Or Module In Trunk Above Battery
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	BROWN/WHITE or BROWN/STRIPE	At Main Harness Going Through Firewall In Passenger Side
BRAKE WIRE (+)	ORANGE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/RED	At Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	WHITE	At Module In Driver's Door
LEFT FRONT WINDOW DOWN	YELLOW	At Module In Driver's Door
RIGHT FRONT WINDOW UP	WHITE/PURPLE	At Module In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	YELLOW/PURPLE	At Module In Driver's Kick Panel
LEFT REAR WINDOW UP	BLUE/RED	At Module In Trunk Above Battery
LEFT REAR WINDOW DOWN	PURPLE/BLUE	At Module In Trunk Above Battery
RIGHT REAR WINDOW UP	BLUE/ORANGE	At Module In Trunk Above Battery
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	At Module In Trunk Above Battery

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 555SW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	GREEN/BLACK	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
RADIO GROUND	BLACK/GREEN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	TAN/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLACK/VIOLET	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/VIOLET	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5000, SCOSCHE LN1328B		METRA 70-1771, SCOSCHE FDK13B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	GRAY/BLACK	Ignition Harness
IGNITION WIRE	GREEN/BLACK	Ignition Harness
ACCESSORY WIRE	PINK/WHITE	Ignition Harness
SECOND ACCESSORY	PINK/YELLOW	Ignition Harness
THIRD ACCESSORY WIRE	YELLOW	Ignition Harness
POWER LOCK (-)	BLACK/BLUE	Module Inside Driver's Door
POWER UNLOCK (-)	BLACK/WHITE	Module Inside Driver's Door

Notes: Unlock requires a double pulse.

PARKING LIGHTS	WHITE/BLUE and BROWN/GREEN	At Headlight Switch
----------------	-------------------------------	---------------------

Notes: Special interface required to activate parking lights. Must use two relays and a 1800-ohm resistor. Refer to TechDoc 3225

DOOR TRIGGER (-)	BLACK/BLUE	At Module In Driver's Kick Panel
------------------	------------	----------------------------------

Notes: This wire drops voltage after the vehicle is secured. Must use a relay to isolate.

TRUNK TRIGGER (-)	BLACK/BLUE	At Module In Trunk Above Battery
-------------------	------------	----------------------------------

Notes: This wire drops voltage after the vehicle is secured. Must use a relay to isolate.

TRUNK RELEASE (-)	WHITE	At Module In Driver's Kick Panel
-------------------	-------	----------------------------------

FUEL DOOR RELEASE (-)	BLACK/WHITE	At Release Switch
-----------------------	-------------	-------------------

Notes: Must use a relay to activate.

FACTORY ALARM DISARM	Disarms with unlock
----------------------	---------------------

TACHOMETER WIRE	BROWN or BROWN/STRIPE	At Ignition Coil
-----------------	-----------------------	------------------

BRAKE WIRE (+)	ORANGE/BLUE	At Brake Pedal Switch
----------------	-------------	-----------------------

HORN TRIGGER (-)	BROWN/RED	At Module In Driver's Kick Panel
------------------	-----------	----------------------------------

LEFT FRONT WINDOW UP	Extended pulses on the door lock wires will roll the windows up or down.
----------------------	--

LEFT FRONT WINDOW DOWN

RIGHT FRONT WINDOW UP

RIGHT FRONT WINDOW DOWN

LEFT REAR WINDOW UP

LEFT REAR WINDOW DOWN

RIGHT REAR WINDOW UP

RIGHT REAR WINDOW DOWN

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE/BLACK	Radio Harness	
RADIO SWITCHED	YELLOW/GREEN	Radio Harness	
RADIO GROUND	BLACK/GREEN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	YELLOW/RED	Radio Harness	
AMP TURN ON (+)	YELLOW	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE/VIOLET	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-5000, SCOSCHE LN1328B	METRA 70-1771, SCOSCHE FDK13B	Not required	
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	GRAY/BLACK	Ignition Harness
IGNITION WIRE	GREEN/BLACK	Ignition Harness
ACCESSORY WIRE	PINK/WHITE	Ignition Harness
SECOND ACCESSORY	PINK/YELLOW	Ignition Harness
THIRD ACCESSORY WIRE	YELLOW	Ignition Harness
POWER LOCK (-)	BLACK/BLUE	Module Inside Driver's Door
POWER UNLOCK (-)	BLACK/WHITE	Module Inside Driver's Door

Notes: Unlock requires a double pulse.

PARKING LIGHTS	WHITE/BLUE and BROWN/GREEN	At Headlight Switch
----------------	-------------------------------	---------------------

Notes: Special interface required to activate parking lights. Must use two relays and a 1800-ohm resistor. Refer to TechDoc 3225

DOOR TRIGGER (-)	BLACK/BLUE	At Module In Driver's Kick Panel
------------------	------------	----------------------------------

Notes: This wire drops voltage after the vehicle is secured. Must use a relay to isolate.

TRUNK TRIGGER (-)	BLACK/BLUE	At Module In Trunk Above Battery
-------------------	------------	----------------------------------

Notes: This wire drops voltage after the vehicle is secured. Must use a relay to isolate.

TRUNK RELEASE (-)	WHITE	At Module In Driver's Kick Panel
-------------------	-------	----------------------------------

FUEL DOOR RELEASE (-)	BLACK/WHITE	At Release Switch
-----------------------	-------------	-------------------

Notes: Must use a relay to activate.

FACTORY ALARM DISARM	Disarms with unlock
----------------------	---------------------

TACHOMETER WIRE	BROWN or BROWN/STRIPE	At Ignition Coil
-----------------	-----------------------	------------------

BRAKE WIRE (+)	ORANGE/BLUE	At Brake Pedal Switch
----------------	-------------	-----------------------

HORN TRIGGER (-)	BROWN/RED	At Module In Driver's Kick Panel
------------------	-----------	----------------------------------

LEFT FRONT WINDOW UP	Extended pulses on the door lock wires will roll the windows up or down.
----------------------	--

LEFT FRONT WINDOW DOWN

RIGHT FRONT WINDOW UP

RIGHT FRONT WINDOW DOWN

LEFT REAR WINDOW UP

LEFT REAR WINDOW DOWN

RIGHT REAR WINDOW UP

RIGHT REAR WINDOW DOWN

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE/BLACK	Radio Harness	
RADIO SWITCHED	YELLOW/GREEN	Radio Harness	
RADIO GROUND	BLACK/GREEN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	YELLOW/RED	Radio Harness	
AMP TURN ON (+)	YELLOW	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE/VIOLET	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5000, SCOSCHE LN1328B		METRA 70-5520, SCOSCHE FDK11B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	GRAY/BLACK	Ignition Harness
IGNITION WIRE	GREEN/BLACK	Ignition Harness
ACCESSORY WIRE	PINK/WHITE	Ignition Harness
SECOND ACCESSORY	PINK/YELLOW	Ignition Harness
THIRD ACCESSORY WIRE	YELLOW	Ignition Harness
POWER LOCK (-)	BLACK/BLUE	Module Inside Driver's Door
POWER UNLOCK (-)	BLACK/WHITE	Module Inside Driver's Door

Notes: Unlock requires a double pulse.

PARKING LIGHTS	WHITE/BLUE and BROWN/GREEN	At Headlight Switch
----------------	----------------------------	---------------------

Notes: Special interface required to activate parking lights. Must use two relays and a 1800-ohm resistor. Refer to TechDoc 3225

DOOR TRIGGER (-)	BLACK/BLUE	At Module In Driver's Kick Panel
------------------	------------	----------------------------------

Notes: This wire drops voltage after the vehicle is secured. Must use a relay to isolate.

TRUNK TRIGGER (-)	BLACK/BLUE	At Module In Trunk Above Battery
-------------------	------------	----------------------------------

Notes: This wire drops voltage after the vehicle is secured. Must use a relay to isolate.

TRUNK RELEASE (-)	WHITE	At Module In Driver's Kick Panel
-------------------	-------	----------------------------------

FUEL DOOR RELEASE (-)	BLACK/WHITE	At Release Switch
-----------------------	-------------	-------------------

Notes: Must use a relay to activate.

FACTORY ALARM DISARM	Disarms with unlock
----------------------	---------------------

TACHOMETER WIRE	BROWN or BROWN/STRIPE	At Ignition Coil
-----------------	-----------------------	------------------

BRAKE WIRE (+)	ORANGE/BLUE	At Brake Pedal Switch
----------------	-------------	-----------------------

HORN TRIGGER (-)	BROWN/RED	At Module In Driver's Kick Panel
------------------	-----------	----------------------------------

LEFT FRONT WINDOW UP	Extended pulses on the door lock wires will roll the windows up or down.	
----------------------	--	--

LEFT FRONT WINDOW DOWN

RIGHT FRONT WINDOW UP

RIGHT FRONT WINDOW DOWN

LEFT REAR WINDOW UP

LEFT REAR WINDOW DOWN

RIGHT REAR WINDOW UP

RIGHT REAR WINDOW DOWN

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE/BLACK	Radio Harness	
RADIO SWITCHED	YELLOW/GREEN	Radio Harness	
RADIO GROUND	BLACK/GREEN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	YELLOW/RED	Radio Harness	
AMP TURN ON (+)	YELLOW	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE/VIOLET	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-5000, SCOSCHE LN1328B	METRA 70-5520, SCOSCHE FDK11B	Not required	
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	GRAY/BLACK	Ignition Harness
IGNITION WIRE	GREEN/BLACK	Ignition Harness
ACCESSORY WIRE	PINK/WHITE	Ignition Harness
SECOND ACCESSORY	PINK/YELLOW	Ignition Harness
THIRD ACCESSORY WIRE	YELLOW	Ignition Harness
POWER LOCK (-)	BLACK/BLUE	Module Inside Driver's Door
POWER UNLOCK (-)	BLACK/WHITE	Module Inside Driver's Door

Notes: Unlock requires a double pulse.

PARKING LIGHTS	WHITE/BLUE and BROWN/GREEN	At Headlight Switch
----------------	-------------------------------	---------------------

Notes: Special interface required to activate parking lights. Must use two relays and a 1800-ohm resistor. Refer to TechDoc 3225

DOOR TRIGGER (-)	BLACK/BLUE	At Module In Driver's Kick Panel
------------------	------------	----------------------------------

Notes: This wire drops voltage after the vehicle is secured. Must use a relay to isolate.

TRUNK TRIGGER (-)	BLACK/BLUE	At Module In Trunk Above Battery
-------------------	------------	----------------------------------

Notes: This wire drops voltage after the vehicle is secured. Must use a relay to isolate.

TRUNK RELEASE (-)	WHITE	At Module In Driver's Kick Panel
-------------------	-------	----------------------------------

FUEL DOOR RELEASE (-)	BLACK/WHITE	At Release Switch
-----------------------	-------------	-------------------

Notes: Must use a relay to activate.

FACTORY ALARM DISARM	Disarms with unlock
----------------------	---------------------

TACHOMETER WIRE	BROWN or BROWN/STRIPE	At Ignition Coil
-----------------	-----------------------	------------------

BRAKE WIRE (+)	ORANGE/BLUE	At Brake Pedal Switch
----------------	-------------	-----------------------

HORN TRIGGER (-)	BROWN/RED	At Module In Driver's Kick Panel
------------------	-----------	----------------------------------

LEFT FRONT WINDOW UP	Extended pulses on the door lock wires will roll the windows up or down.
----------------------	--

LEFT FRONT WINDOW DOWN

RIGHT FRONT WINDOW UP

RIGHT FRONT WINDOW DOWN

LEFT REAR WINDOW UP

LEFT REAR WINDOW DOWN

RIGHT REAR WINDOW UP

RIGHT REAR WINDOW DOWN

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE/BLACK	Radio Harness	
RADIO SWITCHED	YELLOW/GREEN	Radio Harness	
RADIO GROUND	BLACK/GREEN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	YELLOW/RED	Radio Harness	
AMP TURN ON (+)	YELLOW	Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLACK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE/VIOLET	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-5000, SCOSCHE LN1328B	METRA 70-5520, SCOSCHE FDK11B	Not required	
Please verify all part numbers before ordering.			