



Make: Lincoln
Model: Mark VI
Year: 1980-83

Alarm

Function	Color	Location
Constant 12 volts	YELLOW AND YELLOW	IGNITION SWITCH HARNESS
Ignition 12 volts	RED/LIGHT GREEN	IGNITION SWITCH HARNESS
Starter	RED/LIGHT BLUE OR	WHITE/PINK - IGNITION SWITCH HARNESS
Dome Light	BLACK/LIGHT BLUE	(+) AT PIN SWITCH
Trunk Pin Switch	WHITE/PURPLE	(-) AT SWITCH (WITH OEM ALARM)
Parking Lamp	BROWN	(+) AT LIGHT SWITCH
Power Lock	PINK/YELLOW	DRIVER KICK PANEL OR #203
Power Unlock	PINK/LIGHT GREEN	BEHIND GLOVE BOX * #201

* With OEM Keyless Entry See Note #201, Without OEM Keyless Entry See Note #203. #203- See Reversal Rest At Ground Door Lock Diagram. #201- See Negative Pulse Door Lock Diagram.

Accessories

Function	Color	Location
Window Up	D\ RED/YEL P\ RED/BLK D\ RED/L BLU P\ RED/BLK @ MAIN #211	
Window Down	F/ YEL/RED F/ YEL/BLK R/ YEL/L BLU R/ YEL/BLK SWITCH	
Ign Key Warn	BLACK/PINK	(-) STEERING COLUMN HARNESS
Trunk Release	PURPLE/YELLOW	(+) AT RELEASE SWITCH #231
OEM Horn	DARK BLUE	(+) STEERING COLUMN HARNESS
Headlights	RED/YELLOW	(+) AT HEADLIGHT SWITCH
OEM Alarm Arm	N/A	
OEM Alarm Disarm	DARK GREEN/PURPLE	(-) IN EITHER KICK PANEL

#211- See Reversal Rest At Ground Power Window Circuit Diagram. #231- See Positive Pulse Trunk Release Diagram.

Remote Start

Function	Color	Location
Tach Signal	DARK GREEN/YELLOW	AT COIL *
Ignition #2	GRAY/YELLOW	IGNITION SWITCH HARNESS
Ignition #3	N/A	
Accessory	BLACK/LIGHT GREEN	IGNITION SWITCH HARNESS
Neutral Safety	NOT GROUNDING TYPE -	OEM SWITCH OPENS STARTER CIRCUIT
Brake Light	LIGHT GREEN (+)	AT SWITCH ABOVE BRAKE PEDAL
Reverse Light	BLACK/PINK (+)	AT SWITCH
Rear Window Defrost	N/A	

* Throttle Body Injection.

InterConnect Harness

Function	Part #	Available	Location
StrInt,+12,Gnd,Ign		no	
Horn Honk		no	
Lock & Unlock		no	
Light Flash		no	
Dome Light		no	
Trunk Switch		no	
AL-100 / VIP-4000		no	
Remote Start		no	



Make: Lincoln
 Model: Mark VI
 Year: 1980-83

AL100/VIP-4000

Function	Color	Location
RKE Module	IN LUGGAGE COMPARTMENT	
Motor Lock	PNK/BLK	AT OEM KEYLESS *
Motor Unlock	PNK/ORG	AT OEM KEYLESS *
Drv Door Unlock	RED/ORG **	AT KEYLESS OR IN DRIVER KICK PANEL *
OEM Relays	BUILT INTO KEYLESS	
Addon Security Type	#4 CONNECTION	#224
* Circuit Type: Reversal Rest At Ground ** Without Keyless-PNK/ORG		#224 See AL-100/VIP-4000 Type 4 Diagram

Tech Notes

Driver	Passenger		Size	Location
GREEN (+)	WHITE/RED	Front	3 1/2" AND	5 1/4" ** SEE NOTES
BLACK/WHITE (-)	BLACK/WHITE			
PINK/RED (+)	PINK/LT BLUE	Rear	6 X 9"	REAR DECK
PINK/BLUE (-)	GREEN/RED			

* Omega OEM Dash - BU-3.3, BU-3.7 Replacement Doors - BU-5 1/4.3, BU-5 1/4.7, BU-5 1/4.10 Speakers: Rear Deck - BU-69.3, BU-69.7, BU-69.10 ** Front Speakers: 3 1/2" Location In Dash And Also 5 1/4" Location In Front Doors.