

TRIPLE S *Customs*

**LINCOLN TOWN CAR 1990-2006
VEHICLE WIRING**

WIRING INFORMATION: 1990 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN OR LT. GREEN	Ignition Harness
STARTER WIRE	RED OR WHITE/PINK	Ignition Harness
IGNITION WIRE	DK. BLUE/ORANGE	Ignition Harness
ACCESSORY WIRE	GRAY/YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	DK. GREEN	Ignition Harness
POWER DOOR LOCK (Models with factory keyless entry: negative trigger, models without factory keyless entry: positive trigger)	PINK/YELLOW	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (Models with factory keyless entry: negative trigger, models without factory keyless entry: positive trigger)	PINK/GREEN	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel
HEADLIGHTS (+)	GRAY	At Light Switch
DOOR TRIGGER (+)	BLK/BLUE	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	TAN/GREEN	At Factory Alarm Module In Passenger Kick Panel
HOOD TRIGGER	COMMON WITH TRUNK	
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness In Driver's Kick Panel Or Factory Alarm Module In Passenger Kick Panel
TACHOMETER WIRE	GREEN/YELLOW	At Ignition Coil
BRAKE WIRE (+)	LT. GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	DK. BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	In Driver's Door
LEFT REAR WINDOW UP	GRAY/ORANGE	In Driver's Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	In Driver's Door
RIGHT REAR WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION: 1991 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN OR LT. GREEN	Ignition Harness
STARTER WIRE	DK.BLUE/ORANGE	Ignition Harness
IGNITION WIRE	BROWN/PINK	Ignition Harness
SECOND IGNITION WIRE	PINK/BLACK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
POWER DOOR LOCK (Models with factory keyless entry: negative trigger, models without factory keyless entry: positive trigger)	PINK/YELLOW	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (Models with factory keyless entry: negative trigger, models without factory keyless entry: positive trigger)	PINK/GREEN	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel
HEADLIGHTS (+)	GRAY	At Light Switch
DOOR TRIGGER (+)	BLK/BLUE	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	TAN/GREEN	At Factory Alarm Module In Passenger Kick Panel
HOOD TRIGGER	COMMON WITH TRUNK	
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness In Driver's Kick Panel Or Factory Alarm Module In Passenger Kick Panel
TACHOMETER WIRE	GRAY/ORANGE	EDIS Module At Driver Shock Tower
BRAKE WIRE (+)	LT. GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	DK. BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	In Driver's Door
LEFT REAR WINDOW UP	GRAY/ORANGE	In Driver's Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	In Driver's Door
RIGHT REAR WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION: 1992 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN OR LT. GREEN	Ignition Harness
STARTER WIRE	WHITE/PINK	Ignition Harness
IGNITION WIRE	BROWN/PINK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE	PINK/BLACK	Ignition Harness
POWER DOOR LOCK (Models with factory keyless entry use negative trigger power door locks. Models without factory keyless entry use a 5-wire reverse polarity door lock system mastered from the driver switch)	PINK/YELLOW	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (Models with factory keyless entry use negative trigger power door locks. Models without factory keyless entry use a 5-wire reverse polarity door lock system mastered from the driver switch)	PINK/GREEN	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel
HEADLIGHTS (+)	GRAY	At Light Switch
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Drivers Kick Panel
TRUNK PIN (-)	TAN/LT.GREEN	Harness In Drivers Kick Panel
HOOD PIN	COMMON WITH TRUNK	
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	GRAY/ORANGE	EDIS module located at driver side shock tower
BRAKE WIRE (+)	LT. GREEN	Harness At Steering Column
HORN TRIGGER (-)	BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	In Driver's Door
LEFT REAR WINDOW UP	GRAY/ORANGE	In Driver's Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	In Driver's Door
RIGHT REAR WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION: 1993 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN OR LT. GREEN	Ignition Harness
STARTER WIRE	WHITE/PINK	Ignition Harness
IGNITION WIRE	BROWN/PINK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE	PINK/BLACK	Ignition Harness
POWER DOOR LOCK (Models with factory keyless entry use negative trigger power door locks. Models without factory keyless entry use a 5-wire reverse polarity door lock system mastered from the driver switch)	PINK/YELLOW	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (Models with factory keyless entry use negative trigger power door locks. Models without factory keyless entry use a 5-wire reverse polarity door lock system mastered from the driver switch)	PINK/GREEN	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel
HEADLIGHTS (+)	GRAY	At Light Switch
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Drivers Kick Panel
TRUNK PIN (-)	TAN/LT.GREEN	Harness In Drivers Kick Panel
HOOD PIN	COMMON WITH TRUNK	
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	GRAY/ORANGE	EDIS module located at driver side shock tower
BRAKE WIRE (+)	LT. GREEN	Harness At Steering Column
HORN TRIGGER (-)	BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	In Driver's Door
LEFT REAR WINDOW UP	GRAY/ORANGE	In Driver's Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	In Driver's Door
RIGHT REAR WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION: 1994 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN OR LT. GREEN	Ignition Harness
STARTER WIRE	WHITE/PINK	Ignition Harness
IGNITION WIRE	BROWN/PINK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE	PINK/BLACK	Ignition Harness
POWER DOOR LOCK (Models with factory keyless entry use negative trigger power door locks. Models without factory keyless entry use a 5-wire reverse polarity door lock system mastered from the driver switch)	PINK/YELLOW	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (Models with factory keyless entry use negative trigger power door locks. Models without factory keyless entry use a 5-wire reverse polarity door lock system mastered from the driver switch)	PINK/GREEN	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel
HEADLIGHTS (+)	GRAY	At Light Switch
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Drivers Kick Panel
TRUNK PIN (-)	TAN/LT.GREEN	Harness In Drivers Kick Panel
HOOD PIN	COMMON WITH TRUNK	
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	GRAY/ORANGE	EDIS module located at driver side shock tower
BRAKE WIRE (+)	LT. GREEN	Harness At Steering Column
HORN TRIGGER (-)	BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	In Driver's Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	In Driver's Door
LEFT REAR WINDOW UP	GRAY/ORANGE	In Driver's Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	In Driver's Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	In Driver's Door
RIGHT REAR WINDOW DOWN	RED/BLACK	In Driver's Door

WIRING INFORMATION: 1995 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN AND LT. GREEN	Ignition Harness
STARTER WIRE	WHITE/PINK	Ignition Harness
IGNITION WIRE	BROWN/PINK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE	PINK/BLACK	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	BROWN	Harness Found Low In Drivers Kick Panel
HEADLIGHTS (+)	GRAY	Module Under Dash To The Left Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Module Under Dash To The Left Of Steering Column
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Module Under Dash To The Left Of Steering Column
TRUNK TRIGGER (-)	BROWN/WHITE	Module Under Dash To The Left Of Steering Column
HOOD TRIGGER (-)	TAN/LT.GREEN	Module Under Dash To The Left Of Steering Column
TRUNK RELEASE (5-wire)	PURPLE/YELLOW	Harness Found Low In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Module Under Dash To The Left Of Steering Column
TACHOMETER WIRE	TAN/STRIPE	At Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness At Steering Column
HORN TRIGGER (-)	BLUE	Module Under Dash To The Left Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1996 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN AND LT. GREEN	Ignition Harness
STARTER WIRE	WHITE/PINK	Ignition Harness
IGNITION WIRE	BROWN/PINK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE	PINK/BLACK	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	BROWN	Harness Found Low In Drivers Kick Panel
HEADLIGHTS (+)	GRAY	Module Under Dash To The Left Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Module Under Dash To The Left Of Steering Column
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Module Under Dash To The Left Of Steering Column
DOOR TRIGGER (-)	BLUE & BLACK/ORANGE	Module Under Dash To The Left Of Steering Column
TRUNK TRIGGER (-)	BROWN/WHITE	Module Under Dash To The Left Of Steering Column
HOOD TRIGGER (-)	TAN/LT.GREEN	Module Under Dash To The Left Of Steering Column
TRUNK RELEASE (5-wire)	PURPLE/YELLOW	Harness Found Low In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Module Under Dash To The Left Of Steering Column
TACHOMETER WIRE	TAN/STRIPE	At Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness At Steering Column
HORN TRIGGER (-)	BLUE	Module Under Dash To The Left Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1997 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BROWN AND LT. GREEN	Ignition Harness
STARTER WIRE	WHITE/PINK	Ignition Harness
IGNITION WIRE	BROWN/PINK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE	PINK/BLACK	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness In Drivers Kick Panel
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness In Drivers Kick Panel
PARKING LIGHTS (+)	BROWN	Harness Found Low In Drivers Kick Panel
DRIVER DOOR TRIGGER (-)	BLUE	Module Under Dash To The Left Of Steering Column
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Module Under Dash To The Left Of Steering Column
TRUNK TRIGGER (-)	BROWN/WHITE	Module Under Dash To The Left Of Steering Column
HOOD TRIGGER (-)	TAN/LT.GREEN	Module Under Dash To The Left Of Steering Column
TRUNK RELEASE (5-wire)	PURPLE/YELLOW	Harness Found Low In Driver's Kick Panel
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM (-)	DK. GREEN/PURPLE	Module Under Dash To The Left Of Steering Column
TACHOMETER WIRE	TAN/STRIPE	At Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness At Steering Column
HORN TRIGGER (-)	BLUE	Module Under Dash To The Left Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1998 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED/LT.BLUE	Ignition Harness
IGNITION WIRE	WHITE/YELLOW	Ignition Harness
SECOND IGNITION WIRE	PINK/BLACK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE (When installing a remote start system, this wire must be powered as an accessory. If powered as a 2nd ignition the gauges will not function properly.)	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door Harness
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door Harness
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
TRUNK TRIGGER (-)	BROWN/WHITE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
TACHOMETER WIRE	GREEN/WHITE or GREEN/YELLOW	Ignition Coil On Front Of Engine On Driver's Side
BRAKE WIRE (+)	RED/LT.GREEN	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with the PATS (passive anti-theft system) security system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 1999 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED/LT.BLUE	Ignition Harness
IGNITION WIRE	WHITE/YELLOW	Ignition Harness
SECOND IGNITION WIRE	PINK/BLACK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE (When installing a remote start system, this wire must be powered as an accessory. If powered as a 2nd ignition the gauges will not function properly.)	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door Harness
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door Harness
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
TRUNK TRIGGER (-)	BROWN/WHITE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
TACHOMETER WIRE	GREEN/WHITE or GREEN/YELLOW	Ignition Coil On Front Of Engine On Driver's Side
BRAKE WIRE (+)	RED/LT.GREEN	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with the PATS (passive anti-theft system) security system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2000 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED/LT.BLUE	Ignition Harness
IGNITION WIRE	WHITE/YELLOW	Ignition Harness
SECOND IGNITION WIRE	PINK/BLACK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE (When installing a remote start system, this wire must be powered as an accessory. If powered as a 2nd ignition the gauges will not function properly.)	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door Harness
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door Harness
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
TRUNK TRIGGER (-)	BROWN/WHITE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
TACHOMETER WIRE	GREEN/WHITE or GREEN/YELLOW	Ignition Coil On Front Of Engine On Driver's Side
BRAKE WIRE (+)	RED/LT.GREEN	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with the PATS (passive anti-theft system) security system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2001 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED/LT.BLUE	Ignition Harness
IGNITION WIRE	WHITE/YELLOW	Ignition Harness
SECOND IGNITION WIRE	PINK/BLACK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE (When installing a remote start system, this wire must be powered as an accessory. If powered as a 2nd ignition the gauges will not function properly.)	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door Harness
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door Harness
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
TRUNK TRIGGER (-)	BROWN/WHITE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
TACHOMETER WIRE	GREEN/WHITE or GREEN/YELLOW	Ignition Coil On Front Of Engine On Driver's Side
BRAKE WIRE (+)	RED/LT.GREEN	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with the PATS (passive anti-theft system) security system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2002 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED/LT.BLUE	Ignition Harness
IGNITION WIRE	WHITE/YELLOW	Ignition Harness
SECOND IGNITION WIRE	PINK/BLACK	Ignition Harness
ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
SECOND ACCESSORY WIRE (When installing a remote start system, this wire must be powered as an accessory. If powered as a 2nd ignition the gauges will not function properly.)	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door Harness
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door Harness
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
TRUNK TRIGGER (-)	BROWN/WHITE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
TACHOMETER WIRE	GREEN/WHITE or GREEN/YELLOW	Ignition Coil On Front Of Engine On Driver's Side
BRAKE WIRE (+)	RED/LT.GREEN	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with the PATS (passive anti-theft system) security system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2003 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED/LT.BLUE	Ignition Harness
IGNITION WIRE	WHITE/YELLOW	Ignition Harness
ACCESSORY WIRE	PINK/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	GRAY/YELLOW	Ignition Harness
THIRD ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door Harness
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door Harness
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
TRUNK TRIGGER (-)	WHITE/PURPLE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
FACTORY ALARM ARM (-)	LT.GREEN/BLACK	Module Under Dash On Right Side Of Steering Column
FACTORY ALARM DISARM (-)	LT.BLUE/BLACK	Module Under Dash On Right Side Of Steering Column
TACHOMETER WIRE	NOT RED or RED/LT.GREEN	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN.BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2004 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED/LT.BLUE	Ignition Harness
IGNITION WIRE	WHITE/YELLOW	Ignition Harness
ACCESSORY WIRE	PINK/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	GRAY/YELLOW	Ignition Harness
THIRD ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door Harness
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door Harness
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
TRUNK TRIGGER (-)	WHITE/PURPLE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
FACTORY ALARM ARM (-)	LT.GREEN/BLACK	Module Under Dash On Right Side Of Steering Column
FACTORY ALARM DISARM (-)	LT.BLUE/BLACK	Module Under Dash On Right Side Of Steering Column
TACHOMETER WIRE	NOT RED or RED/LT.GREEN	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN.BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	PURPLE/ORANGE	Ignition Harness
ACCESSORY WIRE	GRAY/YELLOW or WHITE/LT.BLUE	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/PURPLE	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
DOMELIGHT SUPERVISION (+)	BLACK/LT.BLUE	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	WHITE/PURPLE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
FACTORY ALARM ARM (-)	LT.GREEN/BLACK	Module Under Dash On Right Side Of Steering Column
FACTORY ALARM DISARM (-)	LT.BLUE/BLACK	Module Under Dash On Right Side Of Steering Column
TACHOMETER WIRE	NOT RED or WHITE/RED	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN/RED	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN.BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door

This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.

WIRING INFORMATION: 2006 Lincoln Town Car

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	YELLOW & LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED	Ignition Harness
IGNITION WIRE	PURPLE/ORANGE	Ignition Harness
ACCESSORY WIRE	GRAY/YELLOW or WHITE/LT.BLUE	Ignition Harness
SECOND ACCESSORY WIRE	WHITE/PURPLE	Ignition Harness
POWER DOOR LOCK (+)	PINK/YELLOW	Harness Coming From Driver's Door
POWER DOOR UNLOCK (+)	PINK/GREEN	Harness Coming From Driver's Door
PARKING LIGHTS (+)	BROWN	Module Under Dash On Right Side Of Steering Column
DRIVER DOOR TRIGGER (-)	BLUE	Driver's door module located just below the mirror in the driver's door
PASSENGER DOORS TRIGGER (-)	BLACK/ORANGE	Driver's door module located just below the mirror in the driver's door
DOMELIGHT SUPERVISION (+)	BLACK/LT.BLUE	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	WHITE/PURPLE	Module Under Dash On Right Side Of Steering Column
TRUNK RELEASE (5-wire)	RED	Lower Harness in Driver's Kick Panel
FACTORY ALARM ARM (-)	LT.GREEN/BLACK	Module Under Dash On Right Side Of Steering Column
FACTORY ALARM DISARM (-)	LT.BLUE/BLACK	Module Under Dash On Right Side Of Steering Column
TACHOMETER WIRE	NOT RED or WHITE/RED	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN/RED	Module Under Dash On Right Side Of Steering Column
HORN TRIGGER (-)	DK.BLUE	Module Under Dash On Right Side Of Steering Column
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN.BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door

This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.