

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	BLACK/BLUE	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or GREEN/YELLOW	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	WHITE/LT, GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	RED/WHITE or WHITE	At Under Dash Light
POWER DOOR LOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
POWER DOOR UNLOCK	Must add actuator in doors	
Notes: Refer to TechDoc 3961		
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/WHITE	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"			
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7505, SCOSCHE FM2157B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE 1	WHITE/BLACK	Ignition Harness
IGNITION WIRE 1	RED/BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	GREEN/RED	Ignition Harness
TACHOMETER	BROWN or BROWN/YELLOW	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	LT.GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	WHITE/RED	Harness In Driver's Kick Panel
POWER DOOR LOCK	Must add actuator in driver door	

Notes: Refer to TechDoc 3961

POWER DOOR UNLOCK	Must add actuator in driver door	
-------------------	----------------------------------	--

Notes: Refer to TechDoc 3961

LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/BLACK	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
POWER ANTENNA (+)	GRAY/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	At Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7505, SCOSCHE FM2157B	METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE 1	WHITE/BLACK	Ignition Harness
IGNITION WIRE 1	RED/BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	GREEN/RED	Ignition Harness
TACHOMETER	BROWN or BROWN/YELLOW	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	LT.GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPER	WHITE/RED	Harness In Driver's Kick Panel
POWER DOOR LOCK	Must add actuator in driver door	

Notes: Refer to TechDoc 3961

POWER DOOR UNLOCK	Must add actuator in driver door	
-------------------	----------------------------------	--

Notes: Refer to TechDoc 3961

LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/BLACK	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
POWER ANTENNA (+)	GRAY/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	At Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7505, SCOSCHE FM2157B	METRA 70-7901, SCOSCHE MA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE 1	WHITE/BLACK	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	GREEN/ORANGE	At Data Connector At Rear Left Of Engine Bay
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	LT.GREEN	Harness At Steering Column
ALL DOOR TRIGGER (-)	WHITE/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light in Trunk
POWER DOOR LOCK	PURPLE	At Module Under Driver's Side Dash
Notes: Negative trigger through a 1000-ohm resistor		
POWER DOOR UNLOCK (-)	Same wire as lock	
TRUNK RELEASE (-)	RED/WHITE	Module Behind Glove Box
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	WHITE/RED	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/BLACK	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
POWER ANTENNA (+)	GRAY/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	At Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7505, SCOSCHE FM2157B	METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE 1	WHITE/BLACK	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	GREEN/ORANGE	At Data Connector At Rear Left Of Engine Bay
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	LT.GREEN	Harness At Steering Column
ALL DOOR TRIGGER (-)	WHITE/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light in Trunk
POWER DOOR LOCK	PURPLE	At Module Under Driver's Side Dash
Notes: Negative trigger through a 1000-ohm resistor		
POWER DOOR UNLOCK (-)	Same wire as lock	
TRUNK RELEASE (-)	RED/WHITE	Module Behind Glove Box
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	WHITE/RED	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/BLACK	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
POWER ANTENNA (+)	GRAY/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	At Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7505	METRA 70-7903, SCOSCHE MA03B	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE 1	WHITE/BLACK	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	GREEN/ORANGE	At Data Connector At Rear Left Of Engine Bay
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	LT.GREEN	Harness At Steering Column
ALL DOOR TRIGGER (-)	WHITE/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light in Trunk
POWER DOOR LOCK	PURPLE	At Module Under Driver's Side Dash
Notes: Negative trigger through a 1000-ohm resistor		
POWER DOOR UNLOCK (-)	Same wire as lock	
TRUNK RELEASE (-)	RED/WHITE	Module Behind Glove Box
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	WHITE/RED	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/BLACK	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
POWER ANTENNA (+)	GRAY/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	At Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7505	METRA 70-7903, SCOSCHE MA03B	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE 1	WHITE/BLACK	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	GREEN/ORANGE	At Data Connector At Rear Left Of Engine Bay
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	LT.GREEN	Harness At Steering Column
ALL DOOR TRIGGER (-)	WHITE/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light in Trunk
POWER DOOR LOCK	PURPLE	At Module Under Driver's Side Dash
Notes: Negative trigger through a 1000-ohm resistor		
POWER DOOR UNLOCK (-)	Same wire as lock	
TRUNK RELEASE (-)	RED/WHITE	Module Behind Glove Box
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	WHITE/RED	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/BLACK	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
POWER ANTENNA (+)	GRAY/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	At Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7505	METRA 70-7903, SCOSCHE MA03B	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE 1	WHITE/BLACK	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLACK/WHITE	Ignition Harness
TACHOMETER	GREEN/ORANGE	At Data Connector At Rear Left Of Engine Bay
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	RED/BLACK	Rear Of Dimmer Switch
PARKING LIGHTS (-)	LT.GREEN	Harness At Steering Column
ALL DOOR TRIGGER (-)	WHITE/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	RED/WHITE	At Light in Trunk
POWER DOOR LOCK	PURPLE	At Module Under Driver's Side Dash
Notes: Negative trigger through a 1000-ohm resistor		
POWER DOOR UNLOCK (-)	Same wire as lock	
TRUNK RELEASE (-)	RED/WHITE	Module Behind Glove Box
LEFT FRONT WINDOW UP	GREEN/RED	In Center Console
LEFT FRONT WINDOW DOWN	WHITE/RED	In Center Console
RIGHT FRONT WINDOW UP	RED/BLACK	In Center Console
RIGHT FRONT WINDOW DOWN	RED/GREEN	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	BLUE/BLACK	At Radio Harness	
RADIO GROUND		Not in Radio Harness	
ILLUMINATION (+)	RED/BLACK	At Radio Harness	
POWER ANTENNA (+)	GRAY/BLACK	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	WHITE	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	At Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7505	METRA 70-7903, SCOSCHE MA03B	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE 1	WHITE/BLUE	Ignition Harness
IGNITION WIRE 1	GREEN/WHITE	Ignition Harness
ACCESSORY WIRE 1	PINK/BLACK	Ignition Harness
ACCESSORY WIRE 2	WHITE/RED	Ignition Harness
FACTORY ALARM ARM/DISARM	GRAY/RED	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to arm and disarm the factory alarm. Arm is a negative trigger through a 1000-ohm resistor. Disarm is a negative trigger. Relays must be used. Test the arm/disarm wire by turning the key in the driver door.		
TACHOMETER	NOT BLACK/WHITE, BLACK, WHITE/BLUE	Any Fuel Injector
BRAKE WIRE (+)	BLACK/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	BLACK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BROWN/BLACK	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/BLUE	In Driver's "A" Pillar
TRUNK TRIGGER (-)	ORANGE or BLACK	At Light In Trunk
POWER DOOR LOCK/UNLOCK	BROWN/WHITE	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger through a 1000-ohm resistor. Unlock is a negative trigger. Relays must be used.		
TRUNK RELEASE (-)	PURPLE	At Switch
LEFT FRONT WINDOW UP	RED/WHITE	In Center Console
LEFT FRONT WINDOW DOWN	RED/GREEN	In Center Console
RIGHT FRONT WINDOW UP	GREEN/RED	In Center Console
RIGHT FRONT WINDOW DOWN	WHITE/RED	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	RED/BLACK	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
POWER ANTENNA (+)	BLUE	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/BLACK	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
3.5", 8"	3.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7506, SCOSCHE MA1532B		METRA 70-7903, SCOSCHE MA03B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE 1	WHITE/BLUE	Ignition Harness
IGNITION WIRE 1	GREEN/WHITE	Ignition Harness
ACCESSORY WIRE 1	PINK/BLACK	Ignition Harness
ACCESSORY WIRE 2	WHITE/RED	Ignition Harness
FACTORY ALARM ARM/DISARM	GRAY/RED	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to arm and disarm the factory alarm. Arm is a negative trigger through a 1000-ohm resistor. Disarm is a negative trigger. Relays must be used. Test the arm/disarm wire by turning the key in the driver door.		
TACHOMETER	NOT BLACK/WHITE, BLACK, WHITE/BLUE	Any Fuel Injector
BRAKE WIRE (+)	BLACK/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	BLACK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BROWN/BLACK	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/BLUE	In Driver's "A" Pillar
TRUNK TRIGGER (-)	ORANGE or BLACK	At Light In Trunk
POWER DOOR LOCK/UNLOCK	BROWN/WHITE	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger through a 1000-ohm resistor. Unlock is a negative trigger. Relays must be used.		
TRUNK RELEASE (-)	PURPLE	At Switch
LEFT FRONT WINDOW UP	RED/WHITE	In Center Console
LEFT FRONT WINDOW DOWN	RED/GREEN	In Center Console
RIGHT FRONT WINDOW UP	GREEN/RED	In Center Console
RIGHT FRONT WINDOW DOWN	WHITE/RED	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	RED/BLACK	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
POWER ANTENNA (+)	BLUE	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/BLACK	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
3.5", 8"	3.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7506, SCOSCHE MA1532B		METRA 70-7903, SCOSCHE MA03B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE 1	WHITE/BLUE	Ignition Harness
IGNITION WIRE 1	GREEN/WHITE	Ignition Harness
ACCESSORY WIRE 1	PINK/BLACK	Ignition Harness
ACCESSORY WIRE 2	WHITE/RED	Ignition Harness
FACTORY ALARM ARM/DISARM	GRAY/RED	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to arm and disarm the factory alarm. Arm is a negative trigger through a 1000-ohm resistor. Disarm is a negative trigger. Relays must be used. Test the arm/disarm wire by turning the key in the driver door.		
TACHOMETER	NOT BLACK/WHITE, BLACK, WHITE/BLUE	Any Fuel Injector
BRAKE WIRE (+)	BLACK/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	BLACK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BROWN/BLACK	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/BLUE	In Driver's "A" Pillar
TRUNK TRIGGER (-)	ORANGE or BLACK	At Light In Trunk
POWER DOOR LOCK/UNLOCK	BROWN/WHITE	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger through a 1000-ohm resistor. Unlock is a negative trigger. Relays must be used.		
TRUNK RELEASE (-)	PURPLE	At Switch
LEFT FRONT WINDOW UP	RED/WHITE	In Center Console
LEFT FRONT WINDOW DOWN	RED/GREEN	In Center Console
RIGHT FRONT WINDOW UP	GREEN/RED	In Center Console
RIGHT FRONT WINDOW DOWN	WHITE/RED	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	RED/BLACK	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
POWER ANTENNA (+)	BLUE	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/BLACK	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
3.5", 8"	3.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7506, SCOSCHE MA1532B		METRA 70-7903, SCOSCHE MA03B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE 1	WHITE/BLUE	Ignition Harness
IGNITION WIRE 1	GREEN/WHITE	Ignition Harness
ACCESSORY WIRE 1	PINK/BLACK	Ignition Harness
ACCESSORY WIRE 2	WHITE/RED	Ignition Harness
FACTORY ALARM ARM/DISARM	GRAY/RED	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to arm and disarm the factory alarm. Arm is a negative trigger through a 1000-ohm resistor. Disarm is a negative trigger. Relays must be used. Test the arm/disarm wire by turning the key in the driver door.		
TACHOMETER	NOT BLACK/WHITE, BLACK, WHITE/BLUE	Any Fuel Injector
BRAKE WIRE (+)	BLACK/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	BLACK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BROWN/BLACK	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/BLUE	In Driver's "A" Pillar
TRUNK TRIGGER (-)	ORANGE or BLACK	At Light In Trunk
POWER DOOR LOCK/UNLOCK	BROWN/WHITE	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger through a 1000-ohm resistor. Unlock is a negative trigger. Relays must be used.		
TRUNK RELEASE (-)	PURPLE	At Switch
LEFT FRONT WINDOW UP	RED/WHITE	In Center Console
LEFT FRONT WINDOW DOWN	RED/GREEN	In Center Console
RIGHT FRONT WINDOW UP	GREEN/RED	In Center Console
RIGHT FRONT WINDOW DOWN	WHITE/RED	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	RED/BLACK	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
POWER ANTENNA (+)	BLUE	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/BLACK	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
3.5", 8"	3.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7519B, SCOSCHE MA1532B	METRA 70-7903, SCOSCHE MA03B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
STARTER WIRE 1	WHITE/BLUE	Ignition Harness
IGNITION WIRE 1	GREEN/WHITE	Ignition Harness
ACCESSORY WIRE 1	PINK/BLACK	Ignition Harness
ACCESSORY WIRE 2	WHITE/RED	Ignition Harness
FACTORY ALARM ARM/DISARM	GRAY/RED	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to arm and disarm the factory alarm. Arm is a negative trigger through a 1000-ohm resistor. Disarm is a negative trigger. Relays must be used. Test the arm/disarm wire by turning the key in the driver door.		
TACHOMETER	NOT BLACK/WHITE, BLACK, WHITE/BLUE	Any Fuel Injector
BRAKE WIRE (+)	BLACK/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
PARKING LIGHTS (+)	BLACK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	BROWN/BLACK	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/BLUE	In Driver's "A" Pillar
TRUNK TRIGGER (-)	ORANGE or BLACK	At Light In Trunk
POWER DOOR LOCK/UNLOCK	BROWN/WHITE	At Harness In Driver's Kick Panel Coming From Driver's Door
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger through a 1000-ohm resistor. Unlock is a negative trigger. Relays must be used.		
TRUNK RELEASE (-)	PURPLE	At Switch
LEFT FRONT WINDOW UP	RED/WHITE	In Center Console
LEFT FRONT WINDOW DOWN	RED/GREEN	In Center Console
RIGHT FRONT WINDOW UP	GREEN/RED	In Center Console
RIGHT FRONT WINDOW DOWN	WHITE/RED	In Center Console

INTERFACE	PART NUMBER	NOTES
Door Lock Interface	DEI 456LW	Optional when interfacing with door locks
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	At Radio Harness	
12V SWITCHED	RED/BLACK	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
POWER ANTENNA (+)	BLUE	At Radio Harness	
LEFT FRONT SPEAKER (+)	RED	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/BLACK	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BLUE/RED	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/WHITE	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
3.5", 8"	3.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7519B, SCOSCHE MA1532B		METRA 70-7903, SCOSCHE MA03B	Not required
Please verify all part numbers before ordering.			