

TRIPLE S *Customs*

MAZDA MILLENIA 1994-2002 VEHICLE WIRING

WIRING INFORMATION 1994 Mazda Millennia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1995 Mazda Millennia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1996 Mazda Millennia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW or ORANGE	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1997 Mazda Millennia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW or ORANGE	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1998 Mazda Millennia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW or ORANGE	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door
This vehicle is equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 1999 Mazda Millenia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW or ORANGE	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN or RED/YELLOW	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door
This vehicle is equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2000 Mazda Millennia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW or ORANGE	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN or RED/YELLOW	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door
This vehicle is equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2001 Mazda Millennia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW or ORANGE	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN or RED/YELLOW	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door
This vehicle is equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION 2002 Mazda Millennia

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/BLUE or GREEN	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND 12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK (negative trigger through a 1000 ohm resistor) ** Test using the passengers door key cylinder switch with all doors closed**	BLUE/YELLOW or ORANGE	Harness Coming Into Vehicle From Passenger Door
POWER DOOR UNLOCK (negative trigger) ** Test using the passengers door key cylinder switch with all doors closed**	Same wire as lock	
PARKING LIGHTS (+)	ORANGE	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	LIGHT GREEN or RED/YELLOW	Harness At Steering Column
DOOR TRIGGER/DOME LIGHT SUPERVISION (-)	LT GREEN	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BROWN/WHITE	Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM ARM		Arms With Lock
FACTORY ALARM DISARM		Disarms With Unlock
FACTORY ALARM DISARM NO UNLOCK (-)	LT. GREEN/RED	Harness Coming Into Vehicle From Driver's Door
TACHOMETER	YELLOW or GRN/BLUE	Connector In Driver Rear Corner Of Engine Bay
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	WHITE/RED	Harness In Driver's Kick From Driver Door
This vehicle is equipped with an Immobilizer system. This must be bypassed when installing a remote start system.		