

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	At Head Light Switch
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Driver's Running Board OR At Factory Anti-theft Module Behind Glove Box
REAR HATCH TRIGGER (-)	GREEN	At Light In Trunk OR At Factory Anti-theft Module Behind Glove Box
HOOD TRIGGER (-)	BROWN/WHITE	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM ARM (-)	GREEN/RED	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM DISARM (-)	LT. GREEN/BLACK	At Factory Anti-theft Module Behind Glove Box
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN or YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	RED/BLACK	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)	BLUE/YELLOW	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	At Head Light Switch
DOOR TRIGGER (-)	BLUE/WHITE	At Factory Anti-theft Module Behind Glove Box
REAR HATCH TRIGGER (-)	GREEN	At Factory Anti-theft Module Behind Glove Box
HOOD TRIGGER (-)	BROWN/WHITE	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM ARM (-)	GREEN/RED	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM DISARM (-)	LT. GREEN/BLACK	At Factory Anti-theft Module Behind Glove Box
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN or YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	RED/BLACK	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)	BLUE/YELLOW	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	At Head Light Switch
DOOR TRIGGER (-)	BLUE/WHITE	At Factory Anti-theft Module Behind Glove Box
REAR HATCH TRIGGER (-)	GREEN	At Factory Anti-theft Module Behind Glove Box
HOOD TRIGGER (-)	BROWN/WHITE	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM ARM (-)	GREEN/RED	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM DISARM (-)	LT. GREEN/BLACK	At Factory Anti-theft Module Behind Glove Box
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN or YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	RED/BLACK	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	BLUE/WHITE	Radio Harness	
POWER ANTENNA (+)	BLUE/YELLOW	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK	MUST ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
POWER DOOR UNLOCK	MUST ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
DOOR TRIGGER (-)	BLUE/WHITE	Module Under Driver's Dash Near Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module Under Driver's Dash Near Kick Panel
HOOD TRIGGER (-)	BROWN/WHITE	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM ARM (-)	GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM DISARM (-)	LT. GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK	MUST ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
POWER DOOR UNLOCK	MUST ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
DOOR TRIGGER (-)	BLUE/WHITE	Module Under Driver's Dash Near Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module Under Driver's Dash Near Kick Panel
HOOD TRIGGER (-)	BROWN/WHITE	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM ARM (-)	GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM DISARM (-)	LT. GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK	MUST ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
POWER DOOR UNLOCK	MUST ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
DOOR TRIGGER (-)	BLUE/WHITE	Module Under Driver's Dash Near Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module Under Driver's Dash Near Kick Panel
HOOD TRIGGER (-)	BROWN/WHITE	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM ARM (-)	GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM DISARM (-)	LT. GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK	MUST ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
POWER DOOR UNLOCK	MUST ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
DOOR TRIGGER (-)	BLUE/WHITE	Module Under Driver's Dash Near Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module Under Driver's Dash Near Kick Panel
HOOD TRIGGER (-)	BROWN/WHITE	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM ARM (-)	GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM DISARM (-)	LT. GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7501, SCOSCHE MA1530B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/GREEN	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK	ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
POWER DOOR UNLOCK	ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
PARKING LIGHTS +	RED/BLACK	Harness A Fuse Box
PARKING LIGHTS (-)	GRAY	Harness At Steering Column
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Passenger Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module In Driver's Kick Panel
HOOD TRIGGER (-)	BROWN/YELLOW	Module In Driver's Kick Panel
FACTORY ALARM ARM (-)	DK.GREEN/BLACK	Harness In Drivers Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN/BLACK or YELLOW/RED	Harness In Drivers Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	At Ignition coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column or Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE FM2157B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/GREEN	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK	ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
POWER DOOR UNLOCK	ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
PARKING LIGHTS +	RED/BLACK	Harness A Fuse Box
PARKING LIGHTS (-)	GRAY	Harness At Steering Column
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Passenger Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module In Driver's Kick Panel
HOOD TRIGGER (-)	BROWN/YELLOW	Module In Driver's Kick Panel
FACTORY ALARM ARM (-)	DK.GREEN/BLACK	Harness In Drivers Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN/BLACK or YELLOW/RED	Harness In Drivers Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	At Ignition coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column or Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE FM2157B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/GREEN	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK	ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
POWER DOOR UNLOCK	ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
PARKING LIGHTS +	RED/BLACK	Harness A Fuse Box
PARKING LIGHTS (-)	GRAY	Harness At Steering Column
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Passenger Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module In Driver's Kick Panel
HOOD TRIGGER (-)	BROWN/YELLOW	Module In Driver's Kick Panel
FACTORY ALARM ARM (-)	DK.GREEN/BLACK	Harness In Drivers Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN/BLACK or YELLOW/RED	Harness In Drivers Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	At Ignition coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column or Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE FM2157B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/GREEN	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK	ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
POWER DOOR UNLOCK	ADD ACTUATOR	In Drivers Door
<b>Notes:</b> Refer to TechDoc 3961		
PARKING LIGHTS +	RED/BLACK	Harness A Fuse Box
PARKING LIGHTS (-)	GRAY	Harness At Steering Column
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Passenger Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module In Driver's Kick Panel
HOOD TRIGGER (-)	BROWN/YELLOW	Module In Driver's Kick Panel
FACTORY ALARM ARM (-)	DK.GREEN/BLACK	Harness In Drivers Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN/BLACK or YELLOW/RED	Harness In Drivers Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	At Ignition coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column or Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/RED	Radio Harness	
RADIO SWITCHED	BLUE/WHITE	Radio Harness	
RADIO GROUND		Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE FM2157B		METRA 70-7901, SCOSCHE MA02B	Not required
Please verify all part numbers before ordering.			