

TRIPLE S *Customs*

MAZDA RX-7 1986-1996 VEHICLE WIRING

WIRING INFORMATION: 1986 Mazda RX-7 without factory alarm

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/GREEN	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	At Headlight Switch
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Driver's Running Board
REAR HATCH TRIGGER (-)	GREEN	At Light In Trunk
TACHOMETER WIRE	YELLOW/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1986 Mazda RX-7 with factory alarm

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	At Head Light Switch
DOOR TRIGGER (-)	BLUE/WHITE	At Factory Anti-theft Module Behind Glove Box
REAR HATCH TRIGGER (-)	GREEN	At Factory Anti-theft Module Behind Glove Box
HOOD TRIGGER (-)	BROWN/WHITE	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM ARM (-)	GREEN/RED	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM DISARM (-)	LT. GREEN/BLACK	At Factory Anti-theft Module Behind Glove Box
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN or YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1987 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	At Head Light Switch
DOOR TRIGGER (-)	BLUE/WHITE	At Factory Anti-theft Module Behind Glove Box
REAR HATCH TRIGGER (-)	GREEN	At Factory Anti-theft Module Behind Glove Box
HOOD TRIGGER (-)	BROWN/WHITE	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM ARM (-)	GREEN/RED	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM DISARM (-)	LT. GREEN/BLACK	At Factory Anti-theft Module Behind Glove Box
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN or YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1988 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	At Head Light Switch
DOOR TRIGGER (-)	BLUE/WHITE	At Factory Anti-theft Module Behind Glove Box
REAR HATCH TRIGGER (-)	GREEN	At Factory Anti-theft Module Behind Glove Box
HOOD TRIGGER (-)	BROWN/WHITE	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM ARM (-)	GREEN/RED	At Factory Anti-theft Module Behind Glove Box
FACTORY ALARM DISARM (-)	LT. GREEN/BLACK	At Factory Anti-theft Module Behind Glove Box
TACHOMETER WIRE	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN or YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1989 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK	MUST ADD ACTUATOR	In Drivers Door
POWER DOOR UNLOCK	MUST ADD ACTUATOR	In Drivers Door
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
DOOR TRIGGER (-)	BLUE/WHITE	Module Under Driver's Dash Near Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module Under Driver's Dash Near Kick Panel
HOOD TRIGGER (-)	BROWN/WHITE	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM ARM (-)	GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM DISARM (-)	LT. GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

The CPU is located in drivers under dash near the kick panel.

WIRING INFORMATION: 1990 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK	MUST ADD ACTUATOR	In Drivers Door
POWER DOOR UNLOCK	MUST ADD ACTUATOR	In Drivers Door
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
DOOR TRIGGER (-)	BLUE/WHITE	Module Under Driver's Dash Near Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module Under Driver's Dash Near Kick Panel
HOOD TRIGGER (-)	BROWN/WHITE	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM ARM (-)	GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM DISARM (-)	LT. GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
The CPU is located in drivers under dash near the kick panel.		

WIRING INFORMATION: 1991 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK	MUST ADD ACTUATOR	In Drivers Door
POWER DOOR UNLOCK	MUST ADD ACTUATOR	In Drivers Door
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
DOOR TRIGGER (-)	BLUE/WHITE	Module Under Driver's Dash Near Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module Under Driver's Dash Near Kick Panel
HOOD TRIGGER (-)	BROWN/WHITE	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM ARM (-)	GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM DISARM (-)	LT. GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
The CPU is located in drivers under dash near the kick panel.		

WIRING INFORMATION: 1992 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
POWER DOOR LOCK	MUST ADD ACTUATOR	In Drivers Door
POWER DOOR UNLOCK	MUST ADD ACTUATOR	In Drivers Door
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
DOOR TRIGGER (-)	BLUE/WHITE	Module Under Driver's Dash Near Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module Under Driver's Dash Near Kick Panel
HOOD TRIGGER (-)	BROWN/WHITE	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM ARM (-)	GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
FACTRY ALARM DISARM (-)	LT. GREEN/BLACK	Module Under Driver's Dash Near Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
The CPU is located in drivers under dash near the kick panel.		

WIRING INFORMATION: 1993 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/GREEN	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK	ADD ACTUATOR	In Drivers Door
POWER DOOR UNLOCK	ADD ACTUATOR	In Drivers Door
PARKING LIGHTS +	RED/BLACK	Harness A Fuse Box
PARKING LIGHTS (-)	GRAY	Harness At Steering Column
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Passenger Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module In Driver's Kick Panel
HOOD TRIGGER (-)	BROWN/YELLOW	Module In Driver's Kick Panel
FACTORY ALARM ARM (-)	DK.GREEN/BLACK	Harness In Drivers Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN/BLACK or YELLOW/RED	Harness In Drivers Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	At Ignition coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column or Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1994 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/GREEN	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK	ADD ACTUATOR	In Drivers Door
POWER DOOR UNLOCK	ADD ACTUATOR	In Drivers Door
PARKING LIGHTS +	RED/BLACK	Harness A Fuse Box
PARKING LIGHTS (-)	GRAY	Harness At Steering Column
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Passenger Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module In Driver's Kick Panel
HOOD TRIGGER (-)	BROWN/YELLOW	Module In Driver's Kick Panel
FACTORY ALARM ARM (-)	DK.GREEN/BLACK	Harness In Drivers Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN/BLACK or YELLOW/RED	Harness In Drivers Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	At Ignition coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column or Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1995 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/GREEN	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK	ADD ACTUATOR	In Drivers Door
POWER DOOR UNLOCK	ADD ACTUATOR	In Drivers Door
PARKING LIGHTS +	RED/BLACK	Harness A Fuse Box
PARKING LIGHTS (-)	GRAY	Harness At Steering Column
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Passenger Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module In Driver's Kick Panel
HOOD TRIGGER (-)	BROWN/YELLOW	Module In Driver's Kick Panel
FACTORY ALARM ARM (-)	DK.GREEN/BLACK	Harness In Drivers Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN/BLACK or YELLOW/RED	Harness In Drivers Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	At Ignition coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column or Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1996 Mazda RX-7

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/GREEN	Ignition Harness
STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK	ADD ACTUATOR	In Drivers Door
POWER DOOR UNLOCK	ADD ACTUATOR	In Drivers Door
PARKING LIGHTS +	RED/BLACK	Harness A Fuse Box
PARKING LIGHTS (-)	GRAY	Harness At Steering Column
DOOR TRIGGER (-)	BLUE/WHITE	Harness In Passenger Kick Panel
REAR HATCH TRIGGER (-)	GRAY	Module In Driver's Kick Panel
HOOD TRIGGER (-)	BROWN/YELLOW	Module In Driver's Kick Panel
FACTORY ALARM ARM (-)	DK.GREEN/BLACK	Harness In Drivers Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN/BLACK or YELLOW/RED	Harness In Drivers Kick Panel
TACHOMETER WIRE	YELLOW/BLUE	At Ignition coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/ORANGE	Harness At Steering Column or Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLACK/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door