

TRIPLE S *Customs*

**MERCEDES BENZ 300E 1989-1993
VEHICLE WIRING**

WIRING INFORMATION: 1989 Mercedes Benz 300E

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	PURPLE	Ignition harness
12V IGNITION WIRE	PINK/RED	Ignition harness
ACCESSORY WIRE	PINK/YELLOW	Ignition harness
SECOND ACCESSORY WIRE	PINK/GREEN	Ignition harness
POWER DOOR LOCK (Vacuum Locks)	BLUE or GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vacuum Lock)	Same wire as lock	
PARKING LIGHTS (+)	GRAY/WHITE (left) GRAY (right)	At Light Switch Or OEM Alarm Under Passenger Footwell
DOOR TRIGGER (-)	BROWN/GRAY and BROWN/GRAY/BLACK	At Right Front Door Pin And Rear Pin Or OEM Alarm
TRUNK TRIGGER (-)	BLACK/YELLOW	OEM Alarm
TACHOMETER WIRE	BLACK	At Ignition Coil On Driver's Side Fender
BRAKE WIRE (+)	BLACK/RED/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/YELLOW/PINK	At Steering Harness
FACTORY ALARM ARM (-)	YELLOW/BLUE or YELLOW/GREEN	OEM Alarm
FACTORY ALARM DISARM (-)	GREEN/YELLOW	OEM Alarm
LEFT FRONT WINDOW UP	BLACK	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	BLACK/WHITE	In Center Console
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Center Console
LEFT REAR WINDOW UP	BLACK/PINK	In Center Console
LEFT REAR WINDOW DOWN	GREEN/BLACK	In Center Console
RIGHT REAR WINDOW UP	BLUE/WHITE	In Center Console
RIGHT REAR WINDOW DOWN	GREEN/RED	In Center Console

WIRING INFORMATION: 1990 Mercedes Benz 300E

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	PURPLE	Ignition harness
12V IGNITION WIRE	PINK/RED	Ignition harness
ACCESSORY WIRE	PINK/YELLOW	Ignition harness
SECOND ACCESSORY WIRE	PINK/GREEN	Ignition harness
POWER DOOR LOCK (Vacuum Locks)	BLUE or GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vacuum Lock)	Same wire as lock	
PARKING LIGHTS (+)	GRAY/WHITE (left) GRAY (right)	At Light Switch Or OEM Alarm Under Passenger Footwell
DOOR TRIGGER (-)	BROWN/GRAY and BROWN/GRAY/BLACK	At Right Front Door Pin And Rear Pin Or OEM Alarm
TRUNK TRIGGER (-)	BLACK/YELLOW	OEM Alarm
TACHOMETER WIRE	BLACK	At Ignition Coil On Driver's Side Fender
BRAKE WIRE (+)	BLACK/RED/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/YELLOW/PINK	At Steering Harness
FACTORY ALARM ARM (-)	YELLOW/BLUE or YELLOW/GREEN	OEM Alarm
FACTORY ALARM DISARM (-)	GREEN/YELLOW	OEM Alarm
LEFT FRONT WINDOW UP	BLACK	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	BLACK/WHITE	In Center Console
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Center Console
LEFT REAR WINDOW UP	BLACK/PINK	In Center Console
LEFT REAR WINDOW DOWN	GREEN/BLACK	In Center Console
RIGHT REAR WINDOW UP	BLUE/WHITE	In Center Console
RIGHT REAR WINDOW DOWN	GREEN/RED	In Center Console

WIRING INFORMATION: 1991 Mercedes Benz 300E

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	PURPLE	Ignition harness
12V IGNITION WIRE	PINK/RED	Ignition harness
ACCESSORY WIRE	PINK/YELLOW	Ignition harness
SECOND ACCESSORY WIRE	PINK/GREEN	Ignition harness
POWER DOOR LOCK (Vacuum Locks)	BLUE or GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vacuum Lock)	Same wire as lock	
PARKING LIGHTS (+)	GRAY/WHITE (left) GRAY (right)	At Light Switch Or OEM Alarm Under Passenger Footwell
DOOR TRIGGER (-)	BROWN/GRAY and BROWN/GRAY/BLACK	At Right Front Door Pin And Rear Pin Or OEM Alarm
TRUNK TRIGGER (-)	BLACK/YELLOW	OEM Alarm
TACHOMETER WIRE	BLACK	At Ignition Coil On Driver's Side Fender
BRAKE WIRE (+)	BLACK/RED/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/YELLOW/PINK	At Steering Harness
FACTORY ALARM ARM (-)	YELLOW/BLUE or YELLOW/GREEN	OEM Alarm
FACTORY ALARM DISARM (-)	GREEN/YELLOW	OEM Alarm
LEFT FRONT WINDOW UP	BLACK	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	BLACK/WHITE	In Center Console
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Center Console
LEFT REAR WINDOW UP	BLACK/PINK	In Center Console
LEFT REAR WINDOW DOWN	GREEN/BLACK	In Center Console
RIGHT REAR WINDOW UP	BLUE/WHITE	In Center Console
RIGHT REAR WINDOW DOWN	GREEN/RED	In Center Console

WIRING INFORMATION: 1992 Mercedes Benz 300E

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	PURPLE	Ignition harness
12V IGNITION WIRE	PINK/RED	Ignition harness
ACCESSORY WIRE	PINK/YELLOW	Ignition harness
SECOND ACCESSORY WIRE	PINK/GREEN	Ignition harness
POWER DOOR LOCK (Vacuum Locks)	BLUE or GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vacuum Lock)	Same wire as lock	
PARKING LIGHTS (+)	GRAY/WHITE (left) GRAY (right)	At Light Switch Or OEM Alarm Under Passenger Footwell
DOOR TRIGGER (-)	BROWN/GRAY and BROWN/GRAY/BLACK	At Right Front Door Pin And Rear Pin Or OEM Alarm
TRUNK TRIGGER (-)	BLACK/YELLOW	OEM Alarm
TACHOMETER WIRE	BLACK	At Ignition Coil On Driver's Side Fender
BRAKE WIRE (+)	BLACK/RED/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/YELLOW/PINK	At Steering Harness
FACTORY ALARM ARM (-)	YELLOW/BLUE or YELLOW/GREEN	OEM Alarm
FACTORY ALARM DISARM (-)	GREEN/YELLOW	OEM Alarm
LEFT FRONT WINDOW UP	BLACK	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	BLACK/WHITE	In Center Console
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Center Console
LEFT REAR WINDOW UP	BLACK/PINK	In Center Console
LEFT REAR WINDOW DOWN	GREEN/BLACK	In Center Console
RIGHT REAR WINDOW UP	BLUE/WHITE	In Center Console
RIGHT REAR WINDOW DOWN	GREEN/RED	In Center Console

WIRING INFORMATION: 1993 Mercedes Benz 300E

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	PURPLE	Ignition harness
12V IGNITION WIRE	PINK/RED	Ignition harness
ACCESSORY WIRE	PINK/YELLOW	Ignition harness
SECOND ACCESSORY WIRE	PINK/GREEN	Ignition harness
POWER DOOR LOCK (Vacuum Locks)	BLUE or GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vacuum Lock)	Same wire as lock	
PARKING LIGHTS (+)	GRAY/WHITE (left) GRAY (right)	At Light Switch Or OEM Alarm Under Passenger Footwell
DOOR TRIGGER (-)	BROWN/GRAY and BROWN/GRAY/BLACK	At Right Front Door Pin And Rear Pin Or OEM Alarm
TRUNK TRIGGER (-)	BLACK/YELLOW	OEM Alarm
TACHOMETER WIRE	BLACK	At Ignition Coil On Driver's Side Fender
BRAKE WIRE (+)	BLACK/RED/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/YELLOW/PINK	At Steering Harness
FACTORY ALARM ARM (-)	YELLOW/BLUE or YELLOW/GREEN	OEM Alarm
FACTORY ALARM DISARM (-)	GREEN/YELLOW	OEM Alarm
LEFT FRONT WINDOW UP	BLACK	In Center Console
LEFT FRONT WINDOW DOWN	GREEN	In Center Console
RIGHT FRONT WINDOW UP	BLACK/WHITE	In Center Console
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	In Center Console
LEFT REAR WINDOW UP	BLACK/PINK	In Center Console
LEFT REAR WINDOW DOWN	GREEN/BLACK	In Center Console
RIGHT REAR WINDOW UP	BLUE/WHITE	In Center Console
RIGHT REAR WINDOW DOWN	GREEN/RED	In Center Console