

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
SECOND IGNITION	BLACK/RED	Ignition Harness
STARTER	BLACK/YELLOW	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
POWER DOOR LOCK	Must add actuator in driver's door	
POWER DOOR UNLOCK	Must add actuator in driver's door	
LEFT DOOR TRIGGER (-)	RED/BLUE	At Fuse Box
RIGHT DOOR TRIGGER (-)	RED/YELLOW	At Fuse Box
TRUNK TRIGGER (-)	BLUE/RED	At Light In Trunk
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	GREEN/YELLOW	Radio	
RADIO SWITCHED	ORANGE/BLACK	Radio	
RADIO GROUND	RED	Radio	
ILLUMINATION (+)	N/A	Radio	
LEFT FRONT SPEAKER(+)	ORANGE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	PINK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	PINK/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5x7"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not required		METRA 70-1770, SCOSCHE FD02B/BCB	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
SECOND IGNITION	BLACK/RED	Ignition Harness
STARTER	BLACK/YELLOW	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
POWER DOOR LOCK	Must add actuator in driver's door	
POWER DOOR UNLOCK	Must add actuator in driver's door	
LEFT DOOR TRIGGER (-)	RED/BLUE	At Fuse Box
RIGHT DOOR TRIGGER (-)	RED/YELLOW	At Fuse Box
TRUNK TRIGGER (-)	BLUE/RED	At Light In Trunk
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	GREEN/YELLOW	Radio	
RADIO SWITCHED	ORANGE/BLACK	Radio	
RADIO GROUND	RED	Radio	
ILLUMINATION (+)	N/A	Radio	
LEFT FRONT SPEAKER(+)	ORANGE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	PINK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	PINK/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5x7"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not required		METRA 70-1770, SCOSCHE FD02B/BCB	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
SECOND IGNITION	BLACK/RED	Ignition Harness
STARTER	BLACK/YELLOW	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
POWER DOOR LOCK	Must add actuator in driver's door	
POWER DOOR UNLOCK	Must add actuator in driver's door	
LEFT DOOR TRIGGER (-)	RED/BLUE	At Fuse Box
RIGHT DOOR TRIGGER (-)	RED/YELLOW	At Fuse Box
TRUNK TRIGGER (-)	BLUE/RED	At Light In Trunk
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	GREEN/YELLOW	Radio	
RADIO SWITCHED	ORANGE/BLACK	Radio	
RADIO GROUND	RED	Radio	
ILLUMINATION (+)	N/A	Radio	
LEFT FRONT SPEAKER(+)	ORANGE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	PINK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	PINK/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5x7"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not required		METRA 70-1770, SCOSCHE FD02B/BCB	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
SECOND IGNITION	BLACK/RED	Ignition Harness
STARTER	BLACK/YELLOW	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
PARKING LIGHTS (+)	RED/BLACK	Harness At Fuse Box
POWER DOOR LOCK	Must add actuator in driver's door	
POWER DOOR UNLOCK	Must add actuator in driver's door	
LEFT DOOR TRIGGER (-)	RED/BLUE	At Fuse Box
RIGHT DOOR TRIGGER (-)	RED/YELLOW	At Fuse Box
TRUNK TRIGGER (-)	BLUE/RED	At Light In Trunk
TACHOMETER	YELLOW/BLUE	Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	GREEN/YELLOW	Radio	
RADIO SWITCHED	ORANGE/BLACK	Radio	
RADIO GROUND	RED	Radio	
ILLUMINATION (+)	N/A	Radio	
LEFT FRONT SPEAKER(+)	ORANGE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	PINK/GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	PINK/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5x7"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not required		METRA 70-1770, SCOSCHE FD02B/BCB	Not required
Please verify all part numbers before ordering.			