

TRIPLE S *Customs*

**MERCURY COUGAR 1989-1997 1999-2002
VEHICLE WIRING**

WIRING INFORMATION: 1989 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/LT.BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
ACCESSORY WIRE	GRAY/YELLOW	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
TACHOMETER WIRE	DK.GREEN/YELLOW	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT.GREEN	Steering column
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DK.GREEN/PURPLE	Harness In Driver's Kick Panel
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1990 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/LT.BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
ACCESSORY WIRE	GRAY/YELLOW	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
TACHOMETER WIRE	DK.GREEN/YELLOW	At Ignition Coil
BRAKE WIRE (+)	LT.GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT.GREEN	Steering column
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DK.GREEN/PURPLE	Harness In Driver's Kick Panel
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1991 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/LT.BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
ACCESSORY WIRE	GRAY/YELLOW	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
TACHOMETER WIRE	3.8L supercharged models: TAN/YELLOW 3.8L nonsupercharged: YELLOW/LT.GREEN 5.0L models: PINK	Harness At Rear Of Passenger Strut Tower
BRAKE WIRE (+)	LT.GREEN	Plug At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT.GREEN	Harness At Steering Column
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DK.GREEN/PURPLE	Harness In Driver's Kick panel
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1992 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/LT.BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
ACCESSORY WIRE	GRAY/YELLOW	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
TACHOMETER WIRE	3.8L supercharged models: TAN/YELLOW 3.8L nonsupercharged: YELLOW/LT.GREEN 5.0L models: PINK	Harness At Rear Of Passenger Strut Tower
BRAKE WIRE (+)	LT.GREEN	Plug At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT.GREEN	Harness At Steering Column
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DK.GREEN/PURPLE	Harness In Driver's Kick panel
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1993 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/LT.BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
ACCESSORY WIRE	GRAY/YELLOW	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
TACHOMETER WIRE	3.8L supercharged models: TAN/YELLOW 3.8L nonsupercharged: YELLOW/LT.GREEN 5.0L models: PINK	Harness At Rear Of Passenger Strut Tower
BRAKE WIRE (+)	LT.GREEN	Plug At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/LT.GREEN	Harness At Steering Column
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DK.GREEN/PURPLE	Harness In Driver's Kick panel
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1994 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/GRAY or RED/BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
SECOND IGNITION WIRE	GRAY/YELLOW	Ignition harness
THIRD IGNITION WIRE	GRAY/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLACK/GREEN	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DARK GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	ORANGE/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1995 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/GRAY or RED/BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
SECOND IGNITION WIRE	GRAY/YELLOW	Ignition harness
THIRD IGNITION WIRE	GRAY/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLACK/GREEN	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DARK GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	ORANGE/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1996 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/GRAY or RED/BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
SECOND IGNITION WIRE	GRAY/YELLOW	Ignition harness
THIRD IGNITION WIRE	GRAY/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLACK/GREEN	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DARK GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	BLUE/GREEN	At Ignition Coil
BRAKE WIRE (+)	GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1997 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK/ORANGE	Ignition harness
STARTER WIRE	RED/GRAY or RED/BLUE	Ignition harness
12V IGNITION WIRE	RED/LT.GREEN	Ignition harness
SECOND IGNITION WIRE	GRAY/YELLOW	Ignition harness
THIRD IGNITION WIRE	GRAY/YELLOW	Ignition harness
12V ACCESSORY WIRE	BLACK/GREEN	Ignition harness
POWER DOOR LOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/YELLOW	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (Vehicles with OEM keyless entry: negative trigger, vehicles without OEM keyless entry: 5-wire reverse polarity)	PINK/GREEN	Harness In Driver's Kick panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER (+)	BLACK/BLUE	At Courtesy Light Under Dash
TRUNK RELEASE (+)	PURPLE/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	DARK GREEN/PURPLE	Harness In Driver's Kick Panel
TACHOMETER	BLUE/GREEN	At Ignition Coil
BRAKE WIRE (+)	GREEN/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	TAN/BLUE	Harness In Driver's Kick From Driver Door
Some models are equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 1999 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	GRAY/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Harness In Driver's Kick panel
PARKING LIGHTS (+)	RED/BLUE and RED/YELLOW	At Headlight Switch
<ul style="list-style-type: none"> The parking light wires must be isolated from each other and from the headlight switch to keep the headlights from flashing with the parking lights. 		
DOOR TRIGGER (+)	BLACK/RED and BLACK/GREEN	At Top Of Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	In Driver's Running Board Towards Rear
TRUNK RELEASE (-)	BLACK/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	BLACK/WHITE	Harness In Driver's Kick Panel
TACHOMETER	BROWN/GREEN	At Ignition Coil
BRAKE WIRE (+)	ORANGE/BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	WHITE/PURPLE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/PURPLE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	YELLOW/GREEN	At Window Switch In Driver's Door
Some models are equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2000 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	GRAY/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Harness In Driver's Kick panel
PARKING LIGHTS (+)	RED/BLUE and RED/YELLOW	At Headlight Switch
<ul style="list-style-type: none"> The parking light wires must be isolated from each other and from the headlight switch to keep the headlights from flashing with the parking lights. 		
DOOR TRIGGER (+)	BLACK/RED and BLACK/GREEN	At Top Of Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	In Driver's Running Board Towards Rear
TRUNK RELEASE (-)	BLACK/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	BLACK/WHITE	Harness In Driver's Kick Panel
TACHOMETER	BROWN/GREEN	At Ignition Coil
BRAKE WIRE (+)	ORANGE/BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	WHITE/PURPLE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/PURPLE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	YELLOW/GREEN	At Window Switch In Driver's Door
Some models are equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2001 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	GRAY/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Harness In Driver's Kick panel
PARKING LIGHTS (+)	RED/BLUE and RED/YELLOW	At Headlight Switch
<ul style="list-style-type: none"> The parking light wires must be isolated from each other and from the headlight switch to keep the headlights from flashing with the parking lights. 		
DOOR TRIGGER (+)	BLACK/RED and BLACK/GREEN	At Top Of Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	In Driver's Running Board Towards Rear
TRUNK RELEASE (-)	BLACK/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	BLACK/WHITE	Harness In Driver's Kick Panel
TACHOMETER	BROWN/GREEN	At Ignition Coil
BRAKE WIRE (+)	ORANGE/BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	WHITE/PURPLE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/PURPLE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	YELLOW/GREEN	At Window Switch In Driver's Door
Some models are equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2002 Mercury Cougar

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	GRAY/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (-)	YELLOW/GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	WHITE/GREEN	Harness In Driver's Kick panel
PARKING LIGHTS (+)	RED/BLUE and RED/YELLOW	At Headlight Switch
<ul style="list-style-type: none"> The parking light wires must be isolated from each other and from the headlight switch to keep the headlights from flashing with the parking lights. 		
DOOR TRIGGER (+)	BLACK/RED and BLACK/GREEN	At Top Of Fuse Box
TRUNK TRIGGER (-)	BLACK/ORANGE	In Driver's Running Board Towards Rear
TRUNK RELEASE (-)	BLACK/YELLOW	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM (-)	BLACK/WHITE	Harness In Driver's Kick Panel
TACHOMETER	BROWN/GREEN	At Ignition Coil
BRAKE WIRE (+)	ORANGE/BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	WHITE/PURPLE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	YELLOW/PURPLE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	YELLOW/GREEN	At Window Switch In Driver's Door
Some models are equipped with Ford's PATS anti-theft system. This must be bypassed when installing a remote start system.		