

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V	RED	Ignition Harness
STARTER	DARK GREEN	Ignition Harness
IGNITION	LT.GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
POWER UNLOCK (-)	PINK/ LT. GREEN	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
PARKING LIGHTS (+)	BROWN/WHITE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
PARKING LIGHTS (-)	BLACK/LT.GREEN	Harness In Driver's Kick Panel Or Connector D at Module Attached To Fuse Box
DOOR TRIGGER (-)	Use domelight wire. The individual door trigger wires rest at ground and go to an open circuit when the door is opened.	
Notes: Individual door trigger wires. They are: LT.GREEN/BLACK (left front door), YELLOW/LT.GREEN (right front door), PURPLE/LT.GREEN (left rear door), and RED (right rear door). These wires are found in connector C at module attached To fuse box		
DOME SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
FACTRY ALARM ARM (-)	Arms on lock with a door open	
FACTRY ALARM DISARM (-)	LT.BLUE/BLACK	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TACHOMETER WIRE	NOT RED	Any Fuel Injector
BRAKE WIRE (+)	RED/LIGHT GREEN	At Switch Or Connector A at Module Attached To Fuse Box
HORN TRIGGER (-)	DK.BLUE	Harness At Steering Column Or Connector B at Module Attached To Fuse Box
LEFT FRONT WINDOW UP	Not recommended due to one-touch open and close.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	PURPLE	Radio Harness	
RADIO GROUND	BLACK/ORANGE	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
FACTORY AMP TURN-ON	GRAY/BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	ORANGE/LT.GREEN	Radio Harness	
LEFT FRONT SPEAKER (-)	LT.BLUE/WHITE	Radio Harness	
RIGHT FRONT SPEAKER (+)	WHITE/LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	DK.GREEN/ORANGE	Radio Harness	
LEFT REAR SPEAKER (+)	GRAY/LT.BLUE	Radio Harness	
LEFT REAR SPEAKER (-)	TAN/YELLOW	Radio Harness	
RIGHT REAR SPEAKER (+)	ORANGE/RED	Radio Harness	
RIGHT REAR SPEAKER (-)	BROWN/PINK	Radio Harness	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-5812, SCOSCHE FD1424B	METRA 70-5520, SCOSCHE FD23B		Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V	RED	Ignition Harness
STARTER	DARK GREEN	Ignition Harness
IGNITION	LT.GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
POWER UNLOCK (-)	PINK/ LT. GREEN	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
PARKING LIGHTS (+)	BROWN/WHITE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
PARKING LIGHTS (-)	BLACK/LT.GREEN	Harness In Driver's Kick Panel Or Connector D at Module Attached To Fuse Box
DOOR TRIGGER (-)	Use domelight wire. The individual door trigger wires rest at ground and go to an open circuit when the door is opened.	
Notes: Individual door trigger wires. They are: LT.GREEN/BLACK (left front door), YELLOW/LT.GREEN (right front door), PURPLE/LT.GREEN (left rear door), and RED (right rear door). These wires are found in connector C at module attached To fuse box		
DOME SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
FACTRY ALARM ARM (-)	Arms on lock with a door open	
FACTRY ALARM DISARM (-)	LT.BLUE/BLACK	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TACHOMETER WIRE	NOT RED	Any Fuel Injector
BRAKE WIRE (+)	RED/LIGHT GREEN	At Switch Or Connector A at Module Attached To Fuse Box
HORN TRIGGER (-)	DK.BLUE	Harness At Steering Column Or Connector B at Module Attached To Fuse Box
LEFT FRONT WINDOW UP	Not recommended due to one-touch open and close.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	PURPLE	Radio Harness	
RADIO GROUND	BLACK/ORANGE	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
FACTORY AMP TURN-ON	GRAY/BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	ORANGE/LT.GREEN	Radio Harness	
LEFT FRONT SPEAKER (-)	LT.BLUE/WHITE	Radio Harness	
RIGHT FRONT SPEAKER (+)	WHITE/LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	DK.GREEN/ORANGE	Radio Harness	
LEFT REAR SPEAKER (+)	GRAY/LT.BLUE	Radio Harness	
LEFT REAR SPEAKER (-)	TAN/YELLOW	Radio Harness	
RIGHT REAR SPEAKER (+)	ORANGE/RED	Radio Harness	
RIGHT REAR SPEAKER (-)	BROWN/PINK	Radio Harness	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5812, SCOSCHE FD1424B		METRA 70-5520, SCOSCHE FD23B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V	RED	Ignition Harness
STARTER	DARK GREEN	Ignition Harness
IGNITION	LT.GREEN/PURPLE	Ignition Harness
ACCESSORY	GRAY/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK/YELLOW	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
POWER UNLOCK (-)	PINK/ LT. GREEN	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
PARKING LIGHTS (+)	BROWN/WHITE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
PARKING LIGHTS (-)	BLACK/LT.GREEN	Harness In Driver's Kick Panel Or Connector D at Module Attached To Fuse Box
DOOR TRIGGER (-)	Use domelight wire. The individual door trigger wires rest at ground and go to an open circuit when the door is opened.	
Notes: Individual door trigger wires. They are: LT.GREEN/BLACK (left front door), YELLOW/LT.GREEN (right front door), PURPLE/LT.GREEN (left rear door), and RED (right rear door). These wires are found in connector C at module attached To fuse box		
DOME SUPERVISION (+)	BLACK/LT. BLUE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
FACTRY ALARM ARM (-)	Arms on lock with a door open	
FACTRY ALARM DISARM (-)	LT.BLUE/BLACK	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TACHOMETER WIRE	NOT RED	Any Fuel Injector
BRAKE WIRE (+)	RED/LIGHT GREEN	At Switch Or Connector A at Module Attached To Fuse Box
HORN TRIGGER (-)	DK.BLUE	Harness At Steering Column Or Connector B at Module Attached To Fuse Box
LEFT FRONT WINDOW UP	Not recommended due to one-touch open and close.	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	PURPLE	Radio Harness	
RADIO GROUND	BLACK/ORANGE	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
FACTORY AMP TURN-ON	GRAY/BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	ORANGE/LT.GREEN	Radio Harness	
LEFT FRONT SPEAKER (-)	LT.BLUE/WHITE	Radio Harness	
RIGHT FRONT SPEAKER (+)	WHITE/LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	DK.GREEN/ORANGE	Radio Harness	
LEFT REAR SPEAKER (+)	GRAY/LT.BLUE	Radio Harness	
LEFT REAR SPEAKER (-)	TAN/YELLOW	Radio Harness	
RIGHT REAR SPEAKER (+)	ORANGE/RED	Radio Harness	
RIGHT REAR SPEAKER (-)	BROWN/PINK	Radio Harness	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-5812, SCOSCHE FD1424B	METRA 70-5520, SCOSCHE FD23B		Not required
Please verify all part numbers before ordering.			