

TRIPLE S *Customs*

MITSUBISHI ENDEAVOR 2004-2005 VEHICLE WIRING

WIRING INFORMATION: 2004 Mitsubishi Endeavor

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLUE/YELLOW	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
SECOND ACCESSORY WIRE	BLUE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PURPLE	At Module Attached To Rear Of Fuse Box
POWER DOOR UNLOCK (-)	LT.GREEN/RED	At Module Attached To Rear Of Fuse Box
PARKING LIGHTS (+)	GREEN/WHITE	In Connector Below Fuse Box
DRIVER DOOR TRIGGER (-)	LT.GREEN	In Connector Below Fuse Box
FRONT PASSENGER DOOR TRIGGER (-)	YELLOW	At Module Attached To Rear Of Fuse Box
DRIVER REAR DOOR TRIGGER (-)	ORANGE/BLACK	In Connector Below Fuse Box
REAR PASSENGER DOOR TRIGGER (-)	ORANGE/BLACK	At Module Attached To Rear Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/GREEN	In Connector Below Fuse Box
GLASS HATCH TRIGGER (-)	RED/YELLOW	At Module Attached To Rear Of Fuse Box
REAR LIFTGATE TRIGGER (-)	YELLOW/BLUE	At Module Attached To Rear Of Fuse Box
HOOD TRIGGER (-)	BLUE/WHITE	At Module Attached To Rear Of Fuse Box
FACTORY ALARM ARM (-)	LT.GREEN/BLACK	At Module Attached To Rear Of Fuse Box
FACTORY ALARM DISARM (-)	RED/GREEN	At Module Attached To Rear Of Fuse Box
TACHOMETER WIRE	Wire that is NOT BLACK/WHITE or BLACK	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	LT.GREEN	At Module Attached To Rear Of Fuse Box
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle is equipped with an Immobilizer system that must be bypassed when installing a remote start system.

WIRING INFORMATION: 2005 Mitsubishi Endeavor

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLUE/YELLOW	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
SECOND ACCESSORY WIRE	BLUE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	PURPLE	At Module Attached To Rear Of Fuse Box
POWER DOOR UNLOCK (-)	LT.GREEN/RED	At Module Attached To Rear Of Fuse Box
PARKING LIGHTS (+)	GREEN/WHITE	In Connector Below Fuse Box
DRIVER DOOR TRIGGER (-)	LT.GREEN	In Connector Below Fuse Box
FRONT PASSENGER DOOR TRIGGER (-)	YELLOW	At Module Attached To Rear Of Fuse Box
DRIVER REAR DOOR TRIGGER (-)	ORANGE/BLACK	In Connector Below Fuse Box
REAR PASSENGER DOOR TRIGGER (-)	ORANGE/BLACK	At Module Attached To Rear Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/GREEN	In Connector Below Fuse Box
GLASS HATCH TRIGGER (-)	RED/YELLOW	At Module Attached To Rear Of Fuse Box
REAR LIFTGATE TRIGGER (-)	YELLOW/BLUE	At Module Attached To Rear Of Fuse Box
HOOD TRIGGER (-)	BLUE/WHITE	At Module Attached To Rear Of Fuse Box
FACTORY ALARM ARM (-)	LT.GREEN/BLACK	At Module Attached To Rear Of Fuse Box
FACTORY ALARM DISARM (-)	RED/GREEN	At Module Attached To Rear Of Fuse Box
TACHOMETER WIRE	Wire that is NOT BLACK/WHITE or BLACK	Ignition Coil
BRAKE WIRE (+)	GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	LT.GREEN	At Module Attached To Rear Of Fuse Box
LEFT FRONT WINDOW UP	RED/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

This vehicle is equipped with an Immobilizer system that must be bypassed when installing a remote start system.