

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
SECOND ACCESSORY WIRE	BLACK/PINK	Ignition Harness
POWER DOOR LOCK (-)	GRAY	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PURPLE	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Connector Above Fuse box Or Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN	At Ignition Coil Or Behind Instrument Cluster
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND		Ground to chassis	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN	At Speaker	
LEFT FRONT SPEAKER (-)	BLACK/RED	At Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/YELLOW	At Speaker	
LEFT REAR SPEAKER (+)	ORANGE	At Speaker	
LEFT REAR SPEAKER (-)	BLACK/PINK	At Speaker	
RIGHT REAR SPEAKER (+)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	BLACK/WHITE	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-7417, SCOSCHE NN2155B	METRA 99-7417, SCOSCHE NN03B/BCB		METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
SECOND ACCESSORY WIRE	BLACK/PINK	Ignition Harness
POWER DOOR LOCK (-)	GRAY	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PURPLE	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Connector Above Fuse box Or Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN	At Ignition Coil Or Behind Instrument Cluster
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND		Ground to chassis	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN	At Speaker	
LEFT FRONT SPEAKER (-)	BLACK/RED	At Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/YELLOW	At Speaker	
LEFT REAR SPEAKER (+)	ORANGE	At Speaker	
LEFT REAR SPEAKER (-)	BLACK/PINK	At Speaker	
RIGHT REAR SPEAKER (+)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	BLACK/WHITE	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-7417, SCOSCHE NN2155B	METRA 99-7417, SCOSCHE NN03B/BCB		METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
SECOND ACCESSORY WIRE	BLACK/PINK	Ignition Harness
POWER DOOR LOCK (-)	GRAY	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PURPLE	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Connector Above Fuse box Or Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN	At Ignition Coil Or Behind Instrument Cluster
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND		Ground to chassis	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN	At Speaker	
LEFT FRONT SPEAKER (-)	BLACK/RED	At Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/YELLOW	At Speaker	
LEFT REAR SPEAKER (+)	ORANGE	At Speaker	
LEFT REAR SPEAKER (-)	BLACK/PINK	At Speaker	
RIGHT REAR SPEAKER (+)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	BLACK/WHITE	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-7417, SCOSCHE NN2155B	METRA 99-7417, SCOSCHE NN03B/BCB		METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/BLUE	Ignition Harness
IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE	Ignition Harness
SECOND ACCESSORY WIRE	BLACK/PINK	Ignition Harness
POWER DOOR LOCK (-)	GRAY	White Connector In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PURPLE	White Connector In Driver's Kick Panel
PARKING LIGHTS (+)	RED/BLUE	Connector Above Fuse box Or Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN	At Ignition Coil Or Behind Instrument Cluster
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/YELLOW	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	PINK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND		Ground to chassis	
ILLUMINATION (+)	RED/BROWN	Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN	At Speaker	
LEFT FRONT SPEAKER (-)	BLACK/RED	At Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/YELLOW	At Speaker	
LEFT REAR SPEAKER (+)	ORANGE	At Speaker	
LEFT REAR SPEAKER (-)	BLACK/PINK	At Speaker	
RIGHT REAR SPEAKER (+)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	BLACK/WHITE	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-7417, SCOSCHE NN2155B	METRA 99-7417, SCOSCHE NN03B/BCB		METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			