

# **TRIPLE S** *Customs*

## **NISSAN 200SX 1995-1998 VEHICLE WIRING**

WIRING INFORMATION: 1995 Nissan 200SX

| WIRE                    | WIRE COLOR   | WIRE LOCATION  |
|-------------------------|--------------|--|
| 12V CONSTANT WIRE       | WHITE/RED    | Ignition Harness   |
| STARTER WIRE            | BLACK/YELLOW | Ignition Harness   |
| SECOND STARTER WIRE     | BLACK/BLUE   | Ignition Harness   |
| IGNITION WIRE           | BLACK/WHITE  | Ignition Harness   |
| ACCESSORY WIRE          | BLUE         | Ignition Harness   |
| SECOND ACCESSORY WIRE   | BLACK/PINK   | Ignition Harness   |
| POWER DOOR LOCK (-)     | GRAY         | White Connector In Driver's Kick Panel                     |
| POWER DOOR UNLOCK (-)   | PURPLE       | White Connector In Driver's Kick Panel                     |
| PARKING LIGHTS (+)      | RED/BLUE     | Connector Above Fuse box Or Harness In Driver's Kick Panel |
| DOOR TRIGGER (-)        | RED/WHITE    | Harness In Driver's Kick Panel Or Pin Switch               |
| TRUNK TRIGGER (-)       | RED          | At Light In Trunk  |
| TACHOMETER WIRE         | GREEN        | At Ignition Coil Or Behind Instrument Cluster              |
| BRAKE WIRE (+)          | RED/GREEN    | At Brake Pedal Switch                                      |
| HORN TRIGGER (-)        | GREEN/YELLOW | Harness At Steering Column                                 |
| LEFT FRONT WINDOW UP    | BLUE         | At Driver Window Motor Inside Door                         |
| LEFT FRONT WINDOW DOWN  | GREEN        | At Driver Window Motor Inside Door                         |
| RIGHT FRONT WINDOW UP   | RED/WHITE    | Harness In Driver's Kick From Driver Door                  |
| RIGHT FRONT WINDOW DOWN | RED/BLACK    | Harness In Driver's Kick From Driver Door                  |

WIRING INFORMATION: 1996 Nissan 200SX

| WIRE                    | WIRE COLOR   | WIRE LOCATION  |
|-------------------------|--------------|--|
| 12V CONSTANT WIRE       | WHITE/RED    | Ignition Harness   |
| STARTER WIRE            | BLACK/YELLOW | Ignition Harness   |
| SECOND STARTER WIRE     | BLACK/BLUE   | Ignition Harness   |
| IGNITION WIRE           | BLACK/WHITE  | Ignition Harness   |
| ACCESSORY WIRE          | BLUE         | Ignition Harness   |
| SECOND ACCESSORY WIRE   | BLACK/PINK   | Ignition Harness   |
| POWER DOOR LOCK (-)     | GRAY         | White Connector In Driver's Kick Panel                     |
| POWER DOOR UNLOCK (-)   | PURPLE       | White Connector In Driver's Kick Panel                     |
| PARKING LIGHTS (+)      | RED/BLUE     | Connector Above Fuse box Or Harness In Driver's Kick Panel |
| DOOR TRIGGER (-)        | RED/WHITE    | Harness In Driver's Kick Panel Or Pin Switch               |
| TRUNK TRIGGER (-)       | RED          | At Light In Trunk  |
| TACHOMETER WIRE         | GREEN        | At Ignition Coil Or Behind Instrument Cluster              |
| BRAKE WIRE (+)          | RED/GREEN    | At Brake Pedal Switch                                      |
| HORN TRIGGER (-)        | GREEN/YELLOW | Harness At Steering Column                                 |
| LEFT FRONT WINDOW UP    | BLUE         | At Driver Window Motor Inside Door                         |
| LEFT FRONT WINDOW DOWN  | GREEN        | At Driver Window Motor Inside Door                         |
| RIGHT FRONT WINDOW UP   | RED/WHITE    | Harness In Driver's Kick From Driver Door                  |
| RIGHT FRONT WINDOW DOWN | RED/BLACK    | Harness In Driver's Kick From Driver Door                  |

WIRING INFORMATION: 1997 Nissan 200SX

| WIRE                    | WIRE COLOR   | WIRE LOCATION  |
|-------------------------|--------------|--|
| 12V CONSTANT WIRE       | WHITE/RED    | Ignition Harness   |
| STARTER WIRE            | BLACK/YELLOW | Ignition Harness   |
| SECOND STARTER WIRE     | BLACK/BLUE   | Ignition Harness   |
| IGNITION WIRE           | BLACK/WHITE  | Ignition Harness   |
| ACCESSORY WIRE          | BLUE         | Ignition Harness   |
| SECOND ACCESSORY WIRE   | BLACK/PINK   | Ignition Harness   |
| POWER DOOR LOCK (-)     | GRAY         | White Connector In Driver's Kick Panel                     |
| POWER DOOR UNLOCK (-)   | PURPLE       | White Connector In Driver's Kick Panel                     |
| PARKING LIGHTS (+)      | RED/BLUE     | Connector Above Fuse box Or Harness In Driver's Kick Panel |
| DOOR TRIGGER (-)        | RED/WHITE    | Harness In Driver's Kick Panel Or Pin Switch               |
| TRUNK TRIGGER (-)       | RED          | At Light In Trunk  |
| TACHOMETER WIRE         | GREEN        | At Ignition Coil Or Behind Instrument Cluster              |
| BRAKE WIRE (+)          | RED/GREEN    | At Brake Pedal Switch                                      |
| HORN TRIGGER (-)        | GREEN/YELLOW | Harness At Steering Column                                 |
| LEFT FRONT WINDOW UP    | BLUE         | At Driver Window Motor Inside Door                         |
| LEFT FRONT WINDOW DOWN  | GREEN        | At Driver Window Motor Inside Door                         |
| RIGHT FRONT WINDOW UP   | RED/WHITE    | Harness In Driver's Kick From Driver Door                  |
| RIGHT FRONT WINDOW DOWN | RED/BLACK    | Harness In Driver's Kick From Driver Door                  |

WIRING INFORMATION: 1998 Nissan 200SX

| WIRE                    | WIRE COLOR   | WIRE LOCATION  |
|-------------------------|--------------|--|
| 12V CONSTANT WIRE       | WHITE/RED    | Ignition Harness   |
| STARTER WIRE            | BLACK/YELLOW | Ignition Harness   |
| SECOND STARTER WIRE     | BLACK/BLUE   | Ignition Harness   |
| IGNITION WIRE           | BLACK/WHITE  | Ignition Harness   |
| ACCESSORY WIRE          | BLUE         | Ignition Harness   |
| SECOND ACCESSORY WIRE   | BLACK/PINK   | Ignition Harness   |
| POWER DOOR LOCK (-)     | GRAY         | White Connector In Driver's Kick Panel                     |
| POWER DOOR UNLOCK (-)   | PURPLE       | White Connector In Driver's Kick Panel                     |
| PARKING LIGHTS (+)      | RED/BLUE     | Connector Above Fuse box Or Harness In Driver's Kick Panel |
| DOOR TRIGGER (-)        | RED/WHITE    | Harness In Driver's Kick Panel Or Pin Switch               |
| TRUNK TRIGGER (-)       | RED          | At Light In Trunk  |
| TACHOMETER WIRE         | GREEN        | At Ignition Coil Or Behind Instrument Cluster              |
| BRAKE WIRE (+)          | RED/GREEN    | At Brake Pedal Switch                                      |
| HORN TRIGGER (-)        | GREEN/YELLOW | Harness At Steering Column                                 |
| LEFT FRONT WINDOW UP    | BLUE         | At Driver Window Motor Inside Door                         |
| LEFT FRONT WINDOW DOWN  | GREEN        | At Driver Window Motor Inside Door                         |
| RIGHT FRONT WINDOW UP   | RED/WHITE    | Harness In Driver's Kick From Driver Door                  |
| RIGHT FRONT WINDOW DOWN | RED/BLACK    | Harness In Driver's Kick From Driver Door                  |