

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Back Of Dash Dimmer Switch Or Harness In Driver's Kick Panel
POWER DOOR LOCK	ORANGE BLACK	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	Same wire as lock	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	BLACK/RED	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	4x6"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-7407, SCOSCHE NN2155B	METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB	
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Back Of Dash Dimmer Switch Or Harness In Driver's Kick Panel
POWER DOOR LOCK	ORANGE BLACK	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	Same wire as lock	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	BLACK/RED	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7407, SCOSCHE NN2155B		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Back Of Dash Dimmer Switch Or Harness In Driver's Kick Panel
POWER DOOR LOCK	ORANGE BLACK	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	Same wire as lock	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	BLACK/RED	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7407, SCOSCHE NN2155B		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Back Of Dash Dimmer Switch Or Harness In Driver's Kick Panel
POWER DOOR LOCK	ORANGE BLACK	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	Same wire as lock	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	BLACK/RED	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7407, SCOSCHE NN2155B		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Back Of Dash Dimmer Switch Or Harness In Driver's Kick Panel
POWER DOOR LOCK	ORANGE BLACK	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	Same wire as lock	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	BLACK/RED	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7407, SCOSCHE NN2155B		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Back Of Dash Dimmer Switch Or Harness In Driver's Kick Panel
POWER DOOR LOCK	ORANGE BLACK	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	Same wire as lock	Harness In Drivers Kick Panel Or Harness Coming Into Vehicle From Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
TRUNK TRIGGER (-)	RED	At Light In Trunk
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)	BLACK/RED	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7407, SCOSCHE NN2155B		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/WHITE	At Factory Anti-Theft Module Or Harness In Driver Kick Panel
POWER DOORUNLOCK (-)	BROWN	At Factory Anti-Theft Module Or Harness In Driver Kick Panel
Notes: · The factory anti-theft module can be found above the hood release cable.		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
DOMELIGHT SUPERVISION (-)		Use Door Trigger Wire
HOOD TRIGGER (-)	YELLOW/BLACK	At Factory Anti-Theft Module or factory hood pin
TRUNK TRIGGER (-)	RED	At Factory Anti-Theft Module Or Light In Trunk
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/GREEN	Harness At Steering Column
FACTORY ALARM ARM (-)	LT GREEN/RED	At Factory Anti-Theft Module
FACTORY ALARM DISARM (-)	GREEN/YELLOW	At Factory Anti-Theft Module
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE/GREEN	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7417, SCOSCHE NN2155B		METRA 70-7550, SCOSCHE NN03B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/WHITE	At Factory Anti-Theft Module Or Harness In Driver Kick Panel
POWER DOORUNLOCK (-)	BROWN	At Factory Anti-Theft Module Or Harness In Driver Kick Panel
Notes: · The factory anti-theft module can be found above the hood release cable.		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
DOMELIGHT SUPERVISION (-)		Use Door Trigger Wire
HOOD TRIGGER (-)	YELLOW/BLACK	At Factory Anti-Theft Module or factory hood pin
TRUNK TRIGGER (-)	RED	At Factory Anti-Theft Module Or Light In Trunk
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/GREEN	Harness At Steering Column
FACTORY ALARM ARM (-)	LT GREEN/RED	At Factory Anti-Theft Module
FACTORY ALARM DISARM (-)	GREEN/YELLOW	At Factory Anti-Theft Module
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE/GREEN	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-7417, SCOSCHE NN2155B	METRA 70-7550, SCOSCHE NN03B		METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/WHITE	At Factory Anti-Theft Module Or Harness In Driver Kick Panel
POWER DOORUNLOCK (-)	BROWN	At Factory Anti-Theft Module Or Harness In Driver Kick Panel
Notes: · The factory anti-theft module can be found above the hood release cable.		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
DOMELIGHT SUPERVISION (-)		Use Door Trigger Wire
HOOD TRIGGER (-)	YELLOW/BLACK	At Factory Anti-Theft Module or factory hood pin
TRUNK TRIGGER (-)	RED	At Factory Anti-Theft Module Or Light In Trunk
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/GREEN	Harness At Steering Column
FACTORY ALARM ARM (-)	LT GREEN/RED	At Factory Anti-Theft Module
FACTORY ALARM DISARM (-)	GREEN/YELLOW	At Factory Anti-Theft Module
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE/GREEN	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-7417, SCOSCHE NN2155B	METRA 70-7550, SCOSCHE NN03B		METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/RED	Ignition Harness
12V ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition Harness
PARKING LIGHTS (+)	RED/BLUE	Ignition Harness
POWER DOOR LOCK (-)	LT GREEN/WHITE	At Factory Anti-Theft Module Or Harness In Driver Kick Panel
POWER DOORUNLOCK (-)	BROWN	At Factory Anti-Theft Module Or Harness In Driver Kick Panel
Notes: · The factory anti-theft module can be found above the hood release cable.		
DOOR TRIGGER (-)	RED/WHITE	Harness In Driver's Kick Panel Or Door Pin Switch
DOMELIGHT SUPERVISION (-)		Use Door Trigger Wire
HOOD TRIGGER (-)	YELLOW/BLACK	At Factory Anti-Theft Module or factory hood pin
TRUNK TRIGGER (-)	RED	At Factory Anti-Theft Module Or Light In Trunk
TACHOMETER WIRE	YELLOW/RED	At Engine Control Module In Passenger Kick Panel
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	YELLOW/GREEN	Harness At Steering Column
FACTORY ALARM ARM (-)	LT GREEN/RED	At Factory Anti-Theft Module
FACTORY ALARM DISARM (-)	GREEN/YELLOW	At Factory Anti-Theft Module
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE/GREEN	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-7417, SCOSCHE NN2155B	METRA 70-7550, SCOSCHE NN03B	METRA 40-NI10, SCOSCHE NDAB	
Please verify all part numbers before ordering.			