

TRIPLE S *Customs*

NISSAN 300ZX 1984-1996 VEHICLE WIRING

WIRING INFORMATION: 1984 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE/BLUE	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
12V ACCESSORY	WHITE/PURPLE	Ignition Harness
STARTER	YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/GREEN	Steering Column Or Dimmer Switch
POWER DOOR LOCK		Actuator Needed In Driver's Door
POWER DOOR UNLOCK		Actuator Needed In Driver's Door
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE/BLACK	Timer Module In Passenger Kick Panel
HOOD TRIGGER (-)	BLACK/PINK	Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
FACTORY ALARM ARM (-)	RED/GREEN	Inside Driver Door Or Kick Panel Or Anti-Theft Module
FACTORY ALARM DISARM (-)	RED/BLUE	Inside Driver Door Or Kick Panel Or Anti-Theft Module
TACHOMETER WIRE	BLUE	Ignition Coil Under Hood Or ECM In Passenger Kick Panel
BRAKE WIRE (+)	LT.GREEN/RED	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Steering Column
LEFT FRONT WINDOW UP	BLUE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> The factory anti-theft module is located under the passenger seat. 		

WIRING INFORMATION: 1985 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE/BLUE	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
12V ACCESSORY	WHITE/PURPLE	Ignition Harness
STARTER	YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/GREEN	Steering Column Or Dimmer Switch
POWER DOOR LOCK		Actuator Needed In Driver's Door
POWER DOOR UNLOCK		Actuator Needed In Driver's Door
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE/BLACK	Timer Module In Passenger Kick Panel
HOOD TRIGGER (-)	BLACK/PINK	Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
FACTORY ALARM ARM (-)	RED/GREEN	Inside Driver Door Or Kick Panel Or Anti-Theft Module
FACTORY ALARM DISARM (-)	RED/BLUE	Inside Driver Door Or Kick Panel Or Anti-Theft Module
TACHOMETER WIRE	BLUE	Ignition Coil Under Hood Or ECM In Passenger Kick Panel
BRAKE WIRE (+)	LT.GREEN/RED	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Steering Column
LEFT FRONT WINDOW UP	BLUE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> The factory anti-theft module is located under the passenger seat. 		

WIRING INFORMATION: 1986 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE/BLUE	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
12V ACCESSORY	WHITE/PURPLE	Ignition Harness
STARTER	YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/GREEN	Steering Column Or Dimmer Switch
POWER DOOR LOCK		Actuator Needed In Driver's Door
POWER DOOR UNLOCK		Actuator Needed In Driver's Door
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE/BLACK	Timer Module In Passenger Kick Panel
HOOD TRIGGER (-)	BLACK/PINK	Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
FACTORY ALARM ARM (-)	RED/GREEN	Inside Driver Door Or Kick Panel Or Anti-Theft Module
FACTORY ALARM DISARM (-)	RED/BLUE	Inside Driver Door Or Kick Panel Or Anti-Theft Module
TACHOMETER WIRE	BLUE	Ignition Coil Under Hood Or ECM In Passenger Kick Panel
BRAKE WIRE (+)	LT.GREEN/RED	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Steering Column
LEFT FRONT WINDOW UP	BLUE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> The factory anti-theft module is located under the passenger seat. 		

WIRING INFORMATION: 1987 Nissan 300ZX

WIRE	WIRE COLOR	Location
12V CONSTANT	WHITE/BLUE	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
12V ACCESSORY	WHITE/PURPLE	Ignition Harness
STARTER	YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/GREEN	Steering Column Or Dimmer Switch
POWER DOOR LOCK		Actuator Needed In Driver's Door
POWER DOOR UNLOCK		Actuator Needed In Driver's Door
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE/BLACK	Timer Module In Passenger Kick Panel
HOOD TRIGGER (-)	BLACK/PINK	OEM Anti-Theft Unit Or Pin Switch
TRUNK TRIGGER		Tied In With Doors
FACTORY ALARM ARM (-)	RED/GRAY	In Driver Door Or Kick Panel Or Anti-Theft Module
FACTORY ALARM DISARM (-)	RED/BLUE	In Driver Door Or Kick Panel Or Anti-Theft Module
TACHOMETER WIRE	BLUE	Ignition Coil Under Hood Or ECM In Passenger Kick Panel
BRAKE WIRE (+)	LT.GREEN/RED	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Steering Column
LEFT FRONT WINDOW UP	BLUE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> The factory anti-theft module is located under the passenger seat. 		

WIRING INFORMATION: 1988 Nissan 300ZX

WIRE	WIRE COLOR	Location
12V CONSTANT	WHITE/BLUE	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
12V ACCESSORY	WHITE/PURPLE	Ignition Harness
STARTER	YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/GREEN	Steering Column Or Dimmer Switch
POWER DOOR LOCK		Actuator Needed In Driver's Door
POWER DOOR UNLOCK		Actuator Needed In Driver's Door
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE/BLACK	Timer Module In Passenger Kick Panel
HOOD TRIGGER (-)	BLACK/PINK	OEM Anti-Theft Unit Or Pin Switch
TRUNK TRIGGER		Tied In With Doors
FACTORY ALARM ARM (-)	RED/GRAY	In Driver Door Or Kick Panel Or Ant-Theft Module
FACTORY ALARM DISARM (-)	RED/BLUE	In Driver Door Or Kick Panel Or Anti-Theft Module
TACHOMETER WIRE	BLUE	Ignition Coil Under Hood Or ECM In Passenger Kick Panel
BRAKE WIRE (+)	LT.GREEN/RED	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Steering Column
LEFT FRONT WINDOW UP	BLUE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> The factory anti-theft module is located under the passenger seat. 		

WIRING INFORMATION: 1989 Nissan 300ZX

WIRE	WIRE COLOR	Location
12V CONSTANT	WHITE/BLUE	Ignition Harness
12V IGNITION	BLACK/WHITE	Ignition Harness
12V ACCESSORY	WHITE/PURPLE	Ignition Harness
STARTER	YELLOW	Ignition Harness
PARKING LIGHTS (+)	RED/GREEN	Steering Column Or Dimmer Switch
POWER DOOR LOCK		Actuator Needed In Driver's Door
POWER DOOR UNLOCK		Actuator Needed In Driver's Door
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE/BLACK	Timer Module In Passenger Kick Panel
HOOD TRIGGER (-)	BLACK/PINK	OEM Anti-Theft Unit Or Pin Switch
TRUNK TRIGGER		Tied In With Doors
FACTORY ALARM ARM (-)	RED/GRAY	In Driver Door Or Kick Panel Or Anti-Theft Module
FACTORY ALARM DISARM (-)	RED/BLUE	In Driver Door Or Kick Panel Or Anti-Theft Module
TACHOMETER WIRE	BLUE	Ignition Coil Under Hood Or ECM In Passenger Kick Panel
BRAKE WIRE (+)	LT.GREEN/RED	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Steering Column
LEFT FRONT WINDOW UP	BLUE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/RED	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> The factory anti-theft module is located under the passenger seat. 		

WIRING INFORMATION: 1990 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE	Ignition Harness
12V IGNITION	BLACK/RED	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
STARTER	BLACK/WHITE	Ignition Harness
SECOND STARTER	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	GREEN/RED	At Light Switch
POWER DOOR LOCK		Actuator Needed In Driver's Door
POWER DOOR UNLOCK		Actuator Needed In Driver's Door
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE	Driver Kick Panel Or Factory Anti-Theft Unit
HOOD TRIGGER (-)	ORANGE/BLUE	Factory Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
FACTORY ALARM ARM (-)	BLUE/RED	Driver Kick Or Factory Anti-Theft Unit
FACTORY ALARM DISARM (-)	GRAY/RED	Driver Kick Or Factory Anti-Theft Unit
TACHOMETER	YELLOW/RED	Test Connector Under Hood
<ul style="list-style-type: none"> The tachometer test connector is located between the fuse/relay panel and inner fender behind the left headlight. The connector is composed of one wire in round connector. 		
BRAKE WIRE (+)	RED/BLACK	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> Factory anti-theft module is located under carpet on passenger floorboard. 		

WIRING INFORMATION: 1991 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE	Ignition Harness
12V IGNITION	BLACK/RED	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
STARTER	BLACK/WHITE	Ignition Harness
SECOND STARTER	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	GREEN/RED	At Light Switch
POWER LOCK		Actuator Needed In Driver's Door
POWER UNLOCK		Actuator Needed In Driver's Door
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE	Driver Kick Or Anti-Theft Unit
HOOD TRIGGER (-)	ORANGE/BLUE	Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
FACTORY ALARM ARM (-)	BLUE/RED	Driver Kick Or Anti-Theft Unit
FACTORY ALARM DISARM (-)	GRAY/RED	Driver Kick Or Anti-Theft Unit
TACHOMETER	YELLOW/RED	Test Connector Under Hood
<ul style="list-style-type: none"> The tachometer test connector is located between the fuse/relay panel and inner fender behind the left headlight. The connector is composed of one wire in round connector. 		
BRAKE WIRE (+)	RED/BLACK	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> Factory anti-theft module is located under carpet on passenger floorboard. 		

WIRING INFORMATION: 1992 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE	Ignition harness
12V IGNITION	BLACK/RED	Ignition harness
12V ACCESSORY	BLUE	Ignition harness
STARTER	BLACK/WHITE	Ignition harness
SECOND STARTER	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GREEN/RED	At light switch
POWER DOOR LOCK (interrupt)	ORANGE/BLACK or BROWN	Near hood release in kick panel
POWER DOOR UNLOCK (-)		
This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used.		
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE	Driver kick or anti-theft unit
HOOD TRIGGER (-)	ORANGE/BLUE	Anti-theft unit
TRUNK TRIGGER		Tied in with doors
FACTORY ALARM ARM (-)	BLUE/RED	Driver kick or factory anti-theft unit
FACTORY ALARM DISARM (-)	GRAY/RED	Driver kick or factory anti-theft unit
TACHOMETER WIRE	YELLOW/RED	Test connector under hood
The tachometer test connector is located between the fuse/relay panel and inner fender behind the left headlight. The connector is composed of one wire in round connector.		
BRAKE WIRE (+)	RED/BLACK	Brake pedal switch
HORN TRIGGER (-)	GREEN/WHITE	Steering column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
The factory anti-theft module is located under the carpet on passenger floorboard.		

WIRING INFORMATION: 1993 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE	Ignition Harness
12V IGNITION	BLACK/RED	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
STARTER	BLACK/WHITE	Ignition Harness
SECOND STARTER	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	GREEN/RED	At Light Switch
POWER DOOR LOCK (interrupt)	BROWN	Driver's Kick Panel
POWER DOOR UNLOCK (-)		
This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used.		
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE	Driver Kick Or Factory Anti-Theft Unit
HOOD TRIGGER (-)	ORANGE/BLUE	Factory Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
TRUNK RELEASE (+)	DARK GREEN	Factory Keyless Entry Module
FACTORY ALARM ARM (-)	BLUE/RED	Driver Kick Or Factory Anti-Theft Unit
FACTORY ALARM DISARM (-)	GRAY/RED	Driver Kick Or A Factory Anti-Theft Unit
TACHOMETER	YELLOW/RED	Test Connector Under Hood
The tachometer test connector is located between the fuse/relay panel and inner fender behind the left headlight. The connector is composed of one wire in round connector.		
BRAKE WIRE (+)	RED/BLACK	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
The factory anti-theft module is located under the carpet on passenger floorboard.		
Few models are equipped with a keyless entry located below passenger side foot area.		

WIRING INFORMATION: 1994 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE	Ignition Harness
12V IGNITION	BLACK/RED	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
STARTER	BLACK/WHITE	Ignition Harness
SECOND STARTER	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	GREEN/RED	At Light Switch
POWER DOOR LOCK (interrupt)	BROWN	Driver's Kick Panel
POWER DOOR UNLOCK (-)		
This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used.		
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE	Driver Kick Or Factory Anti-Theft Unit
HOOD TRIGGER (-)	ORANGE/BLUE	Factory Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
TRUNK RELEASE (+)	DARK GREEN	Factory Keyless Entry Module
FACTORY ALARM ARM (-)	BLUE/RED	Driver Kick Or Factory Anti-Theft Unit
FACTORY ALARM DISARM (-)	GRAY/RED	Driver Kick Or A Factory Anti-Theft Unit
TACHOMETER	YELLOW/RED	Test Connector Under Hood
The tachometer test connector is located between the fuse/relay panel and inner fender behind the left headlight. The connector is composed of one wire in round connector.		
BRAKE WIRE (+)	RED/BLACK	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
The factory anti-theft module is located under the carpet on passenger floorboard.		
Few models are equipped with a keyless entry located below passenger side foot area.		

WIRING INFORMATION: 1995 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE	Ignition Harness
12V IGNITION	BLACK/RED	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
STARTER	BLACK/WHITE	Ignition Harness
SECOND STARTER	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	GREEN/RED	At Light Switch
POWER DOOR LOCK (interrupt)	BROWN	Driver's Kick Panel
POWER DOOR UNLOCK (-)		
This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used.		
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE	Driver Kick Or Factory Anti-Theft Unit
HOOD TRIGGER (-)	ORANGE/BLUE	Factory Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
TRUNK RELEASE (+)	DARK GREEN	Factory Keyless Entry Module
FACTORY ALARM ARM (-)	BLUE/RED	Driver Kick Or Factory Anti-Theft Unit
FACTORY ALARM DISARM (-)	GRAY/RED	Driver Kick Or A Factory Anti-Theft Unit
TACHOMETER	YELLOW/RED	Test Connector Under Hood
The tachometer test connector is located between the fuse/relay panel and inner fender behind the left headlight. The connector is composed of one wire in round connector.		
BRAKE WIRE (+)	RED/BLACK	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
The factory anti-theft module is located under the carpet on passenger floorboard.		
Few models are equipped with a keyless entry located below passenger side foot area.		

WIRING INFORMATION: 1996 Nissan 300ZX

WIRE	WIRE COLOR	LOCATION
12V CONSTANT	WHITE	Ignition Harness
12V IGNITION	BLACK/RED	Ignition Harness
12V ACCESSORY	BLUE	Ignition Harness
STARTER	BLACK/WHITE	Ignition Harness
SECOND STARTER	BLACK/YELLOW	Ignition Harness
PARKING LIGHTS (+)	GREEN/RED	At Light Switch
POWER DOOR LOCK (interrupt)	BROWN	Driver's Kick Panel
POWER DOOR UNLOCK (-)		
This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used.		
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLUE	Driver Kick Or Factory Anti-Theft Unit
HOOD TRIGGER (-)	ORANGE/BLUE	Factory Anti-Theft Unit
TRUNK TRIGGER		Tied In With Doors
TRUNK RELEASE (+)	DARK GREEN	Factory Keyless Entry Module
FACTORY ALARM ARM (-)	BLUE/RED	Driver Kick Or Factory Anti-Theft Unit
FACTORY ALARM DISARM (-)	GRAY/RED	Driver Kick Or A Factory Anti-Theft Unit
TACHOMETER	YELLOW/RED	Test Connector Under Hood
The tachometer test connector is located between the fuse/relay panel and inner fender behind the left headlight. The connector is composed of one wire in round connector.		
BRAKE WIRE (+)	RED/BLACK	Brake Pedal Switch
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/WHITE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	WHITE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/YELLOW	Harness In Driver's Kick From Driver Door
The factory anti-theft module is located under the carpet on passenger floorboard.		
Few models are equipped with a keyless entry located below passenger side foot area.		