

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK	LT. GREEN/BLACK	At Door Lock Switch Inside Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
POWER DOOR UNLOCK (-)	Same wire as lock	
PARKING LIGHTS (+)	RED/BLUE	Connector Above Kick Panel In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Yellow Connector Above Kick In Driver's Kick Panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN/YELLOW or BLUE/BLACK	At Ignition Coil Or Instrument Cluster
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	At Right Front Window Motor
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	At Right Front Window Motor
LEFT REAR WINDOW UP	BLUE/RED	At Left Rear Window Motor
LEFT REAR WINDOW DOWN	BLUE/BLACK	At Left Rear Window Motor
RIGHT REAR WINDOW UP	BLUE/RED	At Right Rear Window Motor
RIGHT REAR WINDOW DOWN	BLUE/BLACK	At Right Rear Window Motor

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK	LT. GREEN/BLACK	At Door Lock Switch Inside Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
POWER DOOR UNLOCK (-)	Same wire as lock	
PARKING LIGHTS (+)	RED/BLUE	Connector Above Kick Panel In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Yellow Connector Above Kick In Driver's Kick Panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN/YELLOW or BLUE/BLACK	At Ignition Coil Or Instrument Cluster
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	At Right Front Window Motor
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	At Right Front Window Motor
LEFT REAR WINDOW UP	BLUE/RED	At Left Rear Window Motor
LEFT REAR WINDOW DOWN	BLUE/BLACK	At Left Rear Window Motor
RIGHT REAR WINDOW UP	BLUE/RED	At Right Rear Window Motor
RIGHT REAR WINDOW DOWN	BLUE/BLACK	At Right Rear Window Motor

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK	LT. GREEN/BLACK	At Door Lock Switch Inside Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
POWER DOOR UNLOCK (-)	Same wire as lock	
PARKING LIGHTS (+)	RED/BLUE	Connector Above Kick Panel In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Yellow Connector Above Kick In Driver's Kick Panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN/YELLOW or BLUE/BLACK	At Ignition Coil Or Instrument Cluster
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	At Right Front Window Motor
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	At Right Front Window Motor
LEFT REAR WINDOW UP	BLUE/RED	At Left Rear Window Motor
LEFT REAR WINDOW DOWN	BLUE/BLACK	At Left Rear Window Motor
RIGHT REAR WINDOW UP	BLUE/RED	At Right Rear Window Motor
RIGHT REAR WINDOW DOWN	BLUE/BLACK	At Right Rear Window Motor

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
SECOND STARTER WIRE	BLACK/YELLOW	Ignition Harness
IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	WHITE/BLUE	Ignition Harness
POWER DOOR LOCK	LT. GREEN/BLACK	At Door Lock Switch Inside Driver's Door
Notes: This vehicle uses a single wire to lock and unlock the doors. Send a negative pulse to unlock the doors, interrupt wire to lock. Relays must be used. Refer to TechDoc 3959		
POWER DOOR UNLOCK (-)	Same wire as lock	
PARKING LIGHTS (+)	RED/BLUE	Connector Above Kick Panel In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	Yellow Connector Above Kick In Driver's Kick Panel
TRUNK TRIGGER (-)	RED	At Light In Trunk
TACHOMETER WIRE	GREEN/YELLOW or BLUE/BLACK	At Ignition Coil Or Instrument Cluster
BRAKE WIRE (+)	RED/GREEN	At Brake Pedal Switch Or Harness In Driver's Kick Panel
HORN TRIGGER (-)	GREEN/WHITE	Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	At Right Front Window Motor
RIGHT FRONT WINDOW DOWN	BLUE/BLACK	At Right Front Window Motor
LEFT REAR WINDOW UP	BLUE/RED	At Left Rear Window Motor
LEFT REAR WINDOW DOWN	BLUE/BLACK	At Left Rear Window Motor
RIGHT REAR WINDOW UP	BLUE/RED	At Right Rear Window Motor
RIGHT REAR WINDOW DOWN	BLUE/BLACK	At Right Rear Window Motor

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLACK	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	Chassis	Not In Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/YELLOW	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	PINK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed		METRA 70-1763, SCOSCHE NN02B	METRA 40-NI10, SCOSCHE NDAB
Please verify all part numbers before ordering.			