

# **TRIPLE S** *Customs*

## **OLDSMOBILE AURORA 1995-2003 VEHICLE WIRING**

WIRING INFORMATION: 1995 Oldsmobile Aurora

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED	Ignition Harness
STARTER	PURPLE	Ignition Harness
IGNITION	PINK	Ignition Harness
SECOND IGNITION	PINK/WHITE	Ignition Harness
ACCESSORY	ORANGE	Ignition Harness
SECOND ACCESSORY	PURPLE/WHITE	Ignition Harness
POWER DOOR LOCK (+)	LT. BLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	WHITE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN/WHITE	Harness Low In Driver's Kick Or At Module Left Of Brake Pedal
PARKING LIGHTS (-)	GRAY/BLACK	At Light Switch
DOOR TRIGGER (-)	DK. BLUE	Harness Low In Driver's Kick
TRUNK/HATCH PIN (-)	ORANGE/BLACK	At Trunk Light
TRNK/HTCH RELEASE (+)	BLACK	At Trunk Release Switch
FACTRY ALARM DISARM (-)	LT. GREEN	Under Rear Seat By Battery
TACHOMETER WIRE	WHITE	In Harness Between The Engine And Firewall On Driver's Side
BRAKE WIRE (+)	WHITE	Brake Switch Or Driver's Kick Panel
HORN TRIGGER (-)	BLACK	At Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.

WIRING INFORMATION: 1996 Oldsmobile Aurora

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED	Ignition Harness
STARTER	PURPLE	Ignition Harness
IGNITION	PINK	Ignition Harness
SECOND IGNITION	PINK/WHITE	Ignition Harness
ACCESSORY	ORANGE	Ignition Harness
SECOND ACCESSORY	PURPLE/WHITE	Ignition Harness
POWER DOOR LOCK (-)	LT. BLUE	At Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	TAN	At BCM In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN/WHITE	Harness Low In Driver's Kick Or At Module Left Of Brake Pedal
PARKING LIGHTS (-)	GRAY/BLACK	At Headlight Switch
DOOR TRIGGER (-)	DK. BLUE	Harness Low In Driver's Kick Panel
TRUNK/HATCH PIN (-)	ORANGE/BLACK	At Light In Trunk
TRUNK RELEASE (+)	BLACK	Trunk Release Switch
FACTRY ALARM DISARM (-)	LT. GREEN	Under Rear Seat By Battery
TACHOMETER WIRE	WHITE	In Harness Between The Engine And Firewall On Driver's Side
BRAKE WIRE (+)	WHITE	Brake Switch Or Driver's Kick Panel
HORN TRIGGER (-)	BLACK	At Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.

WIRING INFORMATION: 1997 Oldsmobile Aurora

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED	Ignition Harness
STARTER	PURPLE	Ignition Harness
IGNITION	PINK	Ignition Harness
SECOND IGNITION	PINK/WHITE	Ignition Harness
ACCESSORY	ORANGE	Ignition Harness
SECOND ACCESSORY	PURPLE/WHITE	Ignition Harness
POWER DOOR LOCK (-)	LT. BLUE	At Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	TAN	At BCM In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN/WHITE	Harness Low In Driver's Kick Or At Module Left Of Brake Pedal
PARKING LIGHTS (-)	GRAY/BLACK	At Headlight Switch
DOOR TRIGGER (-)	DK. BLUE	Harness Low In Driver's Kick Panel
TRUNK/HATCH PIN (-)	ORANGE/BLACK	At Light In Trunk
TRUNK RELEASE (+)	BLACK	Trunk Release Switch
FACTRY ALARM DISARM (-)	LT. GREEN	Under Rear Seat By Battery
TACHOMETER WIRE	WHITE	In Harness Between The Engine And Firewall On Driver's Side
BRAKE WIRE (+)	WHITE	Brake Switch Or Driver's Kick Panel
HORN TRIGGER (-)	BLACK	At Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.

WIRING INFORMATION: 1998 Oldsmobile Aurora

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED	Ignition Harness
STARTER	PURPLE	Ignition Harness
IGNITION	PINK	Ignition Harness
SECOND IGNITION	PINK/WHITE	Ignition Harness
ACCESSORY	ORANGE	Ignition Harness
SECOND ACCESSORY	PURPLE/WHITE	Ignition Harness
POWER DOOR LOCK (-)	LT. BLUE	At Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	TAN	At BCM In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN/WHITE	Harness Low In Driver's Kick Or At Module Left Of Brake Pedal
PARKING LIGHTS (-)	GRAY/BLACK	At Headlight Switch
DOOR TRIGGER (-)	DK. BLUE	Harness Low In Driver's Kick Panel
TRUNK/HATCH PIN (-)	ORANGE/BLACK	At Light In Trunk
TRUNK RELEASE (+)	BLACK	Trunk Release Switch
FACTRY ALARM DISARM (-)	LT. GREEN	Under Rear Seat By Battery
TACHOMETER WIRE	WHITE	In Harness Between The Engine And Firewall On Driver's Side
BRAKE WIRE (+)	WHITE	Brake Switch Or Driver's Kick Panel
HORN TRIGGER (-)	BLACK	At Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 1999 Oldsmobile Aurora

WIRE	WIRE COLOR	WIRE LOCATION
12V	RED	Ignition Harness
STARTER	PURPLE	Ignition Harness
IGNITION	PINK	Ignition Harness
SECOND IGNITION	PINK/WHITE	Ignition Harness
ACCESSORY	ORANGE	Ignition Harness
SECOND ACCESSORY	PURPLE/WHITE	Ignition Harness
POWER DOOR LOCK (-)	LT. BLUE	At Harness In Driver's Kick Panel
POWER DOOR UNLOCK (5-wire reverse polarity)	TAN	At BCM In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN/WHITE	Harness Low In Driver's Kick Or At Module Left Of Brake Pedal
PARKING LIGHTS (-)	GRAY/BLACK	At Headlight Switch
DOOR TRIGGER (-)	DK. BLUE	Harness Low In Driver's Kick Panel
TRUNK/HATCH PIN (-)	ORANGE/BLACK	At Light In Trunk
TRUNK RELEASE (+)	BLACK	Trunk Release Switch
FACTRY ALARM DISARM (-)	LT. GREEN	Under Rear Seat By Battery
TACHOMETER WIRE	WHITE	In Harness Between The Engine And Firewall On Driver's Side
BRAKE WIRE (+)	WHITE	Brake Switch Or Driver's Kick Panel
HORN TRIGGER (-)	BLACK	At Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.

WIRING INFORMATION: 2001 Oldsmobile Aurora

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	DO NOT USE	Must Get 12V Constant From Battery
ORANGE and ORANGE/BLACK 12V wires at the ignition harness are low current 12V sources that should not be used to drive any high current positive circuits. Must go to the battery for 12V.		
STARTER WIRE	PURPLE OR YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	Inside Driver's Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	Inside Driver's Door At Lock Switch
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	BROWN/WHITE	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
HEADLIGHTS (-)	WHITE	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
DRIVER DOOR TRIGGER (-)	TAN	Door Module Inside Each Respective Door
PASSENGER DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Passenger Door
LEFT REAR DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Left Rear Door
RIGHT REAR DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Right Rear Door
DOME SUPERVISION (-)	GRAY	Courtesy Light Under Dash
TRUNK TRIGGER (-)	ORANGE/BLACK	At Light In Trunk
TRUNK RELEASE (-)	BLACK/WHITE	At Fuse Block Under Rear Seat
FUEL DOOR RELEASE (-)	WHITE	At Fuse Block Under Rear Seat
FACTORY ALARM DISARM (-)	LT. GREEN	Module Inside Driver's Door Above Door Speaker
TACHOMETER WIRE	PURPLE/WHITE	Ignition Coil On Top Of Motor
BRAKE WIRE (+)	WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the Pass-Key III immobilizer. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 2002 Oldsmobile Aurora

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	DO NOT USE	Must Get 12V Constant From Battery
ORANGE and ORANGE/BLACK 12V wires at the ignition harness are low current 12V sources that should not be used to drive any high current positive circuits. Must go to the battery for 12V.		
STARTER WIRE	PURPLE OR YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	Inside Driver's Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	Inside Driver's Door At Lock Switch
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	BROWN/WHITE	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
HEADLIGHTS (-)	WHITE	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
DRIVER DOOR TRIGGER (-)	TAN	Door Module Inside Each Respective Door
PASSENGER DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Passenger Door
LEFT REAR DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Left Rear Door
RIGHT REAR DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Right Rear Door
DOME SUPERVISION (-)	GRAY	Courtesy Light Under Dash
TRUNK TRIGGER (-)	ORANGE/BLACK	At Light In Trunk
TRUNK RELEASE (-)	BLACK/WHITE	At Fuse Block Under Rear Seat
FUEL DOOR RELEASE (-)	WHITE	At Fuse Block Under Rear Seat
FACTORY ALARM DISARM (-)	LT. GREEN	Module Inside Driver's Door Above Door Speaker
TACHOMETER WIRE	PURPLE/WHITE	Ignition Coil On Top Of Motor
BRAKE WIRE (+)	WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the Pass-Key III immobilizer. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 2003 Oldsmobile Aurora

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	DO NOT USE	Must Get 12V Constant From Battery
ORANGE and ORANGE/BLACK 12V wires at the ignition harness are low current 12V sources that should not be used to drive any high current positive circuits. Must go to the battery for 12V.		
STARTER WIRE	PURPLE OR YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	Inside Driver's Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	Inside Driver's Door At Lock Switch
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	BROWN/WHITE	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
HEADLIGHTS (-)	WHITE	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
DRIVER DOOR TRIGGER (-)	TAN	Door Module Inside Each Respective Door
PASSENGER DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Passenger Door
LEFT REAR DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Left Rear Door
RIGHT REAR DOOR TRIGGER (-)	DK. BLUE	Door Module Inside Right Rear Door
DOME SUPERVISION (-)	GRAY	Courtesy Light Under Dash
TRUNK TRIGGER (-)	ORANGE/BLACK	At Light In Trunk
TRUNK RELEASE (-)	BLACK/WHITE	At Fuse Block Under Rear Seat
FUEL DOOR RELEASE (-)	WHITE	At Fuse Block Under Rear Seat
FACTORY ALARM DISARM (-)	LT. GREEN	Module Inside Driver's Door Above Door Speaker
TACHOMETER WIRE	PURPLE/WHITE	Ignition Coil On Top Of Motor
BRAKE WIRE (+)	WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Module Located Just In Front Of The Blower Motor Near The Passenger Kick
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the Pass-Key III immobilizer. This must be bypassed when installing a remote start.		