

TRIPLE S *Customs*

**PORSCHE 911 1980-1993
VEHICLE WIRING**

WIRING INFORMATION: 1980 Porsche 911

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1981 Porsche 911

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column

WIRING INFORMATION: 1982 Porsche 911

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1983 Porsche 911 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1984 Porsche 911 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1985 Porsche 911 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1986 Porsche 911 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1987 Porsche 911 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1988 Porsche 911 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1989 Porsche 911 2/4 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1990 Porsche 911 2/4 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1991 Porsche 911 2/4 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1992 Porsche 911 2/4 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

WIRING INFORMATION: 1993 Porsche 911 2/4 Carrera

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch