

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	BLACK	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	Harness From Driver's Door Near Driver's Strut Tower
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness From Driver's Door Near Driver's Strut Tower
PARKING LIGHTS (+)	GRAY/RED (right) GRAY/BLK (left)	At Headlight Switch And At Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Headlight Switch And At Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	Harness By Passenger Strut Tower
FACTRY ALARM ARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
FACTRY ALARM DISARM	Some vehicles armed and disarmed with a separate alarm key switch located on end of driver's door. Other vehicles arm with lock and disarm with unlock.	Factory anti-theft unit tucked behind the heater ducting under cowling under hood. Major disassembly required to access the anti-theft unit.
TACHOMETER WIRE	GREEN or BROWN	At Ignition Coil
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	RED/BLACK	Ignition Harness
ACCESSORY WIRE	RED/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/BLUE	At Factory Anti-Theft Module Under Passenger Seat
POWER DOOR UNLOCK (-)	BROWN/GREEN	At Factory Anti-Theft Module Under Passenger Seat
PARKING LIGHTS (+)	GRAY/RED (RIGHT) GRAY/BLACK (LEFT)	At Head Light Switch Or Fuse Box
HEADLIGHTS (+)	YELLOW (LOW BEAMS)	At Head Light Switch Or Fuse Box
DOOR TRIGGER (-)	BROWN/WHITE	At Factory Anti-Theft Module Under Passenger Seat
TRUNK TRIGGER (-)	BROWN/RED	At Factory Anti-Theft Module Under Passenger Seat
HOOD TRIGGER (-)	BROWN/YELLOW	At Factory Anti-Theft Module Under Passenger Seat
FACTORY ALARM ARM	ARMS ON LOCK	
FACTORY ALARM DISARM	DISARMS ON UNLOCK	
TACHOMETER WIRE	BLACK/PURPLE	Behind Instrument Cluster
BRAKE WIRE (+)	BLACK/RED	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Window Switch
RIGHT FRONT WINDOW UP	RED/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	RED/BLACK	At Window Switch

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	YELLOW	Radio Harness	
RADIO SWITCHED	RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	WHITE	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	BLACK	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4x6"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		None available	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.