

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	In 37-Pin Plug (C1) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
STARTER WIRE (-)	YELLOW (Not For Remote Start)	In Large Plug At ECM Near Coolant Overflow Bottle Under Hood.
Notes: The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE	DK.BLUE	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK AND UNLOCK	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
Notes: Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.		
PARKING LIGHTS (+)	BROWN	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DRIVER DOOR TRIGGER (-)	LT.GREEN/BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
PASSENGER DOOR(S) TRIGGER (-)	LT.BLUE	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DOME LIGHT (-)	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK TRIGGER (-)	ORANGE/BLACK	At Light In Trunk OR If Vehicle Has Factory Keyless Entry, Wire Can Be Found In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK RELEASE (-)	BLACK/WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	WHITE or ORANGE	At Ignition Module Next To Oil Filler Cap
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Door
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Passlock II Bypass Module	DEI 556LW or DEI 555LW	Required when installing a remote start system. Refer to TechDoc 3741.

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not supply a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio Harness	
POWER ANTENNA WIRE	YELLOW	Radio Harness	
AMP TURN-ON WIRE (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Right Front Speaker	
LEFT REAR SPEAKER (+)	BROWN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Right Rear Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5"	Factory amplifier is under the driver's side dash	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3106, SCOSCHE SN1527B	METRA 70-2102, SCOSCHE GM10	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	In 37-Pin Plug (C1) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
STARTER WIRE (-)	YELLOW (Not For Remote Start)	In Large Plug At ECM Near Coolant Overflow Bottle Under Hood.
Notes: The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE	DK.BLUE	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK AND UNLOCK	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
Notes: Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.		
PARKING LIGHTS (+)	BROWN	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DRIVER DOOR TRIGGER (-)	LT.GREEN/BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
PASSENGER DOOR(S) TRIGGER (-)	LT.BLUE	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DOME LIGHT (-)	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK TRIGGER (-)	ORANGE/BLACK	At Light In Trunk OR If Vehicle Has Factory Keyless Entry, Wire Can Be Found In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK RELEASE (-)	BLACK/WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	WHITE or ORANGE	At Ignition Module Next To Oil Filler Cap
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Door
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Passlock II Bypass Module	DEI 556LW or DEI 555LW	Required when installing a remote start system. Refer to TechDoc 3741.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not supply a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio Harness	
POWER ANTENNA WIRE	YELLOW	Radio Harness	
AMP TURN-ON WIRE (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Right Front Speaker	
LEFT REAR SPEAKER (+)	BROWN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Right Rear Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5"	Factory amplifier is under the driver's side dash	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3106, SCOSCHE SN1527B	METRA 70-2102, SCOSCHE GM10	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	In 37-Pin Plug (C1) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
STARTER WIRE (-)	YELLOW (Not For Remote Start)	In Large Plug At ECM Near Coolant Overflow Bottle Under Hood.
Notes: The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE	DK.BLUE	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK AND UNLOCK	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
Notes: Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.		
PARKING LIGHTS (+)	BROWN	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DRIVER DOOR TRIGGER (-)	LT.GREEN/BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
PASSENGER DOOR(S) TRIGGER (-)	LT.BLUE	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DOME LIGHT (-)	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK TRIGGER (-)	ORANGE/BLACK	At Light In Trunk OR If Vehicle Has Factory Keyless Entry, Wire Can Be Found In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK RELEASE (-)	BLACK/WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	WHITE or ORANGE	At Ignition Module Next To Oil Filler Cap
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Door
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Passlock II Bypass Module	DEI 556LW or DEI 555LW	Required when installing a remote start system. Refer to TechDoc 3741.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio Harness	
POWER ANTENNA WIRE	YELLOW	Radio Harness	
AMP TURN-ON WIRE (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Right Front Speaker	
LEFT REAR SPEAKER (+)	BROWN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5"	Factory amplifier is under the driver's side dash	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3106, SCOSCHE SN1527B		METRA 70-2102, SCOSCHE GM10	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	In 37-Pin Plug (C1) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
STARTER WIRE (-)	YELLOW (Not For Remote Start)	In Large Plug At ECM Near Coolant Overflow Bottle Under Hood.
Notes: The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE	DK.BLUE	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK AND UNLOCK	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
Notes: Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.		
PARKING LIGHTS (+)	BROWN	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DRIVER DOOR TRIGGER (-)	LT.GREEN/BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
PASSENGER DOOR(S) TRIGGER (-)	LT.BLUE	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DOMELIGHT (-)	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK TRIGGER (-)	ORANGE/BLACK	At Light In Trunk OR If Vehicle Has Factory Keyless Entry, Wire Can Be Found In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK RELEASE (-)	BLACK/WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	WHITE or ORANGE	At Ignition Module Next To Oil Filler Cap
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Door
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Passlock II Bypass Module	DEI 556LW or DEI 555LW	Required when installing a remote start system. Refer to TechDoc 3741.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio Harness	
POWER ANTENNA WIRE	YELLOW	Radio Harness	
AMP TURN-ON WIRE (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Right Front Speaker	
LEFT REAR SPEAKER (+)	BROWN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5"	Factory amplifier is under the driver's side dash	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3302, SCOSCHE GM1587B		METRA GMOS-LAN-06, SCOSCHE GM17B	METRA 40-CR10, SCOSCHE CRAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	In 37-Pin Plug (C1) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
STARTER WIRE (-)	YELLOW (Not For Remote Start)	In Large Plug At ECM Near Coolant Overflow Bottle Under Hood.
Notes: The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE	DK.BLUE	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK AND UNLOCK	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
Notes: Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.		
PARKING LIGHTS (+)	BROWN	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DRIVER DOOR TRIGGER (-)	LT.GREEN/BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
PASSENGER DOOR(S) TRIGGER (-)	LT.BLUE	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
DOME LIGHT (-)	WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK TRIGGER (-)	ORANGE/BLACK	At Light In Trunk OR If Vehicle Has Factory Keyless Entry, Wire Can Be Found In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
TRUNK RELEASE (-)	BLACK/WHITE	In 56-Pin Plug (C3) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	WHITE or ORANGE	At Ignition Module Next To Oil Filler Cap
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	In 56-Pin Plug (C4) At BCM Which Is Part Of The Fuse And Relay Block In The Dash Below The Heater/AC Controls
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Door
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Passlock II Bypass Module	DEI 556LW or DEI 555LW	Required when installing a remote start system. Refer to TechDoc 3741.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio Harness	
POWER ANTENNA WIRE	YELLOW	Radio Harness	
AMP TURN-ON WIRE (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Right Front Speaker	
LEFT REAR SPEAKER (+)	BROWN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5"	Factory amplifier is under the driver's side dash	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3302, SCOSCHE GM1587B		METRA GMOS-LAN-06, SCOSCHE GM17B	METRA 40-CR10, SCOSCHE CRAB
Please verify all part numbers before ordering.			