

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
12V ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/WHITE	In 14-Pin Plug In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door. Unlock requires a double pulse.		
POWER DOOR UNLOCK (-)	YELLOW/BLACK	In 14-Pin Plug In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door. Unlock requires a double pulse.		
PARKING LIGHTS (+)	GREEN	In 13-Pin Plug On Top Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	In 13-Pin Plug On Top Of Fuse Box
TRUNK TRIGGER	Tied In With Doors	
REAR HATCH RELEASE (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
Notes: Test rear hatch release wire while opening hatch from handle on rear hatch.		
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/RED	At Harness On Top Of Fuse Box
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	BLUE/YELLOW	Radio Harness	
RADIO GROUND	WHITE/BLACK	Radio Harness	
RADIO SWITCH	GRAY	Radio Harness	
RADIO ILLUMINATION	GREEN	Radio Harness	
POWER ANTENNA	ORANGE	Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness	
RIGHT REAR SPEAKER (+)	RED	Radio Harness	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8209, SCOSCHE SCN2056B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
12V ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/WHITE	In 14-Pin Plug In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door. Unlock requires a double pulse.		
POWER DOOR UNLOCK (-)	YELLOW/BLACK	In 14-Pin Plug In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door. Unlock requires a double pulse.		
PARKING LIGHTS (+)	GREEN	In 13-Pin Plug On Top Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	In 13-Pin Plug On Top Of Fuse Box
TRUNK TRIGGER	Tied In With Doors	
REAR HATCH RELEASE (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
Notes: Test rear hatch release wire while opening hatch from handle on rear hatch.		
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/RED	At Harness On Top Of Fuse Box
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	BLUE/YELLOW	Radio Harness	
RADIO GROUND	WHITE/BLACK	Radio Harness	
RADIO SWITCH	GRAY	Radio Harness	
RADIO ILLUMINATION	GREEN	Radio Harness	
POWER ANTENNA	ORANGE	Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness	
RIGHT REAR SPEAKER (+)	RED	Radio Harness	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8209, SCOSCHE SCN2056B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
12V IGNITION WIRE	BLACK	Ignition Harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition Harness
12V ACCESSORY WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	BLUE/WHITE	In 14-Pin Plug In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door. Unlock requires a double pulse.		
POWER DOOR UNLOCK (-)	YELLOW/BLACK	In 14-Pin Plug In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door. Unlock requires a double pulse.		
PARKING LIGHTS (+)	GREEN	In 13-Pin Plug On Top Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	In 13-Pin Plug On Top Of Fuse Box
TRUNK TRIGGER	Tied In With Doors	
REAR HATCH RELEASE (-)	BROWN/YELLOW	Harness In Driver's Kick Panel
Notes: Test rear hatch release wire while opening hatch from handle on rear hatch.		
TACHOMETER WIRE	BLACK	At Ignition Coil
BRAKE WIRE (+)	GREEN/RED	At Harness On Top Of Fuse Box
HORN TRIGGER (-)	WHITE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	BLUE/YELLOW	Radio Harness	
RADIO GROUND	WHITE/BLACK	Radio Harness	
RADIO SWITCH	GRAY	Radio Harness	
RADIO ILLUMINATION	GREEN	Radio Harness	
POWER ANTENNA	ORANGE	Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness	
RIGHT REAR SPEAKER (+)	RED	Radio Harness	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	5.25"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8209, SCOSCHE SCN2056B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Pin 7 in 8-Pin Plug At Ignition Switch
STARTER WIRE 1	WHITE	Pin 8 in 8-Pin Plug At Ignition Switch
STARTER WIRE 2	WHITE	Pin 1 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 1	GRAY	Pin 6 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 2	WHITE	Pin 4 in 8-Pin Plug At Ignition Switch
ACCESSORY WIRE 1	BLACK	Pin 3 in 8-Pin Plug At Ignition Switch
KEYSENSE (-)	BLUE	At Ignition Key Switch
POWER DOOR LOCK (-)	BLUE	Pin 15 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory disarm wire for unlock unless the door locks do not operate with the aftermarket system when the engine is running.		
POWER DOOR UNLOCK (-)	YELLOW	Pin 16 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory arm wire for lock unless the door locks do not operate with the aftermarket system when the engine is running.		
PARKING LIGHTS (+)	GREEN	Pin 29 in White 30-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	WHITE	Pin 18 in 20-Pin Plug At Headlight Switch
LEFT FRONT DOOR TRIGGER (-)	WHITE	At Dash Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	BROWN	At Dash Fuse Box
LEFT REAR DOOR TRIGGER (-)	LIGHT BLUE	At Dash Fuse Box
RIGHT REAR DOOR TRIGGER (-)	LIGHT GREEN	At Dash Fuse Box
DOMESUPERVISION (-)	WHITE	Pin2 in White 6-Pin Plug At Dash Fuse Box
TRUNK TRIGGER (-)	LIGHT GREEN	Pin 7 in White 30-Pin Plug At Dash Fuse Box
TRUNK RELEASE (-)	ORANGE	Pin 3 in White 13-Pin Plug In Driver's Kick Panel
Notes: Test using rear handle		
FACTORY ALARM ARM (-)	LIGHT BLUE	Pin 7in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door		
FACTORY ALARM DISARM (-)	PINK	Pin 6 in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door. Requires a double pulse for unlock		
TACHOMETER WIRE (AC)	GRAY	Pin 9 in 16-Pin Data Link Connector
PARKING BRAKE (-)	BLACK	At Parking Brake Switch
BRAKE WIRE (+)	BLUE	At Brake Pedal Switch
REVERSE LIGHT (+)	RED	Pin 5 in White 32-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	LIGHT GREEN	Pin 30 in White 30-Pin Plug At Dash Fuse Box
LEFT FRONT WINDOW UP	PINK	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	WHITE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT FRONT WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW UP	RED	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW DOWN	BLUE	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door

INTERFACE	PART NUMBER	NOTES
None required		
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	ORANGE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SCN2057B	SCOSCHE TA02B	Not required
METRA 99-8209 or 99-8230	METRA 70-1761	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Pin 7 in 8-Pin Plug At Ignition Switch
STARTER WIRE 1	WHITE	Pin 8 in 8-Pin Plug At Ignition Switch
STARTER WIRE 2	WHITE	Pin 1 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 1	GRAY	Pin 6 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 2	WHITE	Pin 4 in 8-Pin Plug At Ignition Switch
ACCESSORY WIRE 1	BLACK	Pin 3 in 8-Pin Plug At Ignition Switch
KEYSENSE (-)	BLUE	At Ignition Key Switch
POWER DOOR LOCK (-)	BLUE	Pin 15 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory disarm wire for unlock unless the door locks do not operate with the aftermarket system when the engine is running.		
POWER DOOR UNLOCK (-)	YELLOW	Pin 16 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory arm wire for lock unless the door locks do not operate with the aftermarket system when the engine is running.		
PARKING LIGHTS (+)	GREEN	Pin 29 in White 30-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	WHITE	Pin 18 in 20-Pin Plug At Headlight Switch
LEFT FRONT DOOR TRIGGER (-)	WHITE	At Dash Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	BROWN	At Dash Fuse Box
LEFT REAR DOOR TRIGGER (-)	LIGHT BLUE	At Dash Fuse Box
RIGHT REAR DOOR TRIGGER (-)	LIGHT GREEN	At Dash Fuse Box
DOMESUPERVISION (-)	WHITE	Pin2 in White 6-Pin Plug At Dash Fuse Box
TRUNK TRIGGER (-)	LIGHT GREEN	Pin 7 in White 30-Pin Plug At Dash Fuse Box
TRUNK RELEASE (-)	ORANGE	Pin 3 in White 13-Pin Plug In Driver's Kick Panel
Notes: Test using rear handle		
FACTORY ALARM ARM (-)	LIGHT BLUE	Pin 7in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door		
FACTORY ALARM DISARM (-)	PINK	Pin 6 in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door. Requires a double pulse for unlock		
TACHOMETER WIRE (AC)	GRAY	Pin 9 in 16-Pin Data Link Connector
PARKING BRAKE (-)	BLACK	At Parking Brake Switch
BRAKE WIRE (+)	BLUE	At Brake Pedal Switch
REVERSE LIGHT (+)	RED	Pin 5 in White 32-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	LIGHT GREEN	Pin 30 in White 30-Pin Plug At Dash Fuse Box
LEFT FRONT WINDOW UP	PINK	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	WHITE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT FRONT WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW UP	RED	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW DOWN	BLUE	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door

INTERFACE	PART NUMBER	NOTES
None required		
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	ORANGE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SCN2057B	SCOSCHE TA02B	Not required
METRA 99-8209 or 99-8230	METRA 70-1761	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Pin 7 in 8-Pin Plug At Ignition Switch
STARTER WIRE 1	WHITE	Pin 8 in 8-Pin Plug At Ignition Switch
STARTER WIRE 2	WHITE	Pin 1 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 1	GRAY	Pin 6 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 2	WHITE	Pin 4 in 8-Pin Plug At Ignition Switch
ACCESSORY WIRE 1	BLACK	Pin 3 in 8-Pin Plug At Ignition Switch
KEYSENSE (-)	BLUE	At Ignition Key Switch
POWER DOOR LOCK (-)	BLUE	Pin 15 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory disarm wire for unlock unless the door locks do not operate with the aftermarket system when the engine is running.		
POWER DOOR UNLOCK (-)	YELLOW	Pin 16 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory arm wire for lock unless the door locks do not operate with the aftermarket system when the engine is running.		
PARKING LIGHTS (+)	GREEN	Pin 29 in White 30-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	WHITE	Pin 18 in 20-Pin Plug At Headlight Switch
LEFT FRONT DOOR TRIGGER (-)	WHITE	At Dash Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	BROWN	At Dash Fuse Box
LEFT REAR DOOR TRIGGER (-)	LIGHT BLUE	At Dash Fuse Box
RIGHT REAR DOOR TRIGGER (-)	LIGHT GREEN	At Dash Fuse Box
DOMESUPERVISION (-)	WHITE	Pin2 in White 6-Pin Plug At Dash Fuse Box
TRUNK TRIGGER (-)	LIGHT GREEN	Pin 7 in White 30-Pin Plug At Dash Fuse Box
TRUNK RELEASE (-)	ORANGE	Pin 3 in White 13-Pin Plug In Driver's Kick Panel
Notes: Test using rear handle		
FACTORY ALARM ARM (-)	LIGHT BLUE	Pin 7in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door		
FACTORY ALARM DISARM (-)	PINK	Pin 6 in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door. Requires a double pulse for unlock		
TACHOMETER WIRE (AC)	GRAY	Pin 9 in 16-Pin Data Link Connector
PARKING BRAKE (-)	BLACK	At Parking Brake Switch
BRAKE WIRE (+)	BLUE	At Brake Pedal Switch
REVERSE LIGHT (+)	RED	Pin 5 in White 32-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	LIGHT GREEN	Pin 30 in White 30-Pin Plug At Dash Fuse Box
LEFT FRONT WINDOW UP	PINK	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	WHITE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT FRONT WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW UP	RED	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW DOWN	BLUE	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door

INTERFACE	PART NUMBER	NOTES
None required		
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	ORANGE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SCN2057B	SCOSCHE TA02B	Not required
METRA 99-8209 or 99-8230	METRA 70-1761	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Pin 7 in 8-Pin Plug At Ignition Switch
STARTER WIRE 1	WHITE	Pin 8 in 8-Pin Plug At Ignition Switch
STARTER WIRE 2	WHITE	Pin 1 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 1	GRAY	Pin 6 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 2	WHITE	Pin 4 in 8-Pin Plug At Ignition Switch
ACCESSORY WIRE 1	BLACK	Pin 3 in 8-Pin Plug At Ignition Switch
KEYSENSE (-)	BLUE	At Ignition Key Switch
POWER DOOR LOCK (-)	BLUE	Pin 15 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory disarm wire for unlock unless the door locks do not operate with the aftermarket system when the engine is running.		
POWER DOOR UNLOCK (-)	YELLOW	Pin 16 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory arm wire for lock unless the door locks do not operate with the aftermarket system when the engine is running.		
PARKING LIGHTS (+)	GREEN	Pin 29 in White 30-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	WHITE	Pin 18 in 20-Pin Plug At Headlight Switch
LEFT FRONT DOOR TRIGGER (-)	WHITE	At Dash Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	BROWN	At Dash Fuse Box
LEFT REAR DOOR TRIGGER (-)	LIGHT BLUE	At Dash Fuse Box
RIGHT REAR DOOR TRIGGER (-)	LIGHT GREEN	At Dash Fuse Box
DOMESUPERVISION (-)	WHITE	Pin2 in White 6-Pin Plug At Dash Fuse Box
TRUNK TRIGGER (-)	LIGHT GREEN	Pin 7 in White 30-Pin Plug At Dash Fuse Box
TRUNK RELEASE (-)	ORANGE	Pin 3 in White 13-Pin Plug In Driver's Kick Panel
Notes: Test using rear handle		
FACTORY ALARM ARM (-)	LIGHT BLUE	Pin 7in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door		
FACTORY ALARM DISARM (-)	PINK	Pin 6 in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door. Requires a double pulse for unlock		
TACHOMETER WIRE (AC)	GRAY	Pin 9 in 16-Pin Data Link Connector
PARKING BRAKE (-)	BLACK	At Parking Brake Switch
BRAKE WIRE (+)	BLUE	At Brake Pedal Switch
REVERSE LIGHT (+)	RED	Pin 5 in White 32-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	LIGHT GREEN	Pin 30 in White 30-Pin Plug At Dash Fuse Box
LEFT FRONT WINDOW UP	PINK	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	WHITE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT FRONT WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW UP	RED	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW DOWN	BLUE	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door
INTERFACE	PART NUMBER	NOTES
None required		
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	ORANGE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SCN2057B	SCOSCHE TA02B	Not required
METRA 99-8209 or 99-8230	METRA 70-1761	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Pin 7 in 8-Pin Plug At Ignition Switch
STARTER WIRE 1	WHITE	Pin 8 in 8-Pin Plug At Ignition Switch
STARTER WIRE 2	WHITE	Pin 1 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 1	GRAY	Pin 6 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 2	WHITE	Pin 4 in 8-Pin Plug At Ignition Switch
ACCESSORY WIRE 1	BLACK	Pin 3 in 8-Pin Plug At Ignition Switch
KEYSENSE (-)	BLUE	At Ignition Key Switch
POWER DOOR LOCK (-)	BLUE	Pin 15 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory disarm wire for unlock unless the door locks do not operate with the aftermarket system when the engine is running.		
POWER DOOR UNLOCK (-)	YELLOW	Pin 16 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory arm wire for lock unless the door locks do not operate with the aftermarket system when the engine is running.		
PARKING LIGHTS (+)	GREEN	Pin 29 in White 30-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	WHITE	Pin 18 in 20-Pin Plug At Headlight Switch
LEFT FRONT DOOR TRIGGER (-)	WHITE	At Dash Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	BROWN	At Dash Fuse Box
LEFT REAR DOOR TRIGGER (-)	LIGHT BLUE	At Dash Fuse Box
RIGHT REAR DOOR TRIGGER (-)	LIGHT GREEN	At Dash Fuse Box
DOME SUPERVISION (-)	WHITE	Pin2 in White 6-Pin Plug At Dash Fuse Box
TRUNK TRIGGER (-)	LIGHT GREEN	Pin 7 in White 30-Pin Plug At Dash Fuse Box
TRUNK RELEASE (-)	ORANGE	Pin 3 in White 13-Pin Plug In Driver's Kick Panel
Notes: Test using rear handle		
FACTORY ALARM ARM (-)	LIGHT BLUE	Pin 7in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door		
FACTORY ALARM DISARM (-)	PINK	Pin 6 in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door. Requires a double pulse for unlock		
TACHOMETER WIRE (AC)	GRAY	Pin 9 in 16-Pin Data Link Connector
PARKING BRAKE (-)	BLACK	At Parking Brake Switch
BRAKE WIRE (+)	BLUE	At Brake Pedal Switch
REVERSE LIGHT (+)	RED	Pin 5 in White 32-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	LIGHT GREEN	Pin 30 in White 30-Pin Plug At Dash Fuse Box
LEFT FRONT WINDOW UP	PINK	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	WHITE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT FRONT WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW UP	RED	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW DOWN	BLUE	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door

INTERFACE	PART NUMBER	NOTES
None required		
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	ORANGE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SCN2057B	SCOSCHE TA02B	Not required
METRA 99-8209 or 99-8230	METRA 70-1761	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Pin 7 in 8-Pin Plug At Ignition Switch
STARTER WIRE 1	WHITE	Pin 8 in 8-Pin Plug At Ignition Switch
STARTER WIRE 2	WHITE	Pin 1 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 1	GRAY	Pin 6 in 8-Pin Plug At Ignition Switch
IGNITION WIRE 2	WHITE	Pin 4 in 8-Pin Plug At Ignition Switch
ACCESSORY WIRE 1	BLACK	Pin 3 in 8-Pin Plug At Ignition Switch
KEYSENSE (-)	BLUE	At Ignition Key Switch
POWER DOOR LOCK (-)	BLUE	Pin 15 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory disarm wire for unlock unless the door locks do not operate with the aftermarket system when the engine is running.		
POWER DOOR UNLOCK (-)	YELLOW	Pin 16 in White 18-Pin Plug In Driver's Kick Panel
Notes: Use factory arm wire for lock unless the door locks do not operate with the aftermarket system when the engine is running.		
PARKING LIGHTS (+)	GREEN	Pin 29 in White 30-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	WHITE	Pin 18 in 20-Pin Plug At Headlight Switch
LEFT FRONT DOOR TRIGGER (-)	WHITE	At Dash Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	BROWN	At Dash Fuse Box
LEFT REAR DOOR TRIGGER (-)	LIGHT BLUE	At Dash Fuse Box
RIGHT REAR DOOR TRIGGER (-)	LIGHT GREEN	At Dash Fuse Box
DOMESUPERVISION (-)	WHITE	Pin2 in White 6-Pin Plug At Dash Fuse Box
TRUNK TRIGGER (-)	LIGHT GREEN	Pin 7 in White 30-Pin Plug At Dash Fuse Box
TRUNK RELEASE (-)	ORANGE	Pin 3 in White 13-Pin Plug In Driver's Kick Panel
Notes: Test using rear handle		
FACTORY ALARM ARM (-)	LIGHT BLUE	Pin 7in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door		
FACTORY ALARM DISARM (-)	PINK	Pin 6 in White 18-Pin Plug In Driver's Kick Panel
Notes: Test using key in left front door. Requires a double pulse for unlock		
TACHOMETER WIRE (AC)	GRAY	Pin 9 in 16-Pin Data Link Connector
PARKING BRAKE (-)	BLACK	At Parking Brake Switch
BRAKE WIRE (+)	BLUE	At Brake Pedal Switch
REVERSE LIGHT (+)	RED	Pin 5 in White 32-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	LIGHT GREEN	Pin 30 in White 30-Pin Plug At Dash Fuse Box
LEFT FRONT WINDOW UP	PINK	At Motor In Left Front Door
LEFT FRONT WINDOW DOWN	WHITE	At Motor In Left Front Door
RIGHT FRONT WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT FRONT WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW UP	RED	In Harness Coming Into Vehicle From Left Front Door
LEFT REAR WINDOW DOWN	BLUE	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW UP	GREEN	In Harness Coming Into Vehicle From Left Front Door
RIGHT REAR WINDOW DOWN	BROWN	In Harness Coming Into Vehicle From Left Front Door

INTERFACE	PART NUMBER	NOTES
None required		
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	LIGHT GREEN	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
POWER ANTENNA (+)	ORANGE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	PURPLE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	WHITE	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SCN2057B	SCOSCHE TA02B	Not required
METRA 99-8209 or 99-8230	METRA 70-1761	Not required

Please verify all part numbers before ordering.