

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE	At Center Console Switch
POWER DOOR UNLOCK (-)	ORANGE/GREEN	At Center Console Switch
PARKING LIGHTS (+)	RED/WHITE	At Light Switch
DRIVER DOOR TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PASSENGER KICK PANEL (-)	BROWN or BLACK/YELLOW	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	YELLOW/BLUE	At Light In Trunk
TACHOMETER	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/RED	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/GREEN	Radio Harness	
RADIO SWITCHED	BLUE/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED	Radio Harness	
POWER ANTENNA (+)	RED/WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed		METRA 70-8901, SCOSCHE SU03B	Not required
<p>Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 98-8999</p>			
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE	At Center Console Switch
POWER DOOR UNLOCK (-)	ORANGE/GREEN	At Center Console Switch
PARKING LIGHTS (+)	RED/WHITE	At Light Switch
DRIVER DOOR TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PASSENGER KICK PANEL (-)	BROWN or BLACK/YELLOW	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	YELLOW/BLUE	At Light In Trunk
TACHOMETER	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/RED	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/GREEN	Radio Harness	
RADIO SWITCHED	BLUE/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED	Radio Harness	
POWER ANTENNA (+)	RED/WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed		METRA 70-8901, SCOSCHE SU03B	Not required
Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 98-8999			
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE	At Center Console Switch
POWER DOOR UNLOCK (-)	ORANGE/GREEN	At Center Console Switch
PARKING LIGHTS (+)	RED/WHITE	At Light Switch
DRIVER DOOR TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PASSENGER KICK PANEL (-)	BROWN or BLACK/YELLOW	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	YELLOW/BLUE	At Light In Trunk
TACHOMETER	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/RED	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/GREEN	Radio Harness	
RADIO SWITCHED	BLUE/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED	Radio Harness	
POWER ANTENNA (+)	RED/WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed		METRA 70-8901, SCOSCHE SU03B	Not required
Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 98-8999			
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
POWER DOOR LOCK (-)	ORANGE	At Center Console Switch
POWER DOOR UNLOCK (-)	ORANGE/GREEN	At Center Console Switch
PARKING LIGHTS (+)	RED/WHITE	At Light Switch
DRIVER DOOR TRIGGER (-)	BLUE/BLACK	Harness In Driver's Kick Panel
PASSENGER KICK PANEL (-)	BROWN or BLACK/YELLOW	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	YELLOW/BLUE	At Light In Trunk
TACHOMETER	YELLOW	At Ignition Coil
BRAKE WIRE (+)	WHITE/RED	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/GREEN	Radio Harness	
RADIO SWITCHED	BLUE/YELLOW	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED	Radio Harness	
POWER ANTENNA (+)	RED/WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/BLACK	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed		METRA 70-8901, SCOSCHE SU03B	Not required
<p>Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 98-8999</p>			
Please verify all part numbers before ordering.			