

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/YELLOW	At Relays Behind Fuse Box
POWER DOOR UNLOCK (-)	BROWN	At Relays Behind Fuse Box
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/YELLOW	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	BLUE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/YELLOW	At Relays Behind Fuse Box
POWER DOOR UNLOCK (-)	BROWN	At Relays Behind Fuse Box
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/YELLOW	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	BLUE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/YELLOW	At Relays Behind Fuse Box
POWER DOOR UNLOCK (-)	BROWN	At Relays Behind Fuse Box
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/YELLOW	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	BLUE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/YELLOW	At Relays Behind Fuse Box
POWER DOOR UNLOCK (-)	BROWN	At Relays Behind Fuse Box
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/YELLOW	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	BLUE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/YELLOW	At Relays Behind Fuse Box
POWER DOOR UNLOCK (-)	BROWN	At Relays Behind Fuse Box
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/YELLOW	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	BLUE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/YELLOW	At Relays Behind Fuse Box
POWER DOOR UNLOCK (-)	BROWN	At Relays Behind Fuse Box
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/YELLOW	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	BLUE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/YELLOW	At Relays Behind Fuse Box
POWER DOOR UNLOCK (-)	BROWN	At Relays Behind Fuse Box
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/YELLOW	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	BLUE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	YELLOW/BLACK	Ignition Harness
12V ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	BROWN/YELLOW	At Relays Behind Fuse Box
POWER DOOR UNLOCK (-)	BROWN	At Relays Behind Fuse Box
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER (-)	BLACK/ORANGE	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BLACK/YELLOW	At Light In Trunk
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	BLUE/YELLOW	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/ORANGE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			