

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Pin 3 in White 3-Pin Plug At Dash Fuse Box
STARTER WIRE 1	PURPLE/WHITE	Pin 8 in White 8-Pin Plug At Keyless Start Module Under Driver Dash
STARTER WIRE 2	SS1: RED/YELLOW SS2:WHITE/BLACK	Pins 4 and 15 in White 20-Pin Plug At Keyless Start Module Under Driver Dash

**Notes:** Push-button start

IGNITION WIRE 1	BROWN/BLACK	Pin 7 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
ACCESSORY WIRE 1	BROWN/YELLOW	Pin 8 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
ACCESSORY WIRE 2	PINK/BLUE	Pin 27 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
KEYSENSE (-)	WHITE/BLUE	At Keyless Start Module Under Driver Dash
POWER DOOR LOCK (-)	YELLOW/BLACK	Harness Coming Into Vehicle From Driver Door
POWER DOOR UNLOCK (-)	YELLOW/GREEN	Harness Coming Into Vehicle From Driver Door
PARKING LIGHTS (+)	RED/YELLOW	Pin 22 in White 28-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	RED/BLUE	Pin 3 in Black 14-Pin Plug At Headlight Switch
ALL DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module In Passenger Kick Panel
LEFT FRONT DOOR TRIGGER (-)	BLACK/ORANGE	At Keyless Start Module Under Driver Dash
RIGHT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	At Keyless Start Module Under Driver Dash
LEFT REAR DOOR TRIGGER (-)	BLACK/BLUE	At Keyless Start Module Under Driver Dash
RIGHT REAR DOOR TRIGGER (-)	GREEN/ORANGE	At Keyless Start Module Under Driver Dash
DOMESUPERVISION (-)	RED/WHITE	In Harness In Driver's Kick Panel Running Towards Rear
TRUNK TRIGGER (-)	BLACK/YELLOW	Pin 14 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
HOOD TRIGGER (-)	WHITE/GREEN	Pin 2 in White 8-Pin Plug At Keyless Start Module Under Driver Dash
TRUNK RELEASE (-)	PURPLE/WHITE	Pin 4 in White 6-Pin Plug At Release Switch
FACTORY ALARM ARM (-)	LIGHT GREEN	Pin 18 in White 40-Pin Plug At Keyless Start Module Under Driver Dash

**Notes:** Test by turning key in driver's door

FACTORY ALARM DISARM (-)	GRAY/BLUE	Pin 13 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
<b>Notes:</b> Test by turning key in driver's door		
TACHOMETER WIRE (AC)	RED, BLUE/WHITE, GREEN/BLACK or GREEN	Any Fuel Injector
PARKING BRAKE (-)	RED/GREEN	At Parking Brake Switch
BRAKE WIRE (+)	GREEN/WHITE	Pin 1 in White 28-Pin Plug At Dash Fuse Box
REVERSE LIGHT (+)	LIGHT GREEN/RED	Pin 7 in White 28-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	BLUE/WHITE	Pin 3 in White 8-Pin Plug At Keyless Start Module Under Driver Dash

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/RED	Radio Harness	
RADIO SWITCHED	WHITE	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		8" subwoofer if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SI2229B	SCOSCHE SI05B	Not required
None available	METRA 70-1721	Not required

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Pin 3 in White 3-Pin Plug At Dash Fuse Box
STARTER WIRE 1	PURPLE/WHITE	Pin 8 in White 8-Pin Plug At Keyless Start Module Under Driver Dash
STARTER WIRE 2	SS1: RED/YELLOW SS2:WHITE/BLACK	Pins 4 and 15 in White 20-Pin Plug At Keyless Start Module Under Driver Dash
IGNITION WIRE 1	BROWN/BLACK	Pin 7 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
ACCESSORY WIRE 1	BROWN/YELLOW	Pin 8 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
ACCESSORY WIRE 2	PINK/BLUE	Pin 27 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
KEYSENSE (-)	WHITE/BLUE	At Keyless Start Module Under Driver Dash
POWER DOOR LOCK (-)	YELLOW/BLACK	Harness Coming Into Vehicle From Driver Door
POWER DOOR UNLOCK (-)	YELLOW/GREEN	Harness Coming Into Vehicle From Driver Door
PARKING LIGHTS (+)	RED/YELLOW	Pin 22 in White 28-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	RED/BLUE	Pin 3 in Black 14-Pin Plug At Headlight Switch
ALL DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module In Passenger Kick Panel
LEFT FRONT DOOR TRIGGER (-)	BLACK/ORANGE	At Keyless Start Module Under Driver Dash
RIGHT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	At Keyless Start Module Under Driver Dash
LEFT REAR DOOR TRIGGER (-)	BLACK/BLUE	At Keyless Start Module Under Driver Dash
RIGHT REAR DOOR TRIGGER (-)	GREEN/ORANGE	At Keyless Start Module Under Driver Dash
DOME SUPERVISION (-)	RED/WHITE	In Harness In Driver's Kick Panel Running Towards Rear
TRUNK TRIGGER (-)	BLACK/YELLOW	Pin 14 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
HOOD TRIGGER (-)	WHITE/GREEN	Pin 2 in White 8-Pin Plug At Keyless Start Module Under Driver Dash
TRUNK RELEASE (-)	PURPLE/WHITE	Pin 4 in White 6-Pin Plug At Release Switch
FACTORY ALARM ARM (-)	LIGHT GREEN	Pin 18 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
FACTORY ALARM DISARM (-)	GRAY/BLUE	Pin 13 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
TACHOMETER WIRE (AC)	RED, BLUE/WHITE, GREEN/BLACK or GREEN	Any Fuel Injector
PARKING BRAKE (-)	RED/GREEN	At Parking Brake Switch
BRAKE WIRE (+)	GREEN/WHITE	Pin 1 in White 28-Pin Plug At Dash Fuse Box
REVERSE LIGHT (+)	LIGHT GREEN/RED	Pin 7 in White 28-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	BLUE/WHITE	Pin 3 in White 8-Pin Plug At Keyless Start Module Under Driver Dash

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/RED	Radio Harness	
RADIO SWITCHED	WHITE	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		8" subwoofer if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SI2229B	SCOSCHE SI05B	Not required
None available	METRA 70-1721	Not required

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Pin 3 in White 3-Pin Plug At Dash Fuse Box
STARTER WIRE 1	PURPLE/WHITE	Pin 8 in White 8-Pin Plug At Keyless Start Module Under Driver Dash
STARTER WIRE 2	SS1: RED/YELLOW SS2:WHITE/BLACK	Pins 4 and 15 in White 20-Pin Plug At Keyless Start Module Under Driver Dash
IGNITION WIRE 1	BROWN/BLACK	Pin 7 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
ACCESSORY WIRE 1	BROWN/YELLOW	Pin 8 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
ACCESSORY WIRE 2	PINK/BLUE	Pin 27 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
KEYSENSE (-)	WHITE/BLUE	At Keyless Start Module Under Driver Dash
POWER DOOR LOCK (-)	YELLOW/BLACK	Harness Coming Into Vehicle From Driver Door
POWER DOOR UNLOCK (-)	YELLOW/GREEN	Harness Coming Into Vehicle From Driver Door
PARKING LIGHTS (+)	RED/YELLOW	Pin 22 in White 28-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	RED/BLUE	Pin 3 in Black 14-Pin Plug At Headlight Switch
ALL DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module In Passenger Kick Panel
LEFT FRONT DOOR TRIGGER (-)	BLACK/ORANGE	At Keyless Start Module Under Driver Dash
RIGHT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	At Keyless Start Module Under Driver Dash
LEFT REAR DOOR TRIGGER (-)	BLACK/BLUE	At Keyless Start Module Under Driver Dash
RIGHT REAR DOOR TRIGGER (-)	GREEN/ORANGE	At Keyless Start Module Under Driver Dash
DOME SUPERVISION (-)	RED/WHITE	In Harness In Driver's Kick Panel Running Towards Rear
TRUNK TRIGGER (-)	BLACK/YELLOW	Pin 14 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
HOOD TRIGGER (-)	WHITE/GREEN	Pin 2 in White 8-Pin Plug At Keyless Start Module Under Driver Dash
TRUNK RELEASE (-)	PURPLE/WHITE	Pin 4 in White 6-Pin Plug At Release Switch
FACTORY ALARM ARM (-)	LIGHT GREEN	Pin 18 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
FACTORY ALARM DISARM (-)	GRAY/BLUE	Pin 13 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
TACHOMETER WIRE (AC)	RED, BLUE/WHITE, GREEN/BLACK or GREEN	Any Fuel Injector
PARKING BRAKE (-)	RED/GREEN	At Parking Brake Switch
BRAKE WIRE (+)	GREEN/WHITE	Pin 1 in White 28-Pin Plug At Dash Fuse Box
REVERSE LIGHT (+)	LIGHT GREEN/RED	Pin 7 in White 28-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	BLUE/WHITE	Pin 3 in White 8-Pin Plug At Keyless Start Module Under Driver Dash

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/RED	Radio Harness	
RADIO SWITCHED	WHITE	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		8" subwoofer if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SI2229B	SCOSCHE SI05B	Not required
None available	METRA 70-1721	Not required

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Pin 3 in White 3-Pin Plug At Dash Fuse Box
STARTER WIRE 1	PURPLE/WHITE	Pin 8 in White 8-Pin Plug At Keyless Start Module Under Driver Dash
STARTER WIRE 2	SS1: RED/YELLOW SS2:WHITE/BLACK	Pins 4 and 15 in White 20-Pin Plug At Keyless Start Module Under Driver Dash
IGNITION WIRE 1	BROWN/BLACK	Pin 7 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
ACCESSORY WIRE 1	BROWN/YELLOW	Pin 8 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
ACCESSORY WIRE 2	PINK/BLUE	Pin 27 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
KEYSENSE (-)	WHITE/BLUE	At Keyless Start Module Under Driver Dash
POWER DOOR LOCK (-)	YELLOW/BLACK	Harness Coming Into Vehicle From Driver Door
POWER DOOR UNLOCK (-)	YELLOW/GREEN	Harness Coming Into Vehicle From Driver Door
PARKING LIGHTS (+)	RED/YELLOW	Pin 22 in White 28-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	RED/BLUE	Pin 3 in Black 14-Pin Plug At Headlight Switch
ALL DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module In Passenger Kick Panel
LEFT FRONT DOOR TRIGGER (-)	BLACK/ORANGE	At Keyless Start Module Under Driver Dash
RIGHT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	At Keyless Start Module Under Driver Dash
LEFT REAR DOOR TRIGGER (-)	BLACK/BLUE	At Keyless Start Module Under Driver Dash
RIGHT REAR DOOR TRIGGER (-)	GREEN/ORANGE	At Keyless Start Module Under Driver Dash
DOME SUPERVISION (-)	RED/WHITE	In Harness In Driver's Kick Panel Running Towards Rear
TRUNK TRIGGER (-)	BLACK/YELLOW	Pin 14 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
HOOD TRIGGER (-)	WHITE/GREEN	Pin 2 in White 8-Pin Plug At Keyless Start Module Under Driver Dash
TRUNK RELEASE (-)	PURPLE/WHITE	Pin 4 in White 6-Pin Plug At Release Switch
FACTORY ALARM ARM (-)	LIGHT GREEN	Pin 18 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
FACTORY ALARM DISARM (-)	GRAY/BLUE	Pin 13 in White 40-Pin Plug At Keyless Start Module Under Driver Dash
TACHOMETER WIRE (AC)	RED, BLUE/WHITE, GREEN/BLACK or GREEN	Any Fuel Injector
PARKING BRAKE (-)	RED/GREEN	At Parking Brake Switch
BRAKE WIRE (+)	GREEN/WHITE	Pin 1 in White 28-Pin Plug At Dash Fuse Box
REVERSE LIGHT (+)	LIGHT GREEN/RED	Pin 7 in White 28-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	BLUE/WHITE	Pin 3 in White 8-Pin Plug At Keyless Start Module Under Driver Dash

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/RED	Radio Harness	
RADIO SWITCHED	WHITE	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)	BLACK	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	WHITE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLUE/RED	Radio Harness or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
1" tweeter, 6.5"	6.5"		8" subwoofer if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE SI2229B	SCOSCHE SI05B	Not required
None available	METRA 70-1721	Not required

Please verify all part numbers before ordering.