

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-7991, SCOSCHE SI02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-7991, SCOSCHE SI02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-7991, SCOSCHE SI02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-7991, SCOSCHE SI02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-7991, SCOSCHE SI02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-7991, SCOSCHE SI02B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-2009, SCOSCHE GN2200B	METRA 70-7992, SCOSCHE SI03B	Not required	
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED	4-door: Behind Driver's Front Speaker
DOOR TRIGGER (-)	2-door: BROWN	2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/GRAY	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLACK/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	WHITE/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/GRAY	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GREEN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GREEN/GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	4"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2009, SCOSCHE GN2200B		METRA 70-7992, SCOSCHE SI03B	Not required
Please verify all part numbers before ordering.			