

# **TRIPLE S** *Customs*

## **SUZUKI SIDEKICK 1990-1999 VEHICLE WIRING**

WIRING INFORMATION 1990 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1991 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1992 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1993 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1994 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1995 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1996 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1997 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1998 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column

WIRING INFORMATION 1999 Suzuki Sidekick

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
POWER DOOR LOCK (-)	PINK	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	RED/YELLOW	At Light Switch
DOOR TRIGGER (-)	4-door: BLACK/RED 2-door: BROWN	4-door: Behind Driver's Front Speaker 2-door: Behind Driver's Rear Speaker.
TACHOMETER WIRE	BROWN/WHITE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/GREEN	Harness At Steering Column