

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	BLUE/BLACK	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Door Lock Module Under Dash Right Of Brake Pedal
POWER DOOR UNLOCK (-)	PINK/GREEN	At Door Lock Module Under Dash Right Of Brake Pedal
PARKING LIGHTS (+)	RED/YELLOW	At Black Connector At The Fuse Box
DOOR TRIGGER (-)	BLACK/RED	White Connector At Fuse Box Or Factory Keyless Entry Module In Driver's Kick Panel
TRUNK TRIGGER (-)	Tied In With Doors	
TACHOMETER WIRE	BROWN	At Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE or BLUE/GREEN	Harness At Steering Column Or Factory Keyless Entry Module
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	ORANGE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2003, SCOSCHE GM1583B		METRA 70-2003	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	BLUE/BLACK	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Door Lock Module Under Dash Right Of Brake Pedal
POWER DOOR UNLOCK (-)	PINK/GREEN	At Door Lock Module Under Dash Right Of Brake Pedal
PARKING LIGHTS (+)	RED/YELLOW	At Black Connector At The Fuse Box
DOOR TRIGGER (-)	BLACK/RED	White Connector At Fuse Box Or Factory Keyless Entry Module In Driver's Kick Panel
TRUNK TRIGGER (-)	Tied In With Doors	
TACHOMETER WIRE	BROWN	At Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE or BLUE/GREEN	Harness At Steering Column Or Factory Keyless Entry Module
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	ORANGE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2003, SCOSCHE GM1583B		METRA 70-2003	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	BLUE/BLACK	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Door Lock Module Under Dash Right Of Brake Pedal
POWER DOOR UNLOCK (-)	PINK/GREEN	At Door Lock Module Under Dash Right Of Brake Pedal
PARKING LIGHTS (+)	RED/YELLOW	At Black Connector At The Fuse Box
DOOR TRIGGER (-)	BLACK/RED	White Connector At Fuse Box Or Factory Keyless Entry Module In Driver's Kick Panel
TRUNK TRIGGER (-)	Tied In With Doors	
TACHOMETER WIRE	BROWN	At Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE or BLUE/GREEN	Harness At Steering Column Or Factory Keyless Entry Module
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	ORANGE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2003, SCOSCHE GM1583B		METRA 70-2003	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	BLUE/BLACK	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Door Lock Module Under Dash Right Of Brake Pedal
POWER DOOR UNLOCK (-)	PINK/GREEN	At Door Lock Module Under Dash Right Of Brake Pedal
PARKING LIGHTS (+)	RED/YELLOW	At Black Connector At The Fuse Box
DOOR TRIGGER (-)	BLACK/RED	White Connector At Fuse Box Or Factory Keyless Entry Module In Driver's Kick Panel
TRUNK TRIGGER (-)	Tied In With Doors	
TACHOMETER WIRE	BROWN	At Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE or BLUE/GREEN	Harness At Steering Column Or Factory Keyless Entry Module
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	ORANGE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2003, SCOSCHE GM1583B		METRA 70-2003	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	BLUE/BLACK	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Door Lock Module Under Dash Right Of Brake Pedal
POWER DOOR UNLOCK (-)	PINK/GREEN	At Door Lock Module Under Dash Right Of Brake Pedal
PARKING LIGHTS (+)	RED/YELLOW	At Black Connector At The Fuse Box
DOOR TRIGGER (-)	BLACK/RED	White Connector At Fuse Box Or Factory Keyless Entry Module In Driver's Kick Panel
TRUNK TRIGGER (-)	Tied In With Doors	
TACHOMETER WIRE	BROWN	At Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE or BLUE/GREEN	Harness At Steering Column Or Factory Keyless Entry Module
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	ORANGE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2003, SCOSCHE GM1583B		METRA 70-2003	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/GREEN	Ignition Harness
12V IGNITION WIRE	BLACK/BLUE	Ignition Harness
SECOND IGNITION WIRE	BLUE/BLACK	Ignition Harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition Harness
SECOND ACCESSORY WIRE	BLUE	Ignition Harness
STARTER WIRE	BLACK/RED or BLACK/YELLOW	Ignition Harness
POWER DOOR LOCK (-)	PINK	At Door Lock Module Under Dash Right Of Brake Pedal
POWER DOOR UNLOCK (-)	PINK/GREEN	At Door Lock Module Under Dash Right Of Brake Pedal
PARKING LIGHTS (+)	RED/YELLOW	At Black Connector At The Fuse Box
DOOR TRIGGER (-)	BLACK/RED	White Connector At Fuse Box Or Factory Keyless Entry Module In Driver's Kick Panel
TRUNK TRIGGER (-)	Tied In With Doors	
TACHOMETER WIRE	BROWN	At Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE or BLUE/GREEN	Harness At Steering Column Or Factory Keyless Entry Module
LEFT FRONT WINDOW UP	YELLOW	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	RED	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	WHITE/BLACK	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BROWN/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	ORANGE/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	LIGHT GREEN/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	LIGHT GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	GRAY/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2003, SCOSCHE GM1583B		METRA 70-2003	Not required
Please verify all part numbers before ordering.			